

CTC BIM Manager SuiteTM User Guide

Contents

Suite Overview	6
Installation and Configuration	6
License Activation and Management	6
Changing Licensing at Any Time	7
Borrowing a Cloud Shared License	8
Returning a Borrowed Cloud Shared License Early	9
Common Toolbar and Menu Buttons	11
Getting Help	11
Getting More Help: Videos	11
Submitting a Feature Request	
Reporting a Bug	
Contacting Technical Support	13
Getting Application Information	13
Suite Settings	15
Starting Suite Settings	15
Changing Which Ribbon Buttons are Visible and how they Appear	16
Seeing and Changing License Status	
Family Preview Manager	20
Overview	20
Starting Family Preview Manager	20
General Settings	21
Appearance Settings	21
Batch Processing Files	23
Family Tools	25
Overview	25

Starting Family Tools	
Delete Backup Files	
Type Catalog Tools	
Compare Shared Parameters	
Merge Shared Parameters	
Family File Version Detector	
Project Cleaner	
Overview	
Starting Project Cleaner	
Removing Elements from the Model	
Purge	
Saved Selections and Options	
Revision Cloud Remover	
Overview	
Starting Revision Cloud Remover	
Remove Selected Revision Clouds	
Remove All Revision Clouds	
Dimension Checker	
Overview	
Starting Dimension Checker	
Search Filters	
Working With the Search Results Grid	
Family Checker	42
Overview	
Starting Family Checker	
Family Checker Configuration	

Saving and Loading Configurations	
Checking Families	
Reports	
Family Processor	49
Overview	
Starting Family Processor	
Tool Buttons	51
Family-Level Processing Tab	
Lookup Tables Tab	
Change Materials Tab	
Change Parameters Tab	
Processing Order Tab	
Select Families & Begin Tab	
Last Log Tab	
Family Processor Best Practices	
Import & Link Manager	86
Overview	
Starting Import & Link Manager	
The Main Dialog	
Save Report	
Load/Unload Files	
Find and Replace Paths	
Manage Revit Project Links	93
Introduction	
Starting Manage Revit Project Links	
Modifying Link Properties in Revit Files	

Schedule Parameter Resolver	95
Introduction	
Starting Schedule Parameter Resolver	
Choosing a Shared Parameter File	
Resolving Schedule Parameters	
Options	
Shared Parameter Manager	
Introduction	
Starting Shared Parameter Manager	
Master Shared Parameter Files	
Group Management	
Managing Parameters	
Source Shared Parameter Files	
Filters	
Exporting Parameters	
Selection Sets	
Loading Parameters Into the Project	
Options	
Type Swapper	126
Starting Type Swapper	
Duplicate Families	
Swapping Elements	
Approved Styles and Types	
Saving and Loading Selections	
Appendix	132
Family Checker Rating Conventions	

Suite Overview

The products from CTC Software offer many utilities for enhancing the productivity of users of Revit[®] software from Autodesk[®]. Revit users launch these tools from within the Revit software.

Although written to function correctly with the international community in mind wherever possible, CTC Software products are currently only tested on English USA versions of Revit running on English USA versions of Windows.

Installation and Configuration

The standard workstation installation requires little more than running the setup program. For more information regarding topics such as automating workstation installations and preconfiguring workstation settings, please refer to the *CTC BIM Suites Installation and Configuration Guide* document.

License Activation and Management

The productivity tools provided with light background colors are free tools that run without any special licensing. The productivity tools provided with dark background colors are premium tools which require licensing.

Unless initially preconfigured by the system administrator, the first time any of the licensed tools are launched from the Revit ribbon, the *Product and License Information* dialog will appear which requires acknowledging the licensing requirements by clicking the OK button at the bottom.

Current Status		
Application: CTC BIM N	Manager Suite	^
License type: Unknown	1	
Cloud Shared or Free Tr	ial licensing	
Cloud Shared or Free Ti Either cloud shared of premium tools to wo	ial Licensing or free trial licensing requires your company to have a CTC a rk when you have an Internet connection with at least one lice	ccount, and only allows the nse available.
Cloud Shared or Free Ti Either cloud shared premium tools to wo If your organization o	ial Licensing or free trial licensing requires your company to have a CTC a rk when you have an Internet connection with at least one lice does not have a CTC account, but you want to create an accou	ccount, and only allows the nse available. unt and begin a trial, <u>click here.</u>
Cloud Shared or Free Tr Either cloud shared premium tools to wo If your organization You must click the C	ial Licensing or free trial licensing requires your company to have a CTC a rk when you have an Internet connection with at least one lice does not have a CTC account, but you want to create an acco IK button below to accept and start using cloud shared or free	ccount, and only allows the nse available. unt and begin a trial, <u>click here</u> , t <mark>rial licensing</mark> .
Cloud Shared or Free Tr Either cloud shared premium tools to wo If your organization of You must click the C	ial Licensing or free trial licensing requires your company to have a CTC a rk when you have an Internet connection with at least one lice does not have a CTC account, but you want to create an account IK button below to accept and start using cloud shared or free	ccount, and only allows the nse available. unt and begin a trial, <u>click here,</u> trial licensing.

CTC Software products support only cloud-shared licensing, and also free trial licenses that use CTC's cloud licensing engine. You must click the OK button to activate the cloud licensing and acknowledge using a CTC cloud account.

The licensing will automatically apply to all of the tools that are included in the suite which require licensing. So once the first tool has configured the licensing, the other premium tools in the suite will automatically use the same configuration.

Once you click the OK button, you may be asked to login, if you aren't already logged in from using another CTC product.

Either way, once you have logged in, the product will be configured for cloud shared licensing:



and the licensing screen will be updated to show that:

C Product and License Information	×
Current Status	
Application: CTC BIM Manager Suite License type: CloudShared - Logged in user: David - This license is currently not borrowed. - Subscription expires on 6/1/2024 6:00:00 PM	^
Cloud Shared or Free Trial Licensing Either cloud shared or free trial licensing requires your company to have a CTC account, and only allows the premium tools to work when you have an Internet connection with at least one license available. Borrow Sign Out	
Close	e

At this point, you may borrow a license for offline use (if permitted by the administrator). You may also Sign Out from the cloud licensing system in case a different user needs to sign in on this computer.

Changing Licensing at Any Time

Licensing can also be changed at any time using the "Suite Settings" tool, which is discussed below, or by using the "Suite Licensing" menu choice in the licensed add-in tools:



Borrowing a Cloud Shared License

If a license is needed in anticipation of being disconnected from the Internet, borrowing a license can ensure that the CTC tools are available for use when offline.

IMPORTANT: For normal use of the software, where you have a standard Internet connection, you DO NOT need to borrow a license. Borrowing a license is normally only needed when you know you will need to use the software at a time when you won't have a reliable Internet connection. While you have a license borrowed, that is one less shared license available to all other users.

NOTE: Borrowing is only available for purchased cloud shared licenses. Borrowing is not available for trial licenses.

IMPORTANT: In the event your computer is lost, stolen or damaged (e.g. a hard drive crash) **an administrator CAN NOT recover a borrowed license.** In that case, the license will be unavailable to all users until the borrow period has naturally expired. *As such, you only want to borrow a license for the barest minimum amount of time needed.*

Begin by opening the *Product and License Information* screen from either the main pulldown menu of a premium tool, or from the Suite Settings add-in. From here, click the 'Borrow...' button to begin the process of choosing the length of time to borrow a Cloud Shared license.

C Product and License Information	×
Current Status	
Application: CTC BIM Manager Suite License type: CloudShared - Logged in user: David - This license is currently not borrowed. - Subscription expires on 6/1/2024 6:00:00 PM	^
Cloud Shared or Free Trial Licensing Either cloud shared or free trial licensing requires your company to have a CTC account, and only allows the premium tools to work when you have an Internet connection with at least one license available. Borrow Borrow	
CI	ose

The date selector should appear:

C Borrow a Cloud License	<
CTC BIM Manager Suite	
Borrowing a cloud shared license is NOT required to use the software, as long as you have an Internet connection.	
Borrowing a cloud shared license allows you to continue using this software even when you don't have an Internet connection, but it takes away a shared license available to everyone else until it expires or is manually returned early by you.	
In the event your computer is damaged, an Administrator CAN NOT recover a borrowed license, so only borrow for the minimum time needed.	
Choose within the valid date range	
Thursday, April 27, 2023 - Friday, May 26, 2023	
▲ May 2023 ▶	
Sun Mon Tue Wed Thu	
14 15 16 17 18 19 20	
21 22 23 24 25 26	
Today: 4/26/2023	
Borrow this license until this same time on:	
Thursday, May 11, 2023	
To borrow a license, click on a license return date in the calendar and then click the Borrow License button.	
Borrow License Cancel	

Confirm the date selection and click the *Borrow License* button. A success message should appear.

	×
A license has been successfully borrowed until Thursday, May 11, 2023	
ОК]

Returning a Borrowed Cloud Shared License Early

To return the license early, in the Product and License Information form, find the Return Early... button and click it.

urrent Status	
pplication: CTC BIM Manager Suite icense type: CloudShared - This license is currently borrowed until 5/11/2023 1:53:49 PM	· 🥓
oud Shared or Free Trial Licensing	
Either cloud shared or free trial licensing requires your comp premium tools to work when you have an Internet connection	any to have a CTC account, and only allows the with at least one license available.

A prompt will appear confirming that the license should be returned.



Click the Yes button, then you should see:



The license status should now show a 'not borrowed' message.



Common Toolbar and Menu Buttons

Getting Help

In the toolbar, clicking the "Help" button will display this user guide.



Getting More Help: Videos

An alternate source of help is to click on the Videos button, which will display a list of tool-specific videos in your web browser.



Submitting a Feature Request

If you have an idea for enhancing a feature or would like to see a new feature added to the software, you can either use the "Request Feature" button on the About dialog (seen below) or can access that functionality using the "Request Feature" drop-down menu choice:



Selecting this option will open the Support page on the CTC web site, which allows you to add a request for a new feature by selecting the Wish List option.

Reporting a Bug

If you encounter what you feel is an issue or incorrect operation in the software, you can report this as a "bug" by either using the "Report Bug" button on the About dialog (seen below) or can access that functionality using the "Report Bug" drop-down menu choice:



Selecting this option will open the Support page on the CTC web site, which allows you to submit the information about the issue.

Contacting Technical Support

In the toolbar, clicking the "Support" button will open the Support page on the CTC web site. This button may be hidden by your system administrator.



Selecting this option will open the Support page on the CTC web site.

Getting Application Information

In the toolbar, clicking the "About" button will display a dialog which shows information about this tool.



This screen should look like this:

About Type Swapper	×
CTC SOFTWARE	Buy Now!
	Request Feature
Type Swapper	Report Bug
This tool makes it easy to change the type or style used for text, dimensions and line elements. Family elements can also be swapped.	
Website: <u>https://ctcsoftware.com</u>	
Contact Support: https://ctcsoftware.com/support	Installed suite version: 25.3
System Information	Download Latest Suite Installer
Copyright ©2024 CTC Software	ОК

Suite Settings

The Suite Settings tool allows suite-level changes to be applied.

NOTE: You may need to restart Revit in order to see any changes made with this tool take effect.

NOTE: Your system administrator may disable some features of this application.

Starting Suite Settings

On the Revit ribbon, click on the "Suite Settings" button.



Depending on how the ribbon buttons are configured, the button may be labeled "BIM Manager Suite Settings" and be located under the "Free Tools" dropdown button on the *CTC BIM Manager Suite* panel.



This will launch the application, which should look something like this:

S CTC BIM Manager Suite Settings	×
SS - 🕡 Help 👲 Support 🕕 About	
Changing settings with this application may require restarting Revit before the chang will take effect.	jes
Ribbon Button Visibility Licensing	
The buttons that are checked below will be visible in the Revit ribbon:	
BIM Manager Suite Settings Family Tools Project Cleaner Revision Cloud Remover Dimension Checker Family Processor Import and Link Manager Schedule Parameter Resolver Shared Parameter Manager Group free tools under a single ribbon button Group premium tools under a single ribbon button Use small icons for ungrouped tools in the Revit ribbon	~
Save	
www.ctcsoftware.com	.:

Changing Which Ribbon Buttons are Visible and how they Appear

The first tab in the Suite Settings tool allows changing which ribbon buttons are available, if this feature has not been disabled by the system administrator. The *CTC Suites Installation and Configuration* document explains how ribbon button availability can be controlled more automatically using either configuration files or Active Directory security group definitions.

S CTC BIM Manager Suite Settings
SS 🗸 🔞 Help 👲 Support 🕕 About
Changing settings with this application may require restarting Revit before the changes will take effect.
Ribbon Button Visibility Licensing
The buttons that are checked below will be visible in the Revit ribbon:
BIM Manager Suite Settings Family Tools Project Cleaner Revision Cloud Remover Dimension Checker Family Checker Family Processor Import and Link Manager Schedule Parameter Resolver Shared Parameter Manager Type Swapper
Group free tools under a single ribbon button
Group premium tools under a single ribbon button
Use small icons for ungrouped tools in the Revit ribbon
Save
www.ctcsoftware.com

For any ribbon buttons that you don't want to have available, simply clear the checkmark by their name and then click the "Save" button.

If you turn off the button for this application itself, the following dialog will appear when you try to save that change:



Selecting the grouping checkboxes near the bottom of the dialog will condense the tools into a dropdown button. This is the default behavior when the tools are installed on a new computer:

	Free Dim Family Family Tools Checker Checker Processo	Import & r Link Mgr	SFR Schedule Parar Resolver	n Shared Type Param Mgr Swapper
	CTC	BIM Manag	er Suite	
	Free Dim Family Family	Import 8	STR Schedule Para	SM TS m Shared Type Param Mar Swapper
	Tools Checker Checker Process	lowana	C it	Palani Ngi Swappei
ł	SS BIM Manager Suite Settings	BIIVI IVIanag	ger Suite	
9	FT Family Tools	View 1	×	
1	Project Cleaner			
u	Revision Cloud Remover			

Note that if only one tool within a group is visible, the button for that tool will be placed directly on the panel. So there will be no drop-down button if there would be only one tool to show underneath it.

Either free or premium tools (or both) can be ungrouped. For example, these settings:



results in this:



Selecting the "Use small icons for ungrouped tools in the Revit ribbon" checkbox can save some ribbon space for ungrouped tools. For example, these settings:



results in this:

Suite Settings	💀 Rev Cloud Remover	F Family Processor	Channel Denner Man
🗾 Family Tools	📧 Dim Checker	1 Import & Link Mgr	Smared Param Mgr
📧 Project Cleaner	📧 Family Checker	Schedule Param Resolver	Is Type Swapper
	CTC BI	M Manager Suite	

Seeing and Changing License Status

The second tab in the Suite Settings tool allows seeing the current license status and changing the licensing:

5	CTC BIM Manager Suite Settings	×						
SS - 🕡 Help 🕦 Ab	out							
Changing settings with t will take effect.	this application may require restarting Revit before th	e changes						
Current License Status: Application: CTC BIM Ma	anager Suite	~						
License type: NetworkFloating								
(Status updated at: 9:28:56 AM)								
		~						
	Change Licensing							

The top portion of this screen shows how the licensing is currently configured for this suite. Clicking the "Change Licensing..." button will show the dialog that allows changing how the suite is licensed:

Application: CTC BIM Mar	anager Suite	^
License type: Network Flo - This license is current	oating tly not borrowed.	
		~
License Type		
Cloud Shared or Free	Trial License	Borrow
	al licensing requires your company to have a CTC account, and only allows	the second sec
tools to work when yo you have a CTC accord	count login, click the Apply button below.	his option and
Cloud shared and tria tools to work when yo you have a CTC acco If you don't have a CT	ion have an Internet connection (unleasy you borrow a license). If selecting the count login, click the Apply button below. TC account and want to start a free trial, <u>click here</u> .	his option and
 Cloud shared and tria tools to work when yo you have a CTC accord If you don't have a CT If you don't have a CT Network Floating 	TC account and want to start a free trial, <u>click here</u> , License Server: MyServer	Borrow

For more information on how the *Product and License Information* dialog works, please review the "License Activation and Management" section of this document, above.

Family Preview Manager

Overview

The Family Preview Manager can be used to set default preview images (thumbnail). It works on components, detail items, annotations and most other Revit families that are stored externally to project. Preview images are used both by Windows to show a thumbnail in Windows Explorer and by Revit when viewing the properties of a family.

Note that some families do not support thumbnail previews such as profiles.

The previews can be set up in the following ways:

- Default Appearance if nothing is specified by category, use the view angle, display style and detail level set as default
- Appearance By Category determine the view directions display style and detail level based on category

Starting Family Preview Manager

On the "CTC Software" tab, in the BIM Manager Suite ribbon, the Family Preview Manager button will be located in the Free Tools panel.

Family Preview Manager

FPM can process the current family or a file/folder in batches.



Options has the settings which determines how the previews are created.

FM Family Preview Manager				
FM 👻 🗄 Options 💡 Reset Active Family Visibility 🔞 Help 💽 Videos 🧃	About	Ŧ		
EM Options				×
Settings File Location: T:\gondolas.fpmsettings	В	rowse	Save /	٨s
Remember Main Window Size and Postition				
✓ Clean Backup Files				
General Settings Appearance Settings				

General Settings

General Settings defines how all families will be processed.

- Preview Name: determines the view to use for previews. If the view doesn't exist, it will be created.
- Set as active view: the view with the preview name will be set active.
- Enable preview visibility: approximates the appearance of the family as placed in a project default values shown in labels, for example
- Smooth edges with anti-aliasing: curved edges will look less pixelated
- Show dimensions: when applicable, dimension objects will appear in preview
- Show reference planes: entire extent of planes will be shown. May make actual objects appear very small
- Show reference lines: similar effect as planes
- Show levels: similar effect as planes primarily applicable for level hosted families
- Show text notes: note objects will appear in preview (not necessarily labels)
- Show invisible lines: some lines normally invisible will appear in preview
- Show flip controls: controls such as the direction of openings or doors will be displayed
- Show room calculation points: similar effect as planes and levels may force small object sizes
- Show host elements: a door and the wall, for example
- Show connector elements: the connections used in MEP elements will be shown
- Show void elements: normally invisible, useful for showing clearance elements for example
- Show light sources: for families with lighting, show the mesh

Appearance Settings

In addition to setting the default, it is possible to specify different settings by categories. This is especially helpful for families which differ in display such as doors (preview in elevation) versus mechanical equipment (preview in 3D from top left).

The **Default Appearance** options are analogous to Revit's view type (View Angle equals plan, reflected, elevation and 3D), display styles and detail level properties. The settings chosen here will be used for categories which do not have an **Appearance Template** defined.

View Angle:	Plan View: Floor	
Display Style:	Realistic	
View Detail Level:	Fine	

Appearance by Category has functions to create many "templates" to apply to categories of families.



To define appearance templates, first create one by clicking on the "New Appearance Template" tool button:

Appearance by Category				
Categories	Categories			nplates
	₽ 🖽 🖻		🎦 🧷 🗙	E E
⊕ Air Terminals	^	~	New Appearance Template	or / Realistic / Fine)
Balusters				

Choose the desired options in View Angle, Display Style and Detail level:

Template Name Doors and Windows Elevation View Angle: Elevation: Front Display Style: Shaded With Edges	Previe	w Appearance Template	
View Angle: Elevation: Front Display Style: Shaded With Edges	emplate Name	Doors and Windows Elevation	
Display Style: Shaded With Edges	/iew Angle:	Elevation: Front	v
	isplay Style:	Shaded With Edges	v
Detail Level: Fine	etail Level:	Fine	v

Finally, give the template an appropriate name and click OK to save it.

In the categories section, search for the door category and expand it in the list. To use the defined appearance template for all of the host types in the category, first, select it then the appearance template Finally, click the right-pointing arrow:

Catego	ories	3	Appearance	Templates
door		e 🎽	🎦 🧷 🗙	E E
Doors			Doors Windows Elevat	tion (Elevation_Front / Shade
Doors: Ceiling			2	
Doors: Face	-		-	
Doors: Floor				
Doors: Roof				
Doors: Unhosted				
Doors: Wall				

Select individual host types if desired. View types remaining in the category/type list will use the Default Appearance settings:



To save the configuration for later use, Browse to a folder and give the settings file ("*.fpmsettings") a name.

Batch Processing Files

To add multiple families for processing, choose them individually or entire folders by using the appropriate buttons. Here, a folder was selected. Each of the families contained in the folder and subfolders are added to list for processing.

The family's current preview image is displayed (as it was when last saved).

Ocument Batch	
Add File(s)	Add Folder(s) Remove Selected Remove All
Preview Image	File Name
	R\Projects\Revit Express Tools\Common Tools\Family Preview Manager\Testing ∧
	R\Projects\Revit Express Tools\Common Tools\Family Preview Manager\Testing
	Aprojects\Revit Express Tools\Common Tools\Family Preview Manager\Testing

Overwrite Family will save the family after processing.

USE CAUTION! Revit will upgrade the family if it is being processed in a version later than it was last saved!

Choose a location to save a copy of the family after processing. This will not modify the original but it will not re-create the same folder structure. *Therefore, it is recommended to copy the families first and then choose to overwrite.*

Click Process to begin:

	Cance	el		
	Arrojects (Nevit Express 1001s	Common roots (ranning Free		
1.00 SM				
<			>	
Overwrite Family				
Save Family to new loca	tion:			
T:\FPM updated families			Browse	
			Process	

When processing is complete, a log will show successes or failures.

Clear the list and add the folder chosen as the new location to view the result. Family Preview Manager will display the preview as it was set.

Add Folder(s) Remove Selected Remove All	
F le Name	
T: FPM updated families\Window-Casement-Double-Awning.rfa	^
T: FPM updated families\Window-Casement-Double.rfa	
T: FPM updated families\Window-Double-Hung-Arch-Head.rfa	~
	Add Folder(s) Remove Selected Remove All F le Name Image: Comparison of the selected of the selec

Note: Windows Explorer may not show the same preview image under some circumstances.

Family Tools

Overview

Family Tools makes it easy to work with files commonly used to create Revit Families. Family Tools provides functionality to:

- Delete the "backup" files Revit creates when working on families
- Copy comma-delimited "csv" files to equivalent "txt" files, which makes type catalog creation easy by leveraging Microsoft Excel to do most of the editing
- Compare the contents of two shared parameters files
- Safely merge selected contents from one shared parameters file to another
- List which version of Revit was used to create one or more families

Starting Family Tools

On the Revit ribbon, click on the "Family Tools" button.



Delete Backup Files

This tab makes it easy to find and delete selected backup files that Revit created.

IMPORTANT: Files that are deleted using this tool are deleted <u>permanently</u>. They will not be available in the Recycle Bin.

FI Family Tools						
FT • 🔞 Help 🕦 A	bout					
Delete Backup Files	pe Catalog Tools	Compare Shared Params	Merge Shared Params	Family File Version D	etector	
Family files folder: C	:\Temp					Browse
Revit backup files found	:					
C:\Temp\Family1.00	001.fa 002.fa					
C:\Temp\Family2.00	001.rfa					
C:\Temp\Family2.00	002.rfa 001.rfa					
C:\Temp\Family3.00	002.rfa					
Select All Dese	lect All Invert	Selection				Refresh List
						Recursive Search
		De	lete SelectedBackup File	s		

Use the "Browse..." button to find the top-level directory to be searched. If the "Recursive Search" checkbox is selected, subdirectories will be included in the search for backup files.

The "Refresh List" button forces the tool to read through the directory again, displaying the current list of backup files that exist in case the list of files has changed since the last time it looked.

Once it is done finding backup files, simply deselect the backup files that should not be deleted and then use the "Delete Selected Backup Files" button to delete the remaining ones that are checked.

Type Catalog Tools

Type catalogs are comma-delimited text files that Revit reads when loading a family file into a project. They must be in the same folder as the family being loaded, and they must have exactly the same file name as the family file, but instead have a ".txt" file name extension.

Typically the easiest way to edit type catalogs is by using a tool that can create comma-delimited text files, such as Microsoft Excel. However, Excel's native file name extension for these is ".csv" instead of ".txt"

One practice is to create master type catalog files in Excel and save them as ".csv" files from Excel. Simply doubleclicking on these files from Windows Explorer will usually automatically open them again in Excel for later editing. Once the files are done being edited in Excel, they can be *copied* and renamed to the equivalent ".txt" file name.

However, this copying-and-renaming process can be very tedious, especially if many family files are being created or edited.

The "Type Catalog Tools" tab automates this copying-and-renaming process:

FI Family Tools	
FT - @ Help () About	
Delete Backup Files Type Catalog Tools ompare Shared Params Merge Shared Params Family File Version Detector	
Type catalog folder: C:\Temp	Browse
Type catalog CSV files found:	
V Family3.csv V Family4.csv	
Select All Deselect All Invert Selection	Refresh List
Copy Selected CSV Files to TXT Files	

As with the "Delete Backup Files" tab, files to not be copied-and-renamed can easily be deslected before the "Copy Selected CSV Files to TXT Files" button is clicked.

IMPORTANT: This process will silently replace any existing txt files with the contents from their source csv files.

Compare Shared Parameters

Shared parameters files are specially-formatted text files that define the names and data types for special parameters that are used in Revit. For example, a shared parameter called "Voltage" might exist that is defined to be of the Revit data type "Electrical Potential."

Each of these parameters has other information, such as what group they belong to and, most importantly, a special property called a Globally Unique IDentifier ("GUID"), which is a special set of characters that uniquely identifies this parameter from all others that might be created by anyone. For example: ee1f8bb8-e503-49a8-bd5b-170d64400d82

Sometimes multiple shared parameters files come into play. For example, one company may create shared parameters for use in the families that represent its products, whereas a design firm that is using these Revit families may have their own shared parameters. Managing multiple shared parameters files can be difficult.

The "Compare Shared Parameters" tab makes it easy to see the differences between two shared parameters files:

FI Family Tools															• ×
FT - @ Help () About															
	Come Charles														
Delete Backup Files Type Catalog To	Compare Shared Param	is Merg	je Shared F	Params	Family File V	ersion D	etector								
Shared Parameters File 1		_			h			Sha	ared Parameter	s File 2	2				
C:\Temp\Shared Parameters 1.bt			Brow	/se	_		_	C:\	Temp\Shared	Param	eters 2.txt			Br	owse
						Compare		G	enerate Report			-			
1 'File 1' Unique Groups					Copy to Clip	board	1 'File 2' Ur	nique	Groups					Copy to	Clipboard
Name	.▲ ID						Name					ID			
Mechanical	6						Roof					18			
183 'File 1' Unique Parameters					Copy to Clip	board	6 'File 2' Ur	nique	Parameters					Copy to	Clipboard
Name	 DataType 	Visible	GUID			^	Name			⊾ Da	taType	Visib	le GUID		^
Blender Description	TEXT	1	a8d593b	d-ea95-	-499d-8943-7b	11b	Manifold I	nput	1 Diameter	PIP	E_SIZE	1	21578e4c-b262-	4e35-8c76-5ff0332	06
Boiler Water Pressure Drop	PIPING_PRESSURE	1	a66ce4ea	a-9966-	-4361-85e3-61	c5ft	Manifold I	nput	2 Diameter	PIP	E_SIZE	1	cefa99a4-3d4d-4	#87-9790-c11e8b6	94 ≡
Branch Quantity	INTEGER	1	3370db5	5-feb6-4	4f1e-8f90-deaa	a54a	Manifold I	nput	Diameter	PIP	E_SIZE	1	e779b2ab-13c2-	44c0-bc7c-25d800	95
Chilled Water 2 Entering Temperature	PIPING_TEMPERATU	1	47d4729	e-2c44-	-4294-a052-ed	481 🖵	Manifold (Dutpu	t 1 Diameter	PIP	E_SIZE	1	2abcd395-4964-	42f8-ac35-6f54b6b	1f3
•						+	Manifold (Dutpu	t 2 Diameter	PIP	E_SIZE	1	f4d08723-fd59-4	ae6-b1ea-2e2bca0	b2 🔻
374 Common Parameters							,	1	Copy to Clipbo	ard	13 Comm	on Grou	IDS	Convito	Clipboard
Name	 DataType 		1	Visible	GUID					^	Name				<u>^</u>
Actual Exhaust Air Flow	HVAC_AIR_FLOW	1	1	1	137c6e04-d8	9d-469f-9	fa9-b926e1d	11			Construe	ction		20	
Actual Fan Powered Box Induced Air	Flow HVAC_AIR_FLOW	1	1	1	97319351-9af	a-4aea-b	422-c6429c1	d3			Dimensi	ons		1	
Actual Fan Powered Box Primary Air F	low HVAC_AIR_FLOW	1	1	1	a588f307-7b3	0-415e-b	d0f-4cf681c7	34			Electrica	al		5	
										*					*
1 Parameter Conflicts														Copy to	Clipboard
File 1 Name File 2 Name	Conflict Description Fil	e 1 ID			F	File 2 ID				File	1 Data Typ	e	File 2 Data Type	File 1 Visible	File 2
Width Width	GUID mismatch 210	05d4af-c	860-4fed-at	b0a-d9a	aef1c59ffa 1	06f2a8b-	3006-4864-aa	f0-d0)7ea744b6f1	LEN	GTH		LENGTH	1	1
								_							•

In this example, at the bottom we can see the "Width" parameter defined in each file conflict with each other. This means that Revit will treat them as two separate parameters, with different meanings, when it is likely the intention is that they have the same meaning.

Near the "Compare" button is a "Generate Report" checkbox. When checked the results will also appear in a pop-up window as a report that can be easily copied to the clipboard.

Merge Shared Parameters

There are times when it is desirable to combine parameters from one shared parameters file into another shared parameters file. When done, this will provide a single shared parameters file that can be referenced by Revit.

Autodesk strongly recommends that shared parameters files NOT be edited manually, for example using a tool such as notepad. This is because it is very easy for a person to make a mistake, which would result in a corrupt shared parameters file.

Fortunately, the "Merge Shared Parameters" tool makes it easy to <u>safely</u> copy shared parameters from one file to another. This tool takes care of things like ensuring the parameter from the source file ends up in the correct group in the destination file, even if the group IDs in the files are different. It also prevents the importing of parameters from the source file that are in conflict with existing parameters in the destination file.

	les Type Cata	log Tools Com	pare Shared	Params Me	rge Shared Para	ams Family File Version D	Detector					
ROM shared p	arameters file:	C:\Temp\Share	d Parameter	rs 1.bd	_	_					Browse	
) shared para	meters file:	C:\Temp\Share	d Parameter	rs 2.txt 🤞	_	é.					Browse	Swap Fil
ROM paramet	ers to merge:	Merge? Nar	ne	-		Group)ata Type	_			
Load 'From'	Parameters	Aver	age Annual	Operating Cos	st	Energy Analysis	c	URRENCY				
La base Calas		I Blen	der Air Press	ure Drop		Mechanical - Air Flow	н	VAC_PRESSURE				
umber Select	ted;	Ø Blen	der Descript	ion		Mechanical	Т	EXT				
		Ø Boile	r Water Pre	ssure Drop		Mechanical	P	IPING_PRESSURI				
		Bran	ch Connecti	ion Diameter		Dimensions	P	IPE_SIZE			_	
		Select All	Deselect	All Inver	Selection				[Generate Report	Merge a	and Preview
Groups Import	ted		Copy	to Clipboard	2 Parameters	Imported						Copy to Clipboar
Name			ID		Name		DataType		Visib	le GUID		
lechanical			25		Blender Desc	cription	TEXT		1	a8d593bd-ea95-4	199d-8943-7b11b	64b
					Boiler Water	Pressure Drop	PIPING_PRESS	URE	1	a66ce4ea-9966-4	1361-85e3-61c5f	8d34
Parameter Co	nflicts (Not Imp	orted)			490.							Copy to Clipboard
From Name	To Name	Conflict Des	cription	From ID		To ID		From Data T	ype	To Data Type	From Visible	To Visible
	Width	GUID misma	tch	106f2a8b-30	06-4864-aaf0-d	07ea744b6f1 2105d4af-c	c860-4fed-ab0a-d9aef1c5	9ffa LENGTH		LENGTH	1	1
lidth												
lidth												

In this example, the 4 checked parameters seen plus the "Width" parameter were selected for importing. Only two were found that didn't already exist in the destination shared parameters file and didn't conflict with any existing parameters in the destination shared parameters file.

IMPORTANT: Clicking the "Merge and Preview" button <u>DOES NOT</u> update the destination shared parameters file. It only does the merge *in memory*. You must explicitly click the "Save Merged Results" button in order to get the final shared parameters file to be created.

If the "Sort Saved Params" option is checked when saving, the final file will have the parameters sorted by their names.

Family File Version Detector

This detects the version of Revit that was last used to save family files. This is useful for determining if upgrading of family files is needed, or perhaps if a family can be used in projects that are not on the current release of Revit. It will also show the category of each family file.

FI	Fam	ily Tools				- 0	×
F	- (🕡 Help р Videos 🗶 Support 🕕 About					
Dele	ete Ba	ckup Files Type Catalog Tools Compare Shared Params Merge Shared Params	Family File Version D	Detector			
Pa	rent fo	older: C:\Program Files\Autodesk\Revit 2020\Samples				Browse	
		Refresh Files List				Copy Grid to Clipboar	rd
		FileName	Revit Version	Category	Revit Build Date Found	Short File Name	^
•		C:\Program Files\Autodesk\Revit 2020\Samples\advanced_sample_family.rfa				advanced_sample_family.rfa	
		C:\Program Files\Autodesk\Revit 2020\Samples\basic_sample_family.rfa				basic_sample_family.rfa	
		C:\Program Files\Autodesk\Revit 2020\Samples\rac_advanced_sample_family.rfa				rac_advanced_sample_family.rfa	а
		C:\Program Files\Autodesk\Revit 2020\Samples\rac_basic_sample_family.rfa				rac_basic_sample_family.rfa	
		C:\Program Files\Autodesk\Revit 2020\Samples\rme_advanced_sample_family.rfa				rme_advanced_sample_family.rf	a
<				i	i	1	>
To	remo	ve rows from processing, highlight them and use the Del key (does NOT delete files)					
			Detect Versions				

If there are families that appear in the search results that should not be evaluated, simply Ctrl+click on the row header to select multiple items in the list and click the "Delete" key on the keyboard. This <u>will not</u> delete the family files, but instead will simply remove them from this list of families to evaluate.

Once only the family files whose information is needed are on the list, click the "Detect Versions" button to have it analyze the families on the list and then display the results:

P	🛛 Fam	nily Tools					_		×
F	T -	🕜 Help 🛛	🕨 Videos 👲 Support 🕕 About						
D	elete B	ackup Files	Type Catalog Tools Compare Shared Params Merge Shared Params	Family File Version	Detector				
F	Parent f	older:	C:\Program Files\Autodesk\Revit 2020\Samples Recursive file search				Browse		
			Refresh Files List				Copy Grid	to Clipboa	rd
		FileName		Revit Version	Category	Revit Build Date Found	Short File Name		^
	•	C:\Program	n Files\Autodesk\Revit 2020\Samples\advanced_sample_family.rfa	Revit 2020	Generic Models	1/9/2019 3:15:00 PM	dvanced_sample_fam	nily	
		C:\Program	n Files\Autodesk\Revit 2020\Samples\basic_sample_family.rfa	Revit 2020	Furniture	1/9/2019 3:15:00 PM	asic_sample_family		
		C:\Program	n Files\Autodesk\Revit 2020\Samples\rac_advanced_sample_family.fa	Revit 2020	Generic Models	1/9/2019 3:15:00 PM	ac_advanced_sample	e_family	
		C:\Program	n Files\Autodesk\Revit 2020\Samples\rac_basic_sample_family.rfa	Revit 2020	Fumiture	1/9/2019 3:15:00 PM	ac_basic_sample_fam	nily	_
		C:\Program	n Files\Autodesk\Revit 2020\Samples\rme_advanced_sample_family.rfa	Revit 2020	Mechanical Equipment	1/9/2019 3:15:00 PM	me_advanced_sample	e_family	
	<	1			i .			3	>
1	To remo	ve rows fror	n processing, highlight them and use the Del key (does NOT delete files)						
				Detect Version	IS				

The "Copy Grid to Clipboard" button can be used to copy the data into the clipboard, which can then be pasted into other applications, such as Microsoft Excel.

Project Cleaner

Overview

Removing information from a Revit model is important to protect intellectual property and also to help reduce the file size of models prior to being linked into projects or prior to sending projects to outside consultants. Project cleaner removes views, view templates, view filters, images, CAD links, schedules and sheets from Revit projects.

Starting Project Cleaner

On the Revit ribbon, click on the "Project Cleaner" button.



Removing Elements from the Model

Project cleaner has multiple tabs which are used to select the Revit categories and object types for removal.

Project Cleaner	-	×
💦 - 🗙 Remove 🚽 Save Selection 🚰 Load Selection 🖌 Purge 🗄 Options 🔞 Help р Videos 👲 Support 🕦 About		
Views View Templates Filters Sheets Spatial Objects Links Imports Images		
B ○ Schedules B ○ Legends		

Check the checkbox next to each element that should be removed. The check all and check none tools in the upper right corner affect only the check boxes on the active tab.

Once all desired selections have been made on all tabs click the "Remove" button in the toolbar at the top of the dialog. This will remove all checked items on all tabs.



Before deleting the elements, a confirmation dialog will be displayed:

Project	Cleaner - Remove Objects	×
	WARNING!	
	The following number of Views, Sheets, Links and images will be removed:	
	Views: 29 View Templates: 9 Filters: 2 Sheets: 6 Links: 0 Images: 5	
	OK Cancel	

Purge

It can be helpful to purge a model to remove unused elements before or after cleaning. The "Purge" tool invokes Revit's "Purge Unused" feature and is provided as a convenience.

Saved Selections and Options

To save or re-load the list of elements to clean on the project, use the save and load tools on the menu.

📧 Project Cleaner					_		×
PC - X Remove	🛃 Save Selection 📂 Load Selection	∢ Purge…	E Options	🕜 Help	Videos	🕦 About	
Views View Templates	Filters Sheets Links Images					\checkmark	

This is particularly useful if this is a Revit model that will undergo the cleaning process regularly.

The options dialog controls default behavior of the add-in. It also contains sorting options for the lists of items in the interface.

🔁 Options 🛛 🗙
Remember the size and position of the main window
Warn if organization method may take a long time to process
View Organization
O Туре
Discipline/Type
◯ Type/Discipline
O Phase/Type
○ On Sheets or Used/Type
Sheet Organization
⊖ All
O Drawn By
◯ Issue Date
◯ Prefix
Empty or Used
Links
Show Revit, CAD and DWF links
Only show Revit links
OK Cancel

HINT: if Project Processor detects that the View Organization option selected could require a minute or more to query, a message will be presented with information about that situation. In particular, the **"On Sheets or Used/Type"** organization method is often the cause which should be taken into consideration.

Revision Cloud Remover

Overview

Revision Cloud Remover deletes all **non-issued** revision cloud instances from each view in a Revit project.

Note: While the tool does not merge all the revision cloud schedules, the revision cloud information will be removed from the sheets.

Starting Revision Cloud Remover

On the Revit ribbon, click on the "Revision Cloud Remover" button.



Remove Selected Revision Clouds

Click on the ribbon button and select the revisions you want to delete from all views in the current project:

Select All
Select None
Remove

Clicking 'Remove' will complete the process and all selected revisions will be removed.

Remove All Revision Clouds

To easily remove all revision clouds from the project click the 'Select All' button at the top right of the dialog.

Revision Cloud Remover	22
RR - 🔞 Help 🕕 About	
Revision Cloud Names	Select All
 ✓ 1 - Revision 1 (3) ✓ 3 - Revision 3 (4) ✓ 4 - Revision 4 (4) 	Select None
	Remove

Clicking 'Remove' will complete the process and all selected revisions will be removed.

Dimension Checker

Overview

This tool is only available for the 2013 and later versions of Revit. Dimension Checker identifies dimension strings using the dimension override options and presents them for review. Additional filter options can be used to narrow the search results.

Starting Dimension Checker

On the Revit ribbon, click on the "Dimension Checker" button.



Search Filters

The first step when using dimension checker is to select the search options. The three options for filtering search results are "Dimension Value", "Text Fields" and a list of specific characters to search for. These options are related directly to the native Revit "Dimension Text" dialog that is used to configure dimension overrides in Revit:

Dimension Text			
Note: this tool on model geor	replaces or a netry.	ppends dimensions value	s with text and has no effect
Dimension V	alue		
Ouse Actual Value		8' - 4 7/8"]
Replace	With Text	8' - 5".	
Text Fields			
	Above:		
Prefix:		Value:	Suffix:
	Below:	8' - 4 7/8"	
Segment Dimension Leader Visibility: By Element			
		ОК Са	ancel Apply

In the "Dimension Value" box in the next image, select whether to search for dimension strings set to "Use Actual Value" and/or dimensions set to use the "Replace with Text" option.

NOTE: When both "Use Actual Value" and "Replace with Text" are selected at the same time, no dimensions will be filtered from the search results unless also including other search criteria, such as for text fields or those text values that contain specific characters.
DC			Dimensi	on Checker				- 🗆	x
DC - 🔍 Show 🔓 Select 🗄 Options	📕 Save Report.	🔞 Help	Videos	🚺 About					
Select the dimension overrides to search for: Dimension Value Use Actual Value Replace with Text Text Fields Above Left Value Right Below Match All Fields Include Exclude	Element ID	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
EQ Match Case Use a new line for each Match All Phrases Search Search	<							Dimensions Sho	> wn: 0 .;;

The "Text Fields" filter can be used to only return dimension strings that have an override configured for the prefix, suffix, above or below fields. Once enabled, select the checkboxes next to each override property for which to search.

DC			Dimens	ion Checker				- 🗆	×
DC - Q Show 🔓 Select 🗄 Options	📕 Save Report	🔞 Help	Videos	🕕 About					
Select the dimension overrides to search for: Dimension Value Use Actual Value Replace with Text Text Fields Left Value Right Below	Element ID	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
Match All Fields Include EQ Match Case Use a new line for each search criterion. Search									
Ready.	<							Dimensions Sho	> own: 0 .:

The "Text Fields" checkboxes will normally return any dimensions with any of the overrides configured ("or" logic), however by checking the "Match all Fields" checkbox, only dimension strings that have all of the selected overrides configured will be displayed ("and" logic).

DC			Dimensi	on Checker				_ □	×
DC - 🔍 Show 🔓 Select 🗄 Options	📕 Save Report	🔞 Help	Videos	🚺 About					
Select the dimension overrides to search for: Dimension Value Use Actual Value Replace with Text	Element ID	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
Text Fields Above Above Left Value Right Below Match All Fields									
O Include									
Match Case Use a new line for each search criterion.									
Ready.								Dimensions Sho	wn: 0 .::

To search or filter for dimension strings that contain specific characters or phrases, use the Search controls:

DC			Dimensio	on Checker				_ □	×
▶ Show & Select	Save Report.	🔞 Help 🚺	Videos (🗊 About					
Select the dimension overrides to search for: Dimension Value Use Actual Value Replace with Text Text Fields Above	Element ID	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
Left Value Right Below Watch All Fields									
Include C Exclude EQ									
Match Case Use a new line for each search criterion.									
© Ready.	<						[Dimensions Sho	> wn: 0:

Each phrase or character should be entered on its own line in the box below. Choose whether to include or exclude dimensions containing the terms. Press the Enter key to start a new line. In this example the period, comma and dash characters have been added as search criteria:

DC				Dimensi	on Checker				- 🗆	×
► Coptions	🚽 Save	Report	🕢 Help	Videos	🚺 About					
Select the dimension overrides to search for:	Eler ID	nent	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
	6503	548 F	ROOF AC	2 of 4	3'-11 7/8"	7R @ 6.84" =		3'-11 3/4"	7R @ 6.84" =	
Beplace with Text	6503	548 F	ROOF AC	3 of 4	7'-11 3/4"				14R @ 6.84"	
Theplace with rext	6503	548 F	ROOF AC	4 of 4	6'-10 1/4"				12R @ 6.84"	
✓ Text Fields	6504	430 F	ROOF AC	3 of 4	10'-1"				11T@11"=	
Above	6504	619 F	ROOF AC	2 of 3	11'-10 1/2"				13T @ 11" =	
	6505	009 F	ROOF AC	2 of 4	5'-6"				6T@11"	
Left 🖌 Value 🗌 Right	6505	612 F	ROOF AC	3 of 4	6'-5''				7T @11" =	
Below	6656	934 N	IEP EQUI	1 of 2	2'-9"	4T @ 11" =		2'-9"	4T @ 11" =	
Match All Fields	6661	680 N	IEP ACC	1 of 3	8'-3''				9T @ 11" =	
	6661	900 N	MEP ACC	1 of 3	8'-3''				9T@11"=	
	7227	923 T	UNNEL	1 of 2	3'-8"				4T @11"=	
Include EQ EQ Match Case Use a new line for each search criterion.										
Search	٤							Di	mensions Show	> n: 11;

The "Match Case" and "Match All Phrases" checkboxes can be used further narrow the search results:

00			Dimens	ion Checker				- 🗆	×
► C Show & Select	s 🛃 Save Repo	rt 🔞 Help	Videos	🕕 About					
Select the dimension overrides to search for:	Element ID	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
	6503548	ROOF AC	2 of 4	3'-11 7/8"	7R @ 6.84" =		3'-11 3/4"	7R @ 6.84" =	
	6503548	ROOF AC	3 of 4	7'-11 3/4"				14R @ 6.84"	
	6503548	ROOF AC	4 of 4	6'-10 1/4"				12R @ 6.84"	
✔ Text Fields	6504430	ROOF AC	3 of 4	10'-1"				11T @ 11" =	
Above	6504619	ROOF AC	2 of 3	11'-10 1/2"				13T @ 11" =	
	6505009	ROOF AC	2 of 4	5'-6''				6T@11"	
Left 🖌 Value Right	6505612	ROOF AC	3 of 4	6'-5''				7T @11" =	
Below	6656934	MEP EQUI	1 of 2	2'-9"	4T @ 11" =		2'-9"	4T @ 11" =	
Match All Fields	6661680	MEP ACC	1 of 3	8'-3''				9T @ 11" =	
	6661900	MEP ACC	1 of 3	8'-3''				9T @ 11" =	
	7227923	TUNNEL	1 of 2	3'-8''				4T @11"=	
O Include Exclude									
EQ									
Match Case Use a new line for each									
Match All Phrases search criterion.									
Search									
	<								>
🕲 Ready.							0	Imensions Showr	n: 11

Once all search criteria have been specified, click the "Search" button. To refresh the result, click the refresh icon at the lower left corner of the window.

Working With the Search Results Grid

The search results will be displayed on the right side of the dialog. For each dimension the following information is collected and displayed:

- Element ID The Revit ID of the dimension
- Host View Which view the dimension is located on
- Segments List how many dimensions lines are of the same value
- Actual Value The original value of the dimension
- Replace with Text Value Shows the text value used to replace the dimension if configured
- Text Above Shows text above if configured for the dimension string
- Text Below Shows text below if configured for the dimension string
- Text Left Shows prefix text if configured for the dimension string
- Text Right Shows Suffix text if configured for the dimension string

The "Show" button can be used to find a specific dimension in the project. Select a single dimension and click the "Show" button, or double-click on the dimension row. Dimension Checker will open the host view and zoom in on the dimension.

NOTE: The Dimension Checker dialog is modeless, so the Revit project is active and accessible while the tool is open. The "Show" option can be used to help navigate around the model to find dimension strings for editing without closing Dimension Checker between edits.

DC			Dimens	ion Checker				- 🗆	×
DC Show Select 🗄 Options	🛃 Save Repo	t 🔞 Help	Videos	🕕 About					
Select the dimension overrides to search for:	Element ID	Host View	Segments	Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	Text Right
	6503548	ROOF AC	2 of 4	3'-11 7/8"	7R @ 6.84" =		3'-11 3/4"	7R @ 6.84" =	
Use Actual Value	6503548	ROOF AC	3 of 4	7'-11 3/4"				14R @ 6.84"	
Replace with Text	6503548	ROOF AC	4 of 4	6'-10 1/4"				12R @ 6.84"	
Text Fields	6504430	ROOF AC	3 of 4	10'-1"				11T @ 11" =	
Above	6504619	ROOF AC	2 of 3	11'-10 1/2"				13T @ 11" =	
	6505009	ROOF AC	2 of 4	5'-6''				6T@11"	
Left 🗹 Value 🗌 Right	6505612	ROOF AC	3 of 4	6'-5"				7T @11" =	
D-law	6656934	MEP EQUI	1 of 2	2'-9"	4T@11"=		2'-9"	4T @ 11" =	
Derow	6661680	MEP ACC	1 of 3	8'-3''				9T @ 11" =	
	6661900	MEP ACC	1 of 3	8'-3''				9T @ 11" =	
O lastuda 🖉 Eustuda	7227923	TUNNEL	1 of 2	3'-8"				4T @11"=	

Search results can be saved to a spreadsheet format for later review. To save the search results click the "Save" button.

DC				Dimer	nsion Checker				-		
DC - Q Show	Select 🗄 Options	🛃 Save Report	🕡 Help	Video	s 🕕 About						
Select the dimension	n overrides to search for:	Element ID	Host View	Segments	s Actual Value	Replace with Text Value	TextAbove	Text Below	Text Left	t Text Right	
Dimension value		6503548	ROOF AC	2 of 4	3'-11 7/8"	7R @ 6.84'' =		3'-11 3/4"	7R @ 6.8	34'' =	
Use Actual Val	ue	6503548	ROOF AC	3 of 4	7'-11 3/4"				14R@6	.84"	
Replace with T	ext	6503548	ROOF AC	4 of 4	6'-10 1/4"				12R@6	.84"	
Text Fields		6504430	ROOF AC	3 of 4	10'-1"				11T @ 1	1'' =	
	Above	6504619	ROOF AC	2 of 3	11'-10 1/2"				13T @ 1	1" =	
_		6505009	ROOF AC	2 of 4	5'-6"				6T@11		
Left 🗸 👌	Value 👖 Right	6505612	ROOF AC	3 of 4	6'-5"				7T @11"	=	
		6656934	MEP EQUI	1 of 2	2'-9"	4T @ 11" =		2'-9"	4T@11	"=	
Element ID	Host View		✓ Segr	nents 🔻 /	Actual Value 🔻	Replace with Text	Valu - Text	Above 🔻 Te	ext Below 🔻	Text Left 🛛 🔻	Text Right 🔻
6503548	ROOF ACCESS STAIR	SECTION	2 of -	4	3'-11 7/8"	7R @ 6.84" =		3'	-11 3/4"	7R @ 6.84" =	
6503548	ROOF ACCESS STAIR	SECTION	3 of -	4	7'-11 3/4"					14R @ 6.84" =	
G503548	ROOF ACCESS STAIR	SECTION	4 of	4 (6'-10 1/4"					12R @ 6.84" =	
E 6504430	ROOF ACCESS STAIR	THIRD FLOOR F	PLAN 3 of	4 1	10'-1"					11T @ 11" =	
6504619	ROOF ACCESS STAIR	THIRD FLOOR F	PLAN 2 of	3 1	11'-10 1/2"					13T @ 11" =	
6505009	ROOF ACCESS STAIR	ROOF PLAN	2 of -	4 5	5'-6"					6T @ 11"	
6505612	ROOF ACCESS STAIR	ROOF PLAN	3 of -	4 (6'-5"					7T @11" =	
6656934	MEP EQUIPMENT RO	DOM STAIR FLO	DR PLA1 of :	2 2	2'-9"	4T @ 11" =		2'	-9"	4T @ 11" =	
6661680	MEP ACCESS CORRI	DOR 42C STAIR	PLAN 1 of	3 8	8'-3"					9T @ 11" =	
6661900	MEP ACCESS COORI	DOR 42B STAIR	PLAN 1 of	3 8	8'-3"					9T @ 11" =	
7227923	TUNNEL ACCESS STA	AIR - FIRST FLOC	R PLA 1 of	2 3	3'-8"					4T @11"=	
	Search										
		<							D: :	>	
💿 Keady.									Dimensions	snown: 11	

Select the desired file path and choose from .XLSX, .XLS or .CSV file format.

Family Checker

Overview

Family Checker can be invaluable whenever there is a need to evaluate the consistency, completeness and overall "health" of incoming and outgoing Revit families. As is often the case, collaboration and acquisition of useful content is complex and time consuming. Ensuring that a piece of content functions correctly and contains accurate information usually requires detailed, manual examination of each one by a content manager, regardless of the original source.

Use Family Checker to quickly evaluate Revit content from manufacturers, project collaborators, Revit content sites such as Autodesk Seek and in-house libraries. To begin checking families, declare the common shared parameter file, acceptable parameter groupings, allowable names and build the list of family files to check. The Family Checker will open, gather information and produce a spreadsheet-based report without modifying the families themselves.

Based on the generated report, a content manager can identify and fix families which don't meet the established criteria and best practices.

Starting Family Checker

On the Revit ribbon, click on the "Family Checker" button.



When the Family Checker opens, the main form is presented:

Family Checker	-	
FC - 🔛 Manufacturer	Content 🗄 Options 🔞 Help 🚯 About	
Family Selection Report(s)		
O Current Family File	Parent folder: D:\Demo Sets\Family Checker\FS-5 Browse Search in subfolder Files found: Include backup files	Search Again
Multiple Family Files		
	Select All Add Selected Files	
	Selected files:	
	Remove Selected Items Remove All Items	
	a	heck Families
		.:

Family Checker Configuration

Prior to using the Family Checker, it is necessary to configure some of the application options. From the main toolbar, click the options button. The first tab displayed contains the 'General' options that will be used when the selected family files are processed:

E Options -	-		×
🍟 Load Options 🚽 Save Options			
General Valid Groups Name Rules Custom Sub-Categories Family Rulesets			
User Information			
User Initials:			
W		A	uto
Parameter Files			
Main Parameter File: P:\Projects\Revit Express Tools\BIM Manager Suite\Tools\Family Checker\Testing\HIVE Spec Testing Files\Revit_Master_Shar	ed_f	Bro	vse
Remember the size and position of the main window OK		Can	cel

User Initials: Specify what characters identify the user running the report. Click 'Auto' to get the logged in user

Main Parameter File: The path to the shared parameters file which contains the shared parameters that should be used with the families being checked

The 'Groups' tab contains two panes which display the way parameters should be grouped in the family:

eneral Valid Groups Name Rules Custom Sub-Catego	ories Family Rulesets	
Parameter Types:	Parameter Groups:	Defaults
P - Common B - Electrical D - Energy D + HVAC D - Piping D - Structural	Adaptive Component Advanced Alternate Units Analytical Alignment Analytical Alignment Analytical Model Analytical Properties Area Bottom Chords Building Data Calculation Rules Camera Conceptual Energy Data Construction Construction Curtain V Grid Data Data Data	

To add Parameter Types to Parameter Groups, simply expand the type and drag it to the desired group:



Hold the SHIFT or CTRL key while selecting to drag multiple types to a group:



To reset the changes made to groupings, click the 'Defaults...' button.

The 'Name Rules' tab enables Family Checker to evaluate parameters for disallowed or non-standard characters in their names:

r			
E Options			×
💕 Load Options 🛃 Save Options			
General Valid Groups Name Rules Custom Sub-Categories Family Rulesets			
Valid Name Parts: Invalid Name Parts:			
CTRL CTRL_ HD_ @			
Remember the size and position of the main window	ОК	Can	cel

This function can be helpful in identifying invalid characters or unwanted combinations of letters which may interfere with useful data extraction, proper scheduling, or BIM standards. The check is run by matching parts of the parameter names with the specified combinations. If a match is found, the name is declared valid or invalid, depending upon which list the character combination is defined in.

To define valid or invalid name parts, simply type each combination in the appropriate list. Press Enter or Return to add another item to the list.

Custom Sub-Categories

Select items from the 'Undefined Categories' list and use the right arrow to include in the checking process.

Undefined Categories: Categories/Sub-Categories: Image: Categories of the second se	General Valid Groups Name Rules	Custom Sub-Categories	Family Rulesets	
 Dimensions Doors Duct Fittings Duct Systems Ducts Electrical Equipment Electrical Fixtures Entourage Expansion Joints Fire Protection Flex Pipes Floors Food Service Equipment 	Undefined Categories:			Categories/Sub-Categories:
Purniture Furniture Systems Generic Models Grids Hardscape	Dimensions Doors Doors Duct Fittings Duct Systems Duct Systems Ducts Electrical Equipment Electrical Fittures Entourage Expansion Joints Fire Protection Flex Ducts Flex Pipes Floors Food Service Equipment Furniture Systems Generic Models Gids Hardscape			⊕ Analytical Beams Casework └── Hidden Lines>

Expand the category to include just some of the sub-categories in the checking process.



Remove items from the right pane by selecting and clicking the left arrow.

Family Rulesets

Choose options here to include when checking all of the families against the desired "custom" properties and parameters.

Saving and Loading Configurations

It may be necessary to use different rules for checking families. Family Checker can save and load its configuration options stored in .fcs files. To save or load settings, click the 'Load Options...' or 'Save Options...' buttons on the Options dialog:

📧 Options 彦 Load Options 🛃 Save	· Options		
Save Settings File $\leftarrow \rightarrow \checkmark \uparrow \square \ll$	81 (E:) > Temp > ඊ	Search Temp	× Q
This PC A360 Drive Desktop	Name CTC BIM Manager Suite 2016 CTC BIM Project Suite CTC BIM Project Suite 2014	Date modified 12/8/2015 12:10 PM 12/8/2015 12:10 PM 12/8/2015 12:10 PM	Type ^ File fol File fol
File name: Save as type: Far	mily Checker Settings Files (*.fcs)	Save Car	~ ~
Remember the size and p	osition of the main window	ОК	.:: Cancel

When loading options, any previously unsaved changes made will be lost. Be sure to save any configuration changes before loading settings from additional .fcs files.

Checking Families

Family Selection

Current Family: This checks the family that is currently open in Revit

Multiple Families: Use the multi-file selector interface to search through folders for families. Browse to the folder or folders where the families to be checked are located. If the families are located within subfolders of the parent folder, check the "Search in subfolder" box to see a list of all the files.

Select families from the top pane using the helper buttons or by holding CTRL/SHIFT while left-clicking.

📧 Family Checker	-	
FC - 🔛 Manufacturer Content	E Options 🔞 Help 🕦 About	
Family Selection Report(s)		
O Current Family File Parent folde S File(s) File D:\Demo S D:\Demo S D.\Demo S Select	r: D:\Demo Sets\Family Checker\FS-3 Browse Search in subfolder und Include backup files ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Annotation rfa ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Detail Item.rfa ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Model (Unhosted) rfa ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Profile rfa ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Profile rfa ets\Family Checker\FS-35 Parameter Grouping\FS-35-4 - Annotation rfa Deselect All	Search Again
3File(s) S		
<mark>D:\Demo S</mark> D:\Demo S D:\Demo S	ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Model (Unhosted).fa ets\Family Checker\FS-35 Parameter Grouping\FS-35-1 - Profile.fa ets\Family Checker\FS-35 Parameter Grouping\FS-35-4 - Annotation.fa	
	Remove Selected Items Remove All Items	
	c	heck Families
		.::

Continue browsing and adding families until desired list is complete. Click 'Check Families' to begin processing

Manufacturer Content: If families to be checked are obtained from or have been developed by a product manufacturer, activate the 'Manufacturer Content' button to enable additional checks for consistent "Manufacturer" parameter values.



Reports

The reports produced by Family Checker contain several tables which summarize the checks and results for each family. If multiple families were checked, each will have its own tab in the report.

Family Checker reports can be saved and reviewed in most common spreadsheet tools such as Microsoft Excel or other analysis tools such as PowerBI.

Click 'Save Report(s)' to choose a destination and file name for the report.

The report for the families follows a basic Comma Separated Values (.CSV) structure with the column names in the first

The values or ratings given for each check range from 0 or NULL meaning it does not generally apply to 5 which means it meets all optimal standards.

Family Processor

Overview

Family Processor is a tool which allows you to define one or multiple changes to one or more Revit[®] family files. This software can be used to make the following kinds of changes to Revit family files:

- Set the Classification Code (formerly known as the OmniClass value)
- Change the category
- Set "Family Parameters" settings: Shared, WorkPlane-Based, Always vertical, Cut with Voids When Loaded and Room Calculation Point
- Set the Keynotes file
- Clean up issues in the family by opening it with Auditing turned on
- Import all units of measure settings from another family file
- Change the text casing for all parameter values stored in text parameters (Text, Multiline-Text, URL, etc.)
- Sort the parameters by name within each group
- Delete one or more lookup tables
- Import one or more lookup tables from csv files
- Delete one or more materials, with a special option to delete the default materials
- Create materials and set their names, transparency values and basic red, green, and blue values
- Change the name, transparency value and basic red, green, and blue values for existing materials
- Delete parameters
- Add shared parameters and family parameters:
 - Define whether they are instance or type
 - Set their group
 - Set or clear their default value or formula
 - Define a family parameter's name
 - Define a family parameter's type (e.g. length, area, temperature, pressure, etc.)
- Replace an existing parameter with a specific shared parameter
- Replace all parameters in a family that have identically-named shared parameters in a shared parameters file
 - Change existing parameters:
 - o Value
 - o Formula
 - Whether it is instance or type
 - Name (for family parameters only)
 - Change their group

This software also provides the following functions:

- Controlling the order in which the above steps are processed
- Save modified families to an alternate parent folder location, retaining the subfolder tree structure of the newly processed families
- Re-save even if no changes were made, which can be useful for upgrading families to a new version of Revit
- Export all parameter information, for all types, to an XML file
- Override the preview image by building a new one from the view with a specified name

- Create a new shared parameters file which contains all the unique shared parameters discovered during processing of the families
- Create a type catalog file for each family processed, with the option of deleting the types in the family before resaving it
- All family files saved by Family Processor are always compacted to their smallest possible file size.

The ability to automate these tasks with accuracy and consistency can provide enormous time and cost savings, as well as reduce the likelihood of human errors inducing mistakes in the families.

Starting Family Processor

To launch Family Processor, you must have a family open in the Revit editor. This is necessary because a starting family is used as a baseline for default values that may apply to other families. This also makes it easy if you only want to automate changes to that single family. Once you have a family file open, click on the "Family Processor" button.



Once the button is clicked, Family Processor will open:

P Family Processor					– 🗆 X		
🕞 - 🁏 New Settings 🔗 Open St	ettings 🛄 Save Settings 🗦 Option		t 🕜 About				
• • • • • • • • • • • • • • • • • • •	ettings 🕞 save settings	s where videos 👻 suppor	About				
Family-Level Processing Lookup Ta	ables Change Materials Change Par	ameters Processing Order Select	Families & Begin Last Log				
Set Classification Code (formerly k	nown as the OmniClass Value)						
O not set the value (no characteristic)	nge)						
O Set the value to:	O Set the value to: (Example:. 23.75.70.17.37)						
○ Set the value to the value in this text parameter named:							
Delete this parameter	er after successfully setting the new va	lue		* Remember, paramete	er names are CASE-SENSITIVE		
				nemenoer, paramete			
- Family Settings (settings in the "Fa	imily Category and Parameters" dialog)					
Change Family Category:	No Change	✓ ○ 3D					
		 Annotation 	1				
Work Plane-Based	No Change 🗸 🗸	Shared	No Change $~~$				
Always vertical	No Change \sim	Room Calculation Point	No Change 🗸 🗸				
Cut with Voids When Loaded	No Change \checkmark	Cutting In Views	No Change \sim				
Set the keynotes file							
Local File Location:					Browse		
File Path: O Abso	olute O Relative	 At library locations 					
When opening family files, turn o	an Auditing	. , , , , , , , , , , , , , , , , , , ,					
Set all units of measure to match	the units of measure in this family file				Browse		
Final Processing							
Change the text casing of all values for all text parameters in all types to: No Change							
Sort parameters by name within	n groups						

Tool Buttons

Across the top of the Family Processor dialog are the following tool buttons:

The **New Settings** button clears out all of the current definitions of changes to one or more families that should be made. Essentially, it simply clears out the settings to apply to each family.

The **Open Settings** button lets you load previously-saved settings from a file you select.

The Save Settings button lets you save your current settings to a file you select.

The **Options** button brings up the following dialog that lets you control how Family Processor works. These options should be fairly self-explanatory:

F Options	×					
Remember last settings on startup						
Remember last window position on startup						
Show summary of steps to be taken before processing begins						
☑ Warn if a parameter's value does not appear to have a valid unit s	symbol					
When clearing settings, reset to:						
Process multiple family files (not the currently open family)						
Allow exporting parameter values for all types to XML						
Automatically delete the following default materials, if found:						
Analytical Floor Surface Analytical Slab Surface Default Ploor Default Floor Default Ight Source Default Mass Exterior Wall Default Mass Floor Default Mass Interior Wall						
Automatically save log files						
to folder: Brows	e					
Default view name for previews: Preview						
	v					
U	<u> </u>					

The **Help** button launches this user guide.

The Videos button opens a list of videos which can be viewed to learn more about using this tool.

The **About** button will bring up a dialog which provides information about this application.

IMPORTANT: Unless you make changes on the "Processing Order" tab, the order in which changes will be applied to the families matches the order that Family Processor presents the settings to you.

As we'll see shortly, the information in the bottom half of most tabs defines the actual actions to take on one or more families.

The top half of those tabs is used to select or specify what should go in the bottom half. For example, the "Only names containing" field above the list of choices allows you to quickly filter down the list by typing in a part of the name. Only those items that include what you type will remain on the list for selection.

Family-Level Processing Tab

The first tab is the *Family-Level Processing* tab. This tab contains settings that apply to the entire family and not, for example, just to a parameter or a material.

F Family Processor					-		\times
🕞 🗸 🎦 New Settings 📓 Open Sett	tings 📕 Save Settings 🗄	Options 🔞 Help 💽 Videos 👲 Support	: 🕕 About				
Family of evel Processing	les Characa Materials Cha	ner Denersten Denersien Orden Colort	Familia & Dania Last Las				
- Set Classification Code (formerly kno	own as the OmniClass Value)	nge Parameters Processing Order Select i	Families & Begin Last Log				
O Do not set the value (no chang	ge)						
Set the value to:	(Example	e:. 23.75.70.17.37)					
O Set the value to the value in th	is text parameter named:						*
Delete this parameter	after successfully setting the	e new value		* Remember : parameter par	es are CASE-	SENSITIVI	F
Eamily Settings (settings in the "Eam	illy Catagony and Parameters	" dialag)		Kentenber, parameter non		521151111	-
Change Family Colored	Na Changes						
Change Family Category:	No Change	Annotation					
Work Diana Rasad	No Change	Channel	No Change	J			
WOR Plane-based	No Change	 Snared 	No change				
Always vertical	No Change	 Room Calculation Point 	No Change	⊻ 			
Cut with Voids When Loaded	No Change	 Cutting In Views 	No Change	~			
Set the keynotes file							
Local File Location:						Browse.	
File Path: O Absolu	ute 🔿 Relat	ive O At library locations					
When opening family files, turn on	Auditing						
Set all units of measure to match th	he units of measure in this fa	mily file:				Browse	
Final Processing							
Change the text casing of all values	for all text parameters in all t	ypes to: No Change ~					
Sort parameters by name within g	groups						

This tab contains settings that allow you to apply a value to the Classification Code (formerly known as the OmniClass value) property of the family. You can select to make no change, to set a specific value, or to get the value to apply from an existing Text parameter in the family being processed.

For example, the families to be processed may have been created with an older version of Revit which did not have the Classification Code (OmniClass) property on families. If a Text parameter called *OmniClass Value* exists in each family and contains the value to be stored in the Classification Code property of families that now exists in Revit, you can specify that parameter name as the one from which to get the value:

Set the value to the value in this text parameter named: **OmniClass Value** Delete this parameter after successfully setting the new value

You can also have Family Processor delete the parameter once the value has been successfully applied.

Below this section are controls for changing the category of the family as well as the checkbox-based "Family Parameters" from the "Family Category and Parameters" dialog in Revit:

Family Settings (settings in the "Family Category and Parameters" dialog)							
Change Family Category:	No Change	√ 🖲 3D					
Annotation							
Work Plane-Based	No Change \checkmark	Shared	No Change \sim				
Always vertical	Set Checked \sim	Room Calculation Point	No Change \lor				
Cut with Voids When Loaded	Set Unchecked \checkmark						

The category of the family being processed can be changed by selecting something other than "No Change" from the list:

Family Settings (settings in	n the "Family	Category and Parameters" dialog)			
Change Family Category:		No Change	~	🔘 3D 🖌	
		No Change	^	 Annotation 	
Work Plane-Based		Air Terminals Balusters Cable Tray Fittings			No Change \sim
Always vertical		Casework Columns		ulation Point	No Change 🗸 🗸
Cut with Voids When I	Loaded	Communication Devices Conduit Fittings Curtain Panels			
Set the keynotes file		Data Devices Detail Items			
Local File Location:		Doors			
File Path:	Absolu	Duct Fittings Electrical Equipment		library locations	
When opening family	files, turn or	Electrical Fixtures			
Set all units of measu	ure to match	Entourage Fire Alarm Devices Furpiture			
Final Processing		Furniture Systems			
Change the text casing o	of all values	Generic Models Lighting Devices		je ∨	
Sort parameters by na	ame within <u>c</u>	Lighting Fixtures Mass			
		Mechanical Equipment			
		Parking			
		Pipe Accessories Pipe Fittings			
		Planting	~		

The "3D" and "Annotation" options are simply filters which change which category choices are in the list, to simplify the list of choices.

IMPORTANT: Be careful when changing the category of a family! When the category of a family is changed, subcategories will be lost and some category-specific parameters may be lost as well. <u>Use this feature at your own risk.</u>

The "checkbox" values below the category list can be set to 'No Change,' 'Set Checked,' or 'Set Unchecked.'

Below this section is the section for defining the Keynotes file this family will use. This feature is only available in Revit 2015 and later:

🗹 Set the keynotes file						
Local File Location:	C:\ProgramData\Autodes	\ProgramData\Autodesk\RVT 2017\Libraries\US Metric\RevitKeynotes_Metric.txt				
File Path:	Absolute	◯ Relative	○ At library locations			

This works like the equivalent dialog that is natively in Revit. To not set a Keynotes file, simply leave the "Set the keynotes file" checkbox unchecked.

Below this section is a control for opening family files with Auditing turned on. This can be used to help clean up family files which may have some corruption-type issues in them, to which Revit 2015 and later are particularly sensitive.

Below this option is a setting for importing the units of measure to apply to the families being processed. For example:

Set all units of measure to match the units of measure in this family file: C:\Revit Libraries\Metric Family Template.rfa

Browse ...

With this option enabled, all the settings for units of measure from the "Metric Family Template.rfa" family file will be applied to all the families being processed.

This option <u>will NOT convert values to nominal values in the new units of measure</u>. For example, if a value starts out as 33mm in a family but the units of measure for length in the family being used for units of measure are inches, the value in the family being updated will NOT change to a nice, round 1.25 inches but instead will be something like 1.29921 inches. So this process simply changes the working units of measure within the family in the same manner as if that's all that were to be changed in Revit manually.

Below this option is a setting to change the casing of all text-based parameter values. For example:

Change the text casing of all values for all text parameters in all types to: All Uppercase \sim

Text-based parameter values do not include a unit of measure, and include such parameter types as Text, Multi-line Text and URL. This setting allows changing the values to all uppercase, all lowercase, or to use title casing. Title casing uses capital letters as seen in the titles of most things, such as: My Awesome Parameter

A common use case for this option is to ensure all text values are all in uppercase letters, so schedules will appear in a uniform manner.

IMPORTANT: As of the 20.0.0 release, URL parameters WILL NOT have their casing changed, because many web sites have case-sensitive addresses.

Below this setting is a setting to sort parameters within groups, as seen in the Family Types dialog when editing a family. This setting is only available in Revit 2015 or later. This image shows the before and after results of turning on this setting:

•	Family	y Types	×		l.	Fami	ly Types	×
Name: Standard		¥		N	ame: Standard		¥	
Parameter	Value	Formula \land	Family Types	L I	Parameter	Value	Formula \land	Family Types
Mechanical - Flow			<u>N</u> ew		Mechanical - Flow			<u>N</u> ew
Pressure Drop (default)	18.00 Pa	-	Rename		Flow (default)	57.001/s	L_	Rename
Flow (default)	57.00 L/s		_		Max Flow	51100 275		
Max Flow		=	Delete		Min Flow		_	D <u>e</u> lete
Min Flow		=			Pressure Drop (default)	18.00 Pa	=	
Dimensions	<u>L</u>		Parameters		Dimensions			Parameters
Slot Width	25.0	=	A <u>d</u> d		Diffuser Length	1219.0	=	A <u>d</u> d
Radius	73.5	= (Duct Height / 2)	Modify		Diffuser Width	83.0	=	Modify
Duct Height	150.0 mm	=			Duct Height	150.0 mm	=	
Duct Width	200.0 mm	=	Remove	Ĩ	Duct Width	200.0 mm	=	Remo <u>v</u> e
Diffuser Width	83.0	=	Move Up	i i	Radius	73.5	= (Duct Height / 2)	Move Up
Diffuser Length	1219.0	=			Slot Width	25.0	=	
Other			Move Do <u>w</u> n		Other			Move Do <u>w</u> n
Width 5	73.5	= Diffuser Half Widt			Diffuser Half Length	609.5	= Diffuser Length *	
Width 4	10.4	= Diffuser Half Widt	Sorting Order		Diffuser Half Width	41.5	= Diffuser Width * 1	Sorting Order
Width 3	13.8	= Diffuser Half Widt	Ascending		Length 1	622.0	= Diffuser Length /	Ascending
Width 2	20.8	= Diffuser Half Widt			Slot Visibility 1		= Slot Number = 1	
Width 1	54.0	= Diffuser Width / 2	Descending		Slot Visibility 2	1	= Slot Number = 2	Des <u>c</u> ending
Length 1	622.0	= Diffuser Length / .	Look a Tables		Slot Visibility 3		= Slot Number = 3	Look a Tables
Diffuser Half Length	609.5	= Diffuser Length *	Lookup Tables		Slot Visibility 4		= Slot Number = 4	Lookup Tables
Diffuser Half Width	41.5	= Diffuser Width * 1	Manage		Width 1	54.0	= Diffuser Width / 2	Manage
Slot Visibility 4		= Slot Number = 4			Width 2	20.8	= Diffuser Half Widt	
Slot Visibility 3		= Slot Number = 3			Width 3	13.8	= Diffuser Half Widt	
Slot Visibility 2	v	= Slot Number = 2			Width 4	10.4	= Diffuser Half Widt	
Slot Visibility 1		= Slot Number = 1			Width 5	73.5	= Diffuser Half Widt	
Identity Data					Identity Data			
Assembly Code		=			Assembly Code		=	
Type Image		=			Cost		=	
Keynote		=			Description		=	
Model		=			Keynote		=	
Manufacturer		=			Manufacturer		=	
Type Comments		=			Model		=	
UKL		=			Type Comments		=	
<		>			<		>	
						01		1.1.1
	ОК Са	ancel <u>A</u> pply	Help			UK C	ancei <u>A</u> pply	Help
								.11

Lookup Tables Tab

The second tab in Family Processor is the Lookup Tables tab:

P Family Processor	– 🗆 X
🕞 🗣 🖞 New Settings 📄 Open Settings 📕 Save Settings 🗄 Options 🔞 Help 💟 Videos 🕦 Abo	ut
Family-Level Processing Lookup Tables Change Materials Change Parameters Processing Order Select Families Delete Lookup Tables Import Lookup Tables Import Lookup Tables Import Lookup Tables Import Lookup Tables	s & Begin Last Log
Lookup tables found in current family: Only names containing:	Type a lookup table name:
Lookup Table Name Fitting Sizes	Add Lookup Table
Select All Deselect All Add Selected Lables	
	Remove Selected Items Remove All Items

This tab allows deleting lookup tables from the family being processed, or importing lookup tables from CSV files into the family being processed.

This tab contains 2 subtabs:

Delete Lookup Tables Sub Tab

This tab allows you to define, by name, which lookup tables should be deleted from the families to be processed:

F2 Family Processor		_		×
F 🖓 New Settings 🚔 Open Settings 💂 Save Settings 🗄 Options 🔞 Help р Videos 🕦 About				
Family Level Processing Lookup Tables Change Materials Change Parameters Processing Order Select Families & Begin Last Log				
Delete Lookup Tables nport Lookup Tables				
Lookup tables found in current family: Only names containing: Type a lookup table name:				
Lookup Table Name				
Fitting Sizes Add Lookup Table				
Select àll Deselect àll				
Lookup tables found with the following names will be DELETED:				
Remove Selected	Items	Remove	All Items	

As with the other tabs, information from the currently open family is used to provide starter choices in the top half of this tab, and the bottom half of this tab is where the changes to actually apply to the families are listed. As items are added to the bottom half, they are removed from the list in the top half.

In this example, the lookup table shown in the top half ("Fitting Sizes") is in the currently open family. To add a single item from that list to the actual list of lookup tables to delete from families you can:

- Double-click on the lookup table from the list
- Click once to select the lookup table and then click the "Add Selected Tables" button

To select multiple lookup tables from the current family, you can use the Shift and Ctrl keys to select the lookup tables to delete from families, and then click the "Add Selected Tables" button.

We may also want to delete a lookup table in multiple families to process that doesn't happen to exist in the current family. We can do this by specifying the name in the "Type a lookup table name" field and clicking the "Add Lookup Table" button.

This was done in the above example, where a "Test Lookup Table" value was entered and the "Add Lookup Table" button was clicked.

Import Lookup Tables Sub Tab

This tab allows you to define, by <u>file name</u>, which lookup table files should be imported into the families to be processed:

P Family Processor	_		×
F 🖓 New Settings 🚔 Open Settings 🛃 Save Settings 🗄 Options 🔞 Help 🖸 Videos 🕦 About			
Family-Level Processing Lookup Tables Change Materials Change Parameters Processing Order Select Families & Begin Last Log Delete Lookup Tables Import Lookup Tables			
Browse for Files to Add			_
U: (Temp \ritting Sizes.csv			
Remove Selected Items	Remova	: All Items	

Click the "Browse for Files to Add..." button to select which CSV files to import as lookup tables into each family to be processed.

In the example above, the lookup table file **D:\Temp\Fitting Sizes.csv** was selected. During the processing of the family files, this lookup table file will be imported into each family.

Change Materials Tab

The next tab in Family Processor is the Change Materials tab:

Family Processor			.		- • ×
Family-Level Processing Lookup Tables Change Materials Delete Materials Add Materials Materials to Change	itings :=	options	Processin	p 🔽 Videos 🕕 Abou g Order 🛛 Select Families	at & Begin Last Log
Materials found in current family:			Only name	s containing:	Type a material name:
Material Name Default Default Light Source Default Roof Default Wall C' C Select All Deselect All	Red 127 255 0 127	Green 127 255 127 127 127	Blue 127 0 0 127 255 Add S	Transparency % Λ 0 - 75 - 0 - 0 - - - - - - - - - - - - - - -	Add Material Select from Family File(s)
Materials found with the following names will be DELE	TED:				
					Remove Selected Items Remove All Items

This tab contains 3 subtabs:

Delete Materials Sub Tab

This tab allows you to define, by name, which materials should be deleted from the families to be processed:

As with the other tabs, information from the currently open family is used to provide starter choices in the top half of this tab, and the bottom half of this tab is where the changes to actually apply to the families are listed. As items are added to the bottom half, they are removed from the top half.

Currently no changes to apply are listed in the example above.

In this example, the materials that appear in the top half are those in the currently open family. To add a single item from that list to the actual materials to delete from families you can:

- Double-click on the material from the list
- Click once to select the material and then click the "Add Selected Materials" button

To select multiple materials from the current family, you can use the Shift and Ctrl keys to select the materials to delete from families, and then click the "Add Selected Materials" button.

ang comp rabio	onongone		00.000.10	annoo a bogin - coor i	-vy	
Delete Materials dd Materials Materials to Change						
Materials found in current family:			Only name	es containing:		Type a material name:
Material Name Default Default Light Source Default Roof Default Wall Cincent Select All Deselect All Materials found with the following names will be DEL	Red 127 255 0 127 2	Green 127 255 127 127 0	Blue 127 0 127 255 Add 9	Transparency % 0 75 0 0 75 > Velected Materials	~	Add Material Select from Family File(s)
						Remove Selected Items Remove All Pares
1						HEIROVE DECOURT REINS FREITOVE ALL LEINS

As with the other tabs, information from the currently open family is used to provide starter choices in the top half of this tab, and the bottom half of this tab is where the changes to actually apply to the families are listed. As items are added to the bottom half, they are removed from the top half.

Currently no changes to apply are listed in the example above.

In this example, the materials that appear in the top half are those in the currently open family. To add a single item from that list to the actual materials to delete from families you can:

- Double-click on the material from the list
- Click once to select the material and then click the "Add Selected Materials" button

To select multiple materials from the current family, you can use the Shift and Ctrl keys to select the materials to delete from families, and then click the "Add Selected Materials" button.

In the above example you can see that there are more materials after *Default Wall*. We can filter out all the other materials by putting the word "default" in the *Only names containing* field, which will turn yellow when information has been typed into it:

kenais touriu in cuiterik rainily.		(Only name	es containin <mark>g</mark> default	Type a material name:
Naterial Name	Red	Green	Blue	Transparency %	
efault	127	127	127	0	Add Material
efault Light Source	255	255	0	75	
efault Roof	0	127	0	0	
	127	127	127	U	
					Select from Family File(s)
Select All Deselect All		-	Add S	elected Materials	
terials found with the following name	e will be DELETED:				
terials round with the ronowing name	s will be bele teb.				

In this example we'll select *Default Light Source* and *Default Wall* and click the "Add Selected Materials" button:

laterials found in current family:		(Only name	es containing: <mark>default</mark>	Type a material name:
Material Name	Red	Green	Blue	Transparency %	
Default	127	127	127	0	Add Material
Default Roof	0	127	0	0	
					Select from Family File(s)
Select All Deselect All			Add S	elected Materials)
<u>faterials found with t</u> he following names w	ill be DELETED:				
Default Light Source					
					Remove Selected Items Remove All Items

We may also want to delete a material in multiple families to process that doesn't happen to exist in the current family. We can do this by specifying the name in the "Type a material name" field and clicking the "Add Material" button:

atomato resulta un essiterik ranny:		1	Only name	es containing: <mark>default</mark>	Type a material name:
Material Name	Red	Green	Blue	Transparency %	My Material 2
Default	127	127	127	0	Add Material
Default Roof	0	127	0	0	
					Select from Family File(s)
Select All Deselect All			, Add S	elected Materials	
aterials round with the following name	s will be DELE I ED:				
erault Light Source Jefault Wall					
ly Material 1					

Further, we can use one or more family files other than the currently open one to get material definitions from as well. This can be useful in case you don't know all of the material names that exist in other family files to be processed:

aterials found in current family:			Only name	es containing:	Type a mate	erial name:			
Material Name	Red	Green	Blue	Transparency	A				
Default	127	127	127	0	- A	dd Material			
Default Roof	0	127	0	0	-				
Glass	0	0	255	75					
Laminate - Ivory, Matte	247	247	239	0	-				
A III	0	0	255	•	Select fr	om Familu Fil	ə[s]		
		(-				on ranny ra	5(0)		
Se P Sele	ect Mater	rials from	n One o	or More Famil	iles		_ 0	×	
ator									
Select Family File(s)									
efau									
ly M Material Name	Red	G	ireen	Blue	ansparency Perc	ent			
_									ems Remove All Items
									ems Remove All Items
									ems Remove All Items
									ems Remove All Items
									ems Remove All Items
									ems Remove All Items
									ems Remove All Items
									ems Remove All Items
									ems Remove All Items

When the "Select Files" dialog appears (shown below), the "Browse..." button can be used to find a folder in which family files exist.

Once family files are found, they are displayed in the top list. One or many can be selected in the top list, and the "Add Selected Files" button can be clicked to copy the selected items to the lower list.

Note that files can be added from very different folders, as selected items from multiple searches can all be consolidated into one list using this dialog (search, add some, search elsewhere, add some, etc.).

	Select F	iles		
Parent folder: C:\Program Files\Autode: 6 File(s) Found	sk\Revit 2015\Samples	Browse	Search in subfolder Include backup files	Search Again
C:\Program Files\Autodesk\Revit 2015\ C:\Program Files\Autodesk\Revit 2015\ C:\Program Files\Autodesk\Revit 2015\ C:\Program Files\Autodesk\Revit 2015\ C:\Program Files\Autodesk\Revit 2015\	Samples\rac_advanced_sampl Samples\rac_basic_sample_far Samples\rme_advanced_sampl Samples\rme_basic_sample_far Samples\rst_advanced_sample	e_family.rfa nily.rfa le_family.rfa mily.rfa e_family.rfa		^ ~
Select All Deselect All	🐥 🛛 Add Selecte	ed Files 🛛 🔶		
3 File(s) Selected C:\Program Files\Autodesk\Revit 2015 C:\Program Files\Autodesk\Revit 2015 C:\Program Files\Autodesk\Revit 2015	Samples\rac_basic_sample_far Samples\rme_advanced_sample Samples\rst_advanced_sample	mily.fa le_family.fa ⊵family.fa		
	Remove Selected Items	Remove All Items		
			Ok	Cancel

Once the "OK" button is clicked, the family files in the lower list will be scanned and the list of unique materials found in all the families will be shown on the previous screen:

P Select	Material	s from One	or More Fa	imily Files 📃 🗖 🗙
Select Family File(s)				
Material Name	Red	Green	Blue	Transparency Percent
Concrete - Precast Concrete - 35 MPa	198	187	187	0
Concrete - Precast Concrete - Normal Weight	198	187	187	0
Default	127	127	127	0
Default Light Source	255	255	0	75
Default Roof	0	127	0	0
Default Wall	127	127	127	0
Glass	0	0	255	75
Laminate - Ivory, Matte	247	247	239	0
Phase - Demo	255	0	0	40
Phase - Exist	127	127	127	0
Phase - Temporary	0	0	255	40
Poche	0	0	255	0
✓ Wood - Birch	224	178	126	0
Select All Deselect All				OK Cancel

One or many of these can be selected. Clicking the "OK" button will return the selected items to the list in the lower section of the main Family Processor screen:

Delete Materials Add Materials Materials to Change					
Materials found in current family:		(Only name	s containing: default	Type a material name:
Material Name	Red	Green	Blue	Transparency %	
Default Light Source Default Roof	255 0	255 127	0 0	75 0	Add Material
Select All Deselect All Materials found with the following names will be DELETI	ED:	ŧ	Add S	elected Materials	Select from Family File(s)
Default Default Wall Glass My Material 1 Wood - Birch					
					Remove Selected Items Remove All Items

Items can be removed from the list in the bottom half of the screen by either double-clicking on them or by using the "Remove Selected Items" and "Remove All Items" buttons at the bottom of the screen (highlighted).

To use the "Remove Selected Items" button, you must first select the name(s) of the materials to remove from the list by clicking on them. You can use the Ctrl and Shift buttons while clicking to help select multiple items.

Add Materials Sub Tab

This tab allows you to define new materials to be added to a family. The following values can be specified:

- Material Name
- Simple red value
- Simple green value
- Simple blue value
- Transparency percent value

If a material with the same name already exists on a family being processed it will <u>not</u> be modified with the values you specify for adding materials. If a material with the same name already exists, this addition definition will simply be ignored.

This tab works just like the *Delete Materials* tab, with the ability to set these additional values. For example:

	indicinais to change							
laterials found in current family:				Jnly name	is containing	9:		
Material Name		Red	Green	Blue	Transpa	rency %		
Default Light Source		255	255	0	75		Add Material	
Default Roof		0	127	0	0			
Default Wall		127	127	127	0			
Laminate - Ivory, Matte		247	247	239	0			
Wood - Birch		224	178	126	0		Select from Family File(s)	
at <mark>erial definitions to ADD:</mark> New Material Name	Red (0-255)	Gree	en (0-255)	Blue	(0-255)	Transparer	ncy Percent (0-100)	
Aterial definitions to ADD New Material Name Default	Red (0-255)	Gree 127	en (0-255)	Blue 127	(0-255)	Transparer 0	ncy Percent (0-100)	
Default Glass	Red (0-255) 127 0	Gree 127 0	en (0-255)	Blue 127 255	(0-255)	Transparer 0 75	ncy Percent (0-100)	
Default Glass Poche	Red (0-255) 127 0 0 0	Gree 127 0 0	en (0-255)	Blue 127 255 255	(0-255)	Transparer 0 75 0	ncy Percent (0-100)	
Aterial definitions to ADD: New Material Name Default Glass Poche	 Red (0-255) 127 0 0 	Gree 127 0 0	en (0-255)	Blue 127 255 255	(0-255)	Transparer 0 75 0	ncy Percent (0-100)	
aterial definitions to ADD: New Material Name ▶ Default Glass Poche	 Red (0-255) 127 0 0 	Gree 127 0 0	en (0-255)	Blue 127 255 255	(0-255)	Transparer 0 75 0	ncy Percent (0-100)	
Default Glass Poche	 Red (0-255) 127 0 0 	Gree 127 0 0	en (0-255)	Blue 127 255 255	(0-255)	Transparer 0 75 0	ncy Percent (0-100)	

To select items to be removed from the bottom list, you click on their row headers. You can use the Ctrl and Shift buttons while clicking to help select multiple items:

late	erial definitions to ADD:					
	New Material Name	Red (0-255)	Green (0-255)	Blue (0-255)	Transparency Percent (0-100)	
	Default	127	127	127	0	
	lass			255	75	
Þ	oche			255		
						Remove Selected Items

Materials to Change Sub Tab

This tab allows you to define new values for materials that already exist in families to be processed.

The following properties can be changed on materials to be edited:

- Material Name
- Simple red value
- Simple green value
- Simple blue value
- Transparency percent value

This tab works in the same way as the *Add Materials* tab. For example:

	s round in current ramily:			I	Only name	es containing:		Type a	material name:		
Materia	al Name		Red	Green	Blue	Transparer	icy % 🔺				
Defaul	t Light Source		255	255	0	75		+	Add Material		
Defaul	t Roof		0	127	0	0					
Defaul	t Wall		127	127	127	0					
Lamina	ate - Ivory, Matte		247	247	239	0	~				
<.			0	0	200	0	>	Sel	ect from Family File	[\$]	
lateria C	al definitions to CHANGE:	New Mate	erial Name		B	ed (0-255)	Green ((-255)	Blue (0-255)	Transparency Percent (0-100)	
De	efault				19	2	192		192	0	
G	ass	Bulletproof	Glass		0		0		240	50	
N 14	y Company Material 1				0		0		0	0	

Here you can see that we changed the Default material to be a lighter gray, and we changed the name of "Glass" to be "Bulletproof Glass" and made it a lighter shade of blue with less transparency than regular glass.

Change Parameters Tab

This tab contains tools for allowing you to change many aspects of the parameters to be found in the family files to be processed:

Add Shared Parameters Add Family Parameters Replace with Shared Parameters Parameters to Change Type a parameter names: (Parameter names detected: Show all shared parameters Only names containing: Type a parameter name: (Parameter names are CASE-SENSITIVE) Parameter Name Parameter Type Group Name Parameter Name Parameter Type Parameter Name Parameter Type Parameter Inames Group Name Parameter Inames Material Material Materials and Finishes Length Dimensions Con Material Materials and Finishes Select All Deselect All Desel	ly-Level Processing Lookup T ared Parameters file:	ables Change Materia s Change Parame	eters rocessing Order Select Far	milies & Begin Last Log Browse Reloa
Parameter Name Parameter Type Group Name Agase Material Materials and Finishes Height Length Dimensions Length Length Dimensions Ton Material Materials and Finishes Select All Deselect All Add Selected Names Select All Deselect All Add Selected Names Trameters found with the following names will be DELETED:	ete Parameters Add Shared Parameter names detected:	arameters Add Family Parameters Repla	ce with Shared Parameters Paramet	ters to Change Type a parameter name: (Parameter names are CASE-SENSITI
rrameters found with the following names will be DELETED:	Parameter Name Base Material Height Length Tron Material C Select All Deselect All	Parameter Type Material Length Length Material	Group Name Materials and Finishes Dimensions Dimensions Materials and Finishes Add Selected Names	Add Parameter Name Select from Family File(s)
	arameters found with the foll	lowing names will be DELETED:		

An important thing to note regarding changing parameters is **only ONE shared parameters file can be used when adding shared parameters or replacing parameters with shared parameters.** If you need to work with more than one shared parameters file, you'll have to process the families once for each shared parameters file.

The shared parameters file to use is specified at the top of this tab. The first time you visit this tab, the empty area in which to specify the shared parameters file to use will blink yellow 3 times.

Family-Level Processing Lookup Tables Change Materials Change Parameters Select Families & Begin Last Log								
Shared Parameters file: C:\Temp\SharedParams.txt Browse Reload								
Delete Parameters Add Shared Parameters Add Family Parameters Replace with Shared Parameters Parameters to Change								

You only need to specify a shared parameters file if you will be adding shared parameters or replacing a parameter with a shared parameter.

Delete Parameters Sub Tab

This tab allows you to define, by name, which parameters should be deleted from the families to be processed:

elete Parameters , dd Shared Pa	arameters Add Family Parameters Replac	ce with Shared Parameters Parameter	ers to Change	
arameter names detected:	Show all shared parameters	Only names containing:	Type a parameter name:	(Parameter names are CASE-SENSITIV
Parameter Name	Parameter Type	Group Name	A	
Base Material	Material	Materials And Finishes	Add Parameter Name	
Height	Length	Dimensions		
Top Material	Material	Materials And Finishes	-	
<	I south	Dimonologia		
Select All Deselect All		Add Selected Names	Select from Family File(s)	
arameters found with the fol	lowing names will be DELETED:			
Length My Parameter 1				

Remember that in Revit, parameter names <u>are</u> case-sensitive, so the correct use of upper- and lower-case letters matters.

This dialog works the same as the Delete Materials dialog, except for the additional "Show all shared parameters" checkbox. When unchecked it will show only those parameters that were found in the currently open family. When checked it will also include in the list all the parameters defined in the shared parameters file specified as well, if any.

Also as with the Delete Materials dialog, the "Select from Family File(s)..." button allows selecting parameter definitions from one or more family files other than the one currently open.

Select Family File(s)					
Parameter Name	Parameter Type	Group Name	Instance?	Shared?	1
Height	Length	Dimensions	No	No	
Keynote	Text	Identity Data	No	No	
Length	Length	Dimensions	No	No	
 Load Classification 	LoadClassification	Electrical	No	No	
Manufacturer	Text	Identity Data	No	No	
Model	Text	Identity Data	No	No	
Nominal Air Flow	HVACAirflow	Mechanical - Flow	Yes	No	
North Corbel Type	FamilyType	Construction	No	No	
North Corbels Number	Integer	Construction	No	No	- 1
North Corbels Number 1	Integer	Other	No	No	
Number of Poles	NumberOfPoles	Electrical	No	No	
Rebar Grids W	Force	Other	Yes	No	
Rebar Grids Weight	Number	Structural	Yes	No	
Refrigerant Flow	PipingFlow	Mechanical	Yes	No	

Add Shared Parameters Sub Tab

This tab allows you to add shared parameters to the families being processed:

Share	ed Parameters file: C:\Temp\SharedParams.txt						Browse	Reloa	d
Delet	e Parameter Add Shared Parameters Add Family Para	meters Re	place with Shared Paramete	Parameters to Chang	e				
Para	meters found in the current shared parameters file:		Only names contain	ning: <mark>load</mark>					
Pa	Parameter Name Parameter Type Shared Parameters File Group Name								~
Re Su Uit	Return Fan Full Load Current ElectricalCurrent Electrical - Loads Supply Fan Full Load Current ElectricalCurrent Electrical - Loads Ultraviolet Lights 2 Apparent Load ElectricalApparentPower Electrical - Loads Ultraviolet Lights Apparent Load ElectricalApparentPower Electrical - Loads								-
Sel	elect All Deselect All ected parameters to add as SHARED parameters:		Add Selected Pa	arameters should include unit sym	bols. Values and form	nulas will be app	lied to ALL TYPES	S in familie	s
	Parameter Name	Instance?	Parameter Type	Value	Formula	Add to Group		_	
	Rated Load Current		ElectricalCurrent	20 A		Electrical - Loa	ds	-	
•	Return Fan Apparent Load		ElectricalApparentPower	10 kW		Electrical - Loa	ds	•	-
	Supply Fan Apparent Load		Electrical Apparent Power		20 kW	Electrical - Loa	ds	-	
Al	I Instance All Type Invert all groups are available in all flavors of Revit. Adding to	Validate an invalid	Unit Symbols group will result in the para	Set Group for Select	ted Items Remove e "Other" group.	Selected Items	Remove Al	l Items	j

The definitions for the shared parameters can <u>only</u> come from the shared parameters file specified, so those are the only ones presented as choices. Family Processor uses the names of the parameters listed in this dialog and the name of the shared parameters file to tell Revit how to correctly add the shared parameters to the families being processed.

As with other parameter-oriented tabs, this tab has special features that are worth noting:

- The Parameter Types are shown to help you understand what kind of data is expected for each parameter
- The "Instance?" column in the bottom section allows you to control whether each parameter is an instance parameter or a type parameter
- The "Formula" column allows you to specify a formula for the parameter. This formula should be entered the same way you enter it into Revit.
- Just as in Revit, formulas may only reference other parameters that already exist in the family. So, for example, a formula used on the "Add Shared Parameters" tab can NOT reference a parameter on the "Add Family Parameters" tab, because the "Add Family Parameters" tab is processed later. For this case, specify the formula for the new shared parameter on the "Parameters to Change" tab, which is processed last.
- The "Add to Group" column allows you to specify which parameter group the new shared parameter should be placed in.
- Adding a parameter to an invalid group for the version of Revit being used will result in the parameter being added to the "Other" group.
- The "Value" column allows you to specify a default value for each parameter. If you leave that value blank, Revit will provide a default for you.
- If you specify a value for a parameter that has a units of measure associated with it, it is <u>strongly recommended</u> that you also provide the unit symbols for that value, as can be seen in the example above. You can type the value in just as you do in Revit

• The "Validate Unit Symbols" button can help provide you with a list of valid symbols typically associated with a particular parameter type. If, for example, we just type a value of "5" for Supply Fan Apparent load and then click the "Validate Unit Symbols" button, we'd see this:

Invalid or Missing Unit Symbol		
The value: 5 does not appear to contain a valiv ElectricalApparentPower	d unit symbol for a paramet	ter of type
This may cause unexpected/inco	rrect values to be in the fa	milies that are processed.
Select a valid unit symbol to use:	W kW Btu/s Btu/h cal/s kcal/s VA kVA hp	▼ IK Cancel

Selecting one of the choices and clicking the "OK" button will apply that unit symbol to the value in the grid.

- Family Processor <u>will</u> let you continue without specifying unit symbols, but the results in the final family files may be unpredictable.
- An option exists to allow Family Processor to automatically warn you if you enter a value that should have unit symbols, but doesn't.
- Yes/No parameter values or formulas can be set to any of the following to mean Yes (case insensitive):
 - 1 yes checked true
- Yes/No parameter values or formulas can be set to any of the following to mean No (case insensitive):
 0 no unchecked false
- A material definition can be assigned to a Material parameter by setting the parameter's value to the name of the material. Example value: Glass
- A Family Type parameter *value* (not formula) can be set using the name of the nested family and type to set it to. Use the exact text that you see for choices in the combo box list when changing the value manually.

IMPORTANT: Because one new parameter to add may require a formula that references another new parameter to add, the order of the parameters being added can be very important. Just like when using the Revit user interface, **the parameter being used in the formula must be added first.**

You can control the order of the parameters to add by using the up and down arrow buttons to the right of the list of parameters to add:

las will be applied to ALL TYPES in familie	
Add to Group	
Electrical - Loads 🔹	
Electrical - Loads 🔹	-
Electrical - Loads 🔹	
elected Items Remove All Items	

These buttons are enabled when you select one or more rows to move up and down the list by clicking on their row header buttons.

In the example above, we may want to have the *Supply Fan Apparent Load* parameter added before the others. To make that happen, we click on the row header for it, and then the up-arrow button twice:

Se	ielected parameters to add as SHARED parameters: Values should include unit symbols. Values and formulas will be applied to ALL TYPES in families							-
	Parameter Name	Instance?	Parameter Type	Value	Formula	Add to Group		
	Rated Load Current		ElectricalCurrent	20 A		Electrical - Loads	-	
	Return Fan Apparent Load		Electrical Apparent Power	10 kW		Electrical - Loads	•	-
Г	Supply Fan Apparent Load		Electrical Apparent Power	5		Electrical - Loads	•	
A	All Instance All Type Invert Validate Unit Symbols Set Group for Selected Items Remove Selected Items Remove All Items							
No	t all groups are available in all flavors of Revit. Adding to	an invalid g	roup will result in the para	ameter being added to the	"Other" group.			

When at least one parameter is selected, the "Set Group for Selected Items" and "Remove Selected Items" buttons will be enabled. Clicking on the "Set Group for Selected Items" button will prompt you to select a group to apply to all selected parameters. For example:

🖻 Select the Group			×
Select the new group:	Dimensions		~
		Cancel	Ok

This allows you to change the group for many parameters in one step, without having to select it manually for each parameter, one at a time.

Clicking on the "Remove Selected Items" button will remove those selected parameters from the list.

Add Family Parameters Sub Tab

This tab allows you to add family parameters to the families being processed.

Sha	red Parameters file: C:\Temp\Shar	redParams.txt	_					Browse	Reload	
Dele	ete Parameters Add Shared Parameter	Add Family Para	meters le	place with Shared Paramete	rs Parameters to	o Change				
Fan	nily parameters found in current family	y:		Only names contain	ing:	Type a parameter	r name: (Parar	meter names are (ASE-SENSI	TIVE)
P	arameter Name	Parameter Type		Group Name	^	My Parameter 3				
B	ase Material	Material		Materials And Finishes	E	Parameter Type:	PipeSize			•
L La	ength op Material	Length Material		Dimensions Materials And Finishes		👃 🛛 Add Para	ameter			
W	Adth	Length		Dimensions						_
	Select All		Select from Far			mily File(s)				
	Deselect All			Mud Selected P	arameters					
Sel	lected parameters to add as FAMI	LY parameters:		Values	should include	unit symbols. Valu	es and formulas will be appl	lied to ALL TYPES	in families	
	Parameter Name		Instance?	Parameter Type	Value	Formula	Add to Grou	p		
•	Height			Length	457.00 mm				-	_
	My Parameter 1			Length			Other		-	-
	My Parameter 2			PipeSize			Other		-	_
A	Il Instance All Type Inv	ert	Validate U	Jnit Symbols	Set Group fo	r Selected Items	Remove Selected Items	Remove All	Items	
Not	all groups are available in all flavors	of Revit. Adding to	an invalid g	roup will result in the parar	meter being adde	ed to the "Other" gro	oup.			

It works exactly the same way as the "Add Shared Parameters" tab, except the list of source parameters are the parameters in the currently open family, plus you have the ability to add your own custom parameter definitions, or get definitions from one or more other family files.

Replace with Shared Parameters Sub Tab

This tab allows you to replace an existing family or shared parameter in the families being processed with a specific shared parameter from the selected shared parameters file.

Shared Parameters file:	C:\Temp\SharedParams.txt				Browse	Reload
Delete Parameters Add Share	ed Parameters Add Family Paramete	Replace with Shared Parameters Farameters	to Change			
Parameters in current family:	Show all shared paran	eters Unly names containing:	Type a parameter nar	me: (Para	meter names are CAS	E-SENSITIVE)
Parameter Name Base Material Height Length Top Material Width	Parameter Type Material Length Length Material Length	Group Name Materials and Finishes Dimensions Dimensions Materials and Finishes Dimensions	Parameter Type: Add Parame	<select a="" parameter="" typ<br="">ater y File(s)</select>	08>	~
Select All Deselect A		Add Selected Names				
Existing parameters found	I with Current Name to REPLACE:					
Current Name	▲ Paramet	er Type Replace with S	P Name			
Automatically replace all p	parameters found in the family with m	atching name and type found in the shared par	ameters file.	Remove Selected	Items Remov	e All Items
On this tab you define the parameter name and type to replace with a specific shared parameter. As with other tabs, the list in the top section is built from the parameters in the currently open family, plus you have the option to show or hide all the shared parameters from the currently selected shared parameters file as well.

Also as with other tabs, you have the ability to manually define your own parameter name and type to replace with a shared parameter, or get parameter definitions from another family file.

Once a parameter to replace is in the lower section, you assign a parameter from the currently selected shared parameters file to replace it with.

As can be seen in the next image, when you choose which shared parameter to use to replace the existing parameter, you only get to choose from those shared parameters defined <u>as the same parameter type</u> as the one to replace:

Delete Parameters	Add Shared Parameters	Add Family	Parameters	Replace with Shared Parame	ers Parameters t	to Change					
arameters in curr	ent family:] Show all sh	ared parame	eters Only names conta	ning:	Type a parameter n	ame:		(Parameter na	mes are	CASE-SENSITIVE
Parameter Name	F	Parameter Typ	e	Group Name	<u>^</u>			_			
Actual Air Flow	,	HVACAirflow		Mechanical - Air Flo	v	Parameter Type:	<select< td=""><td>a Parame</td><td>ter Type></td><td></td><td></td></select<>	a Parame	ter Type>		
Actual Air Flow Im	balance H	HVACAirflow		Mechanical - Air Flo	v	Add Param	eter				
Actual Chilled Wa	ter Coil Condensate	PipingFlow		Plumbing	-			_			
•		m			•	Select from Fam	lu File(s)				
Select All	Deselect All			Add Sel	cted Names	CONC. NON I AN	y ,				
xisting parame	ters found with Curren	t Name to RE	PLACE:					_			
Current Nam	e	*	Parameter	Туре	Replace with SP	Name		-			
Actual Supply	y Air How		HVACAitio	N	Actual Air Flow		To be				
Length			Length		Actual Air Flow Imit	balance	- 6				
					Actual Exhaust Air Actual Fan Power	r Flow ed Box Induced Air Flo	~				
					Actual Exhaust Air Actual Fan Power Actual Fan Power Actual Retum Air I Actual Supply Air (Actual Supply Air (Actual Supply Air (r Flow ed Box Induced Air Flo ed Box Primary Air Flow Flow Connection 1 Flow Connection 2 Flow Connection 3 Flow Flow	N	sove Se	lected Items	Rer	nove All Items
					Actual Exhaust Air Actual Fan Power Actual Fan Power Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air f Actual Ventilation	Flow ed Box Induced Air Floe ed Box Primary Air Flow Row Connection 1 Flow Connection 2 Flow Connection 3 Flow Row Air Flow	N	iove Se	lected Items	Ren	nove All Items
					Actual Exhaust Air Actual Fan Powen Actual Ran Powen Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air fa Actual Ventilation - Air Teminal Air Flo Damper Air Row	Flow ed Box Induced Air Flo ed Box Primary Air Flow Flow Connection 1 Flow Connection 2 Flow Connection 3 Flow Flow Air Flow W	N	iove Se	lected Items	Rer	nove All Items
_					Actual Exhaust Air Actual Fan Powen Actual Ran Powen Actual Return Air I Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air I Actual Ventilation : Air Temminal Air Flo Damper Air Flow M Design Air Flow M	Flow ed Box Induced Air Floo ed Box Primary Air Flow Row Connection 1 Flow Connection 2 Flow Connection 3 Flow Row Air Flow W aximum Inimum	F	iove Se	lected Items]	Rer	nove All Items
_		_	_		Actual Exhaust Air Actual Fan Power Actual Retum Air f Actual Retum Air f Actual Supply Air (Actual Supply Air (Actual Supply Air Actual Supply Air Actual Ventilation Air Terminal Air Flo Damper Air Flow M Design Air Flow M Design Cooling Air	Flow ed Box Induced Air Floe ed Box Primary Air Row Row Connection 1 Row Connection 2 Row Connection 3 Row Row Air Flow W aximum inimum r Bow Maximum	E	ove Se	lected Items	Rer	nove All Items
		_	_		Actual Exhaust Ari Actual Fan Powen Actual Fan Powen Actual Retum Ari Actual Supply Ari Actual Supply Ari Actual Supply Ari Actual Supply Ari Actual Ventilation Damper Ari Damper Ari Row Design Ari Row M Design Cooling Ari Design Cooling Ari Design Cooling Ari Design Cooling Ari Design Cooling Ari Design Cooling Ari Design Cooling Ari	Flow ed Box Induced Air Floo ed Box Primary Air Flow Row Connection 1 Row Connection 2 Row Connection 3 Row Row Air Flow W aximum inimum Flow Maximum r Row Maximum r Row	E	iove Se	lected Items	Rer	nove All Items
		_			Actual Exhaust Ari Actual Fan Powen Actual Fan Powen Actual Retum Ari Actual Supply Ari Actual Supply Ari Actual Supply Ari Actual Supply Ari Actual Ventilation Ventilation Ventilation Damper Air Row M Design Ari Row M Design Cooling Air Design Cooling Air Design Cooling Air Design Cooling Air Design Cooling Air Design Fan Power Design Fan Power	Flow ed Box Induced Air Floe ed Box Primary Air Flow Row Connection 1 Flow Connection 2 Flow Row Air Flow W aximum inimum Flow Maximum r Flow Maximum r Flow Maximum r Flow Maximum r Flow Maximum r Flow Maximum r Flow Maximum	v v	iove Se	lected Items	Rer	nove All Items
		_			Actual Exhaust Ar Actual Fan Powen Actual Fan Powen Actual Retum Air I Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Ventilation Ventilation Ventilation Damper Air Row M Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Exhaust Ai Design Exhaust Ai Design Heating Ai Design Heating Air	Flow ed Box Induced Air Floe ed Box Primary Air Flow Row Connection 1 Flow Connection 2 Flow Connection 3 Flow Row Air Flow W aximum inimum Flow Maximum ir Flow Maximum ir Flow Maximum ir Flow Air Plow Air Flow Maximum r Flow Maximum r Flow Maximum r Flow Maximum r Flow Maximum	v v	ove Se	lected Items	Rer	nove All Items
_		_			Actual Exhaust Arr Actual Fan Powen Actual Fan Powen Actual Fan Powen Actual Supply Air (Actual Ventilation Design Air How M Design Air How M Design Coling Air Design Coling Air Design Coling Air Design Exhaust A Design Heating Ai Design Heating Air Design Heating Air Design Primary Air	Flow ed Box Induced Air Floe ed Box Primary Air Row Row Connection 1 Row Connection 2 Row Air Row Maximum inimum Row Maximum r Row Maximum r Row Maximum r Row Roimary Air Roor r Row Maximum r Row Minimum r Row Maximum Row Minimum	N E	iove Se	lected Items	Rer	nove All Items
					Actual Exhaust Arr Actual Fan Powen Actual Fan Powen Actual Retum Air I Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Ventilation Design Air How M Design Air Row M Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Heating Ai Design Heating Ai Design Heating Air Design Heating Air Design Primary Air Design Retum Air Design Retum Air	Flow ed Box Induced Air Floe ed Box Primary Air Row Row Connection 1 Row Connection 2 Row Air Row Maximum inimum Air Row Maximum in Row Maximum ir Row Maximum r Row Animum Flow Maximum Flow Maximum Row Minimum Row Maximum Row Maximum	N E	sove Se	lected Items	Ren	nove All Items
					Actual Exhaust Arr Actual Fan Powen Actual Fan Powen Actual Retum Air I Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Supply Air (Actual Ventilation Design Air How M Design Air Row M Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Heating Ai Design Primary Air Design Primary Air Design Primary Air Design Primary Air Design Retum Air Design Retum Air Design Retum Air Design Retum Air Design Retum Air	Flow ed Box Induced Air Floe ed Box Primary Air Row Row Connection 1 Row Connection 2 Row Air Row New Air Row W Air Row W Air Row Maximum Flow Maximum Flow Maximum Flow Minimum Flow Minimum Row Maximum Row Maximum Row Maximum Row Maximum Row Maximum Row Maximum Row Maximum Row Maximum Row Maximum Row Maximum	v v	ove Se	lected Items	Ren	nove All Items
1:5 🖾 🗲		2) Q (2) .			Actual Exhaust Arr Actual Fan Powen Actual Fan Powen Actual Ran Powen Actual Supply Air (Actual Ventilation Design Air How M Design Air How M Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Coling Air Design Heating Ai Design Heating Ai Design Heating Air Design Return Air Design Supply Air	Flow ed Box Induced Air Floe ed Box Primary Air Row Row Connection 1 Row Connection 2 Row Row Row Air Flow Waximum inimum Air Flow Maximum Flow Maximum Flow Minimum Flow Minimum Row Minimum Row Minimum Row Maximum Row Maximum Row Row Maximum Row Row Maximum Row	v v	ove Se	lected litems	Ren	nove All Items

This ensures that you can only choose a replacement parameter that Revit will allow to work.

If a shared parameter exists with the exact same name and parameter type as the parameter to be replaced, it will automatically be selected by default from the list as soon as the parameter to be replaced is added to the list.

An option exists at the bottom of the list which can be used to automatically find all parameters in the family being processed whose name and parameter type matches the name and parameter type of parameters that exist in the shared parameters file and automatically replace them with those shared parameters:

Automatically replace all parameters found in the family with matching name and type found in the shared parameters file.	Remove Selected Items	Remove All Items

For example, if the family contains a Length parameter called Overall Length and the shared parameters file also contains a Length parameter called Overall Length, the one in the family will be automatically replaced by the one in the shared parameters file because they are both of the same parameter type and have exactly the same (case sensitive) name.

If the parameter in the family is either a family parameter or a *different* shared parameter than the one in the shared parameters file, it will be swapped out with the one from the shared parameters file. This would automatically occur for all parameters in the family with matching definitions in the shared parameters file.

Parameters to Change Sub Tab

Shared Parameters file: D:\Temp\Daikin Applied Revit Shared Parameters en-US.txt Browse. Reload Delete Parameters Add Shared Parameters Add Family Parameters Replace with Shared Parameter Parameters to Change rameter name: (Parameter names are CASE-SENSITIVE) Parameter in current family Show all shared parameters Only names contair Parameter Name Parameter Type Group Name Parameter Type: PipingFlow Assembly Code Text Identity Data Base Material Material Materials And Finishes Add Parameter Currency Cost Identity Data Identity Data Description Text Select from Family File(s). Deselect All # Add Selected Names Select All Existing parameters found with Current Name to CHANGE Values should include unit symbols. Values and formulas will be applied to ALL TYPES in familie Parameter Type Move to Group Current Name New Name Instance? New Value New Formula Set Type • Length 762.00 mm -Length <No Change> 762.00 Width Length <No Change> Ŧ Set Type My Parameter Pipe Flow No Change PipingFlow Plumbing Ŧ All Type Validate Unit Symbols Set Instance/Type Set Group for Selected Items Remove Selected Items All Instance Invert Remove All Items Name changes will only work on Family Parameters (not Shared or Built-In parameters) Use a space to clear a formula or TEXT value

This tab allows you to make changes to the properties of existing family and shared parameters.

As can be seen in the above image, you can change the name (for family parameters), whether or not the parameter is instance or type (or leave that setting alone), the value, the formula and the group in which the parameter should be listed.

If no characters have been typed in for a value or formula (the cell in the grid is empty), the current value or formula will NOT be changed.

To clear out a parameter's formula or a TEXT parameter's value, set the formula or value to one or more space characters.

Just as in Revit, you may only change the value or formula for a built-in parameter. So you can't, for example, change the Model parameter to be an instance parameter.

When adding a FamilyType parameter (has a combo box allowing you to "swap out" one nested family for another) to the list of parameters to change while a family is open with that parameter in it, by default a number will appear in the

Value field representing the ID of the currently selected choice in this family. **You MUST change that value to be blank** (not even spaces, to leave its value alone) or to the <u>name</u> of the type to apply, exactly as it appears in the list of choices in the combo box list when changing the value manually in the family editor for the family being processed. This is because ID values are likely to vary between families. Also, as normally seen in Revit, you cannot set the formula for a FamilyType parameter.

When at least one parameter (row) is selected in the lower section, the "Set Instance/Type for Selected Items," "Set Group for Selected Items" and "Remove Selected Items" buttons will also be enabled. Clicking on the "Set Group for Selected Items" button will prompt you to select a group to apply to all selected parameters. For example:

🖻 Select the Group			×
Select the new group:	Dimensions		~
		Cancel	Ok

This allows you to change the group for many parameters in one step, without having to select it manually for each parameter, one at a time.

In similar fashion, the "Set Instance/Type for Selected Items" button allows you to set whether the selected parameters should be changed to be Instance or Type parameter, or set to "No Change" to ensure those parameters keep their current instance or type status:

🖻 Select Setting as Instand	ce or Type	×
Select the new setting:	No Change No Change Set Instance Set Type	

Clicking on the "Remove Selected Items" button will remove those selected parameters from the list.

Handling Special Parameter Workflows

When adding parameters, the entire add will fail if a parameter with the same case-sensitive name already exists in the family. If a parameter already exists with the same name, it will remain untouched by the add process.

However, it may be desirable to "add the parameter with my value if the parameter doesn't exist in the family, or set my value on the parameter if it already exists in the family." Family Processor does NOT assume everyone wants to do this at all times: <u>add means only to add, not to change existing</u>. This ensures there is no confusion.

IMPORTANT: But this workflow can still be achieved by defining the parameter in the "Add" list, and defining it **AGAIN** in the "Parameters to Change" list.

The Add process will create it and set the value if it doesn't exist. Whether or not it was just added, the Change process will set the value because the parameter will now exist.

Another workflow might be "I'm adding dozens of parameters by selecting them from a complex mechanical family, and the formulas for many parameters reference other parameters, but determining the order they need to be added in so all the formulas work during the add would be difficult, time-consuming or error-prone."

IMPORTANT: This workflow can also be achieved by selecting the parameters from another family in the "Add" list, in any order, and selecting them from the other family **AGAIN** in the "Change" list, again in any order.

In this case the parameters will be added to the family even if setting the formula during the Add fails because another parameter needed in the formula hasn't been added yet.

However, when the Change command is run again later, all the parameters WILL be on the family at that time, so setting the formulas again will always work.

Processing Order Tab

This tab allows you to control the order in which the changes to be made to the family are applied:

🖻 Family Processor	_	×
🕞 🗣 🕆 🖹 New Settings 💣 Open Settings 📓 Save Settings 🗄 Options 🔞 Help 💽 Videos 🕦 About		
Family-Level Processing Lookup Tables Change Materials Change Parameter Processing Order elect Families & Begin Last Log		
Change the order of processing by reordering the items below. Uncheck items to prevent them from being processed.		
 Family-Level Processing Delete Lookup Tables Import Lookup Tables Delete Materials Add Materials Add Materials Delete Parameters Add Shared Parameters Add Shared Parameters Replace with Shared Parameters Replace with Shared Parameters Replace with Shared Parameters Parameters to Change 		

By default, the order in which the changes are applied matches the order in which the settings are presented in the tool.

However, there are some workflows which cannot be done with the default order, or that could be done but which would require multiple runs of Family Processor with different settings on the same families.

One example is the desire to replace an existing parameter with a shared parameter if the original parameter is found, but if the original parameter is NOT found, to then add the shared parameter. This ensures the shared parameter exists on the family, but has replaced an existing parameter if it had been there originally.

For example, "I want to replace parameter Volts with shared parameter Voltage, but if parameter Volts doesn't exist, then add shared parameter Voltage"

Using the default processing order, shared parameter Voltage would get added even if parameter Volts exists, then the replace later would fail because shared parameter Voltage would already exist in the family, and you'd wind up with both parameters on the family.

So in this case you'd want the Replace with Shared Parameters to happen before the Add Shared Parameters.

To change the order of processing, select one or more items in the list and use the green "Move Up" and "Move Down" buttons. To make the example above work, these settings would be made:

Change the order of processing by reordering the items below. Uncheck items to prevent them from being processed.

You can also disable the settings during processing by unchecking an item. For example, if we want to keep the settings of the family parameters to add, but not apply them for the time being, simply uncheck that item:



IMPORTANT: The processing order is saved with the rest of the settings. If you disable an item by unchecking it and save the settings, the next time those settings are loaded that item <u>will still be disabled</u>.

This button:

9

can always be used to reset the processing to the default order Family Processor uses.

Select Families & Begin Tab

This tab allows you to control which family or families are processed, and configure any special processing that should be done:

P Family Processor	_	×
F 🖓 New Settings 🚔 Open Settings 🛃 Save Settings 🗄 Options 🔞 Help 🖸 Videos 🕕 About		
Family-Level Processing Lookup Tables Change Materials Change Parameter Select Families & Begin ast Log O Current family file (will not be saved) Multiple family files Multiple family files		
Log only errors Begin Processing		

If selecting the current family file, as seen above, the currently open family will have the changes applied to it, but the family will not be saved automatically. You must do that yourself once you have approved of the changes made.

At the bottom of the screen is an option to log only errors. The Last Log tab (discussed next) shows the log of all the processing that was done during the last run of Family Processor. If this option is checked, it reduces the log to only errors that may have occurred, such as trying to add a family parameter when there was already a parameter on the family with that exact name.

If the option is turned on in the Options dialog, another checkbox may appear at the bottom of this screen that allows exporting the parameter information for all types to an XML file.

When multiple families are to be processed, the screen looks like this:

 Current family file (will 	not be saved)
Multiple family files	Parent folder: C:\Program Files\Autodesk\Revit 2017 Family files found:
	C:\Program Files\Autodesk\Revit 2017\Samples\rac_advanced_sample_family.fa C:\Program Files\Autodesk\Revit 2017\Samples\rac_basic_sample_family.fa C:\Program Files\Autodesk\Revit 2017\Samples\rme_davanced_sample_family.fa C:\Program Files\Autodesk\Revit 2017\Samples\rme_basic_sample_family.fa
	Select All Deselect All Add Selected Files
	Selected files to process:
	C: <u>Program Files:V4utodesk:\Revit 2017:Samples:vac_advanced_sample_family.ffa</u> C: <u>Program Files:V4utodesk:VRevit 2017:Samples:vac_basic_sample_family.ffa</u> C: <u>Program Files:V4utodesk:VRevit 2017:Samples:vme_advanced_sample_family.ffa</u> C: <u>Program Files:V4utodesk:VRevit 2017:Samples:vme_basic_sample_family.ffa</u> D::Temp:VFP:Door-Swing-ICS-Single.ffa
- T	
	Remove Selected Items Remove All Items
	Preview only. Does NOT save any families to disc (useful for testing your settings)
	Add prefix: Add suffix: Re-save even if no changes needed (useful for upgrades or compacting families)
	Save to alternate parent folder: D:\Temp\Processed Browse
	Override the preview image using the view with this name (select or type the case-sensitive view name): Preview
	Create new shared parameters file from all unique shared parameters found in families:
	Create type catalog files
	🗌 Delete the types in the families 🔽 Include instance params 🔄 Sort params alphabetically 🖉 Sort types alphabetically 🔄 Save as *.csv files
	Exclude params with names including (separate with characters, * wildcards are supported):
	Begin Processing

The upper portion of this screen is used to select which families to process. The lower portion of this screen contains some options.

One of these options is the "Preview only" option. With this option selected, each family to process is opened and the changes attempted on them, but the families are not saved once the processing on them is complete. The Last Log tab will show both the successful changes that were able to be made to the families processed, as well as the changes that were not able to be made.

The "Add prefix" and "Add suffix" options let you change the names of the saved families to have them start with, or end with, text that you choose.

The "Save to alternate parent folder" allows you to save the changed versions to a completely different folder structure, while maintaining the same set of subfolders as in the original parent folder.

NOTE: Saving to an alternate parent folder <u>always</u> saves family files, even if no changes were detected.

In the example above, when the first family in the list is processed, the updated version would be saved to: D:\Temp\Processed\Samples\rac_advanced_sample_family.rfa

This is because the "Parent folder" specified at the top is "C:\Program Files\Autodesk\Revit 2017" but the family being processed is in the *further* subfolder "Samples" – so that set of subfolders is appended to the alternate parent folder selected, which was "D:\Temp\Processed"

There are more options available as well:

Preview only: Does NOT save any families to disc (useful for testing your settings)

Add prefix: Add suffix: Re-save even if no chan	iges needed (useful for upgrade	s or compacting families)						
Save to alternate parent folder:		Browse						
Override the preview image using the view with this name (select or type the case-sensitive view name):	Preview	\sim						
Create new shared parameters file from all unique shared parameters found in families:								
Create type catalog files								
Delete the types in the families 🛛 Include instance params 🗌 Sort params alphabetically	Sort types alphabetically	Save as *.csv files						
Exclude params with names including (separate with characters, * wildcards are supported): CTRL*/*Calc	culated*							

The "Override the preview image using the view with this name (select or type the case-sensitive view name)" allows you to specify a view to use to create a new preview image. If this option is unselected (the default) the preview image will be regenerated from the last view used to make it, retaining the same preview image as was originally in the file.

If this option is selected, and a view with the specified name can be found in the family, the preview image will be recreated using the specified view. The list of choices for views to use comes from the currently open family, however you may type in any view name you wish. Just remember that view names are case-sensitive.

The "Create new shared parameters file from all unique shared parameters found in families" option, if checked, will create a new shared parameters file that will consist of all the unique shared parameters found in all the families that are processed.

There are some limitations:

- The shared parameters file to create must not exist. You will not be able to proceed until the name of a new file to create has been specified.
- Some information, such as the descriptive tool-tip text for parameters, cannot be determined from the families and as such will not be included in the resulting shared parameters file
- The shared parameters file WILL NOT be generated if the resulting file would have included bad data, such as multiple parameters with identical case-sensitive names but different GUIDs. In a case like that, the log will include the reason why the file could not be generated.

If, in the Options, the option for "When creating a shared parameters file, show the detail log" is enabled, a separate window will appear after the processing is complete which shows which parameter was added from which family file, and which parameters were skipped because they are duplicates of ones already added to the shared parameters file. For example:

Shared Parameters Found Log				_		×		
🕞 Copy to Clipboard 🛛 层 Save						술 Reset		
Shared Parameter Name	Shared Parameter GUID	Added?	Source Family					
Overall Length	1d650a63-8dc5-41ec-883f-138e10513593	Yes	C:\Temp\Bug\Family1.rfa					
Total Surface Area	a7667a23-2866-445e-86f5-7b533b60b94c	Yes	C:\Temp\Bug\Family1.rfa					
Overall Width	55facb25-0921-4cd4-87f1-bdd55e51a1a1	Yes	C:\Temp\Bug\Family2.fa					
Total Surface Area	a7667a23-2866-445e-86f5-7b533b60b94c	No (Duplicate)	C:\Temp\Bug\Family2.fa					
Overall Height	dcb28b7c-10e1-47f9-a5ae-3bcaa896282a	Yes	C:\Temp\Bug\Family3.rfa					
Total Surface Area	a7667a23-2866-445e-86f5-7b533b60b94c	No (Duplicate)	C:\Temp\Bug\Family3.rfa					
OK								

The "Create Type catalog files" option, if checked, will create type catalog files next to the family files being saved.

NOTE: The type catalog files will NOT include built-in parameters, such as Manufacturer, Cost, etc. These are most commonly seen in the Identity Data group.

If type catalog files exist, the new ones being generated will overwrite the old ones.

IMPORTANT: If you choose to "Delete the types in the families" be aware that once the types are removed from the families, they are gone and cannot be used to regenerate type catalogs again in the future. For example, if you generate type catalogs and delete the types from the families, then later add a parameter to the families and want to regenerate the type catalogs, the old type catalogs will get overwritten with new ones that have no types in them.

If you leave the types in the families users can still benefit from this by only loading the desired types into the project using the type selector dialog, thus keeping the project smaller and lighter and simpler to use than if all the types in the family were loaded, which is what happens when not using type catalogs.

IMPORTANT: If you choose to "Delete the types in the families" be sure to test this process on some families with this option turned OFF to ensure the type catalog files generated include all the data necessary. Once the types in the families have been deleted, the only way to get missing data back is to revert to using backup copies of the families from before the types were deleted.

If the option to sort the parameters is selected, the parameters in the type catalog files generated will be sorted alphabetically. If it is not selected, the parameters will appear in the order returned by Revit. In 2015 or later, this is the order seen within each group on the Family Types dialog in Revit, however the order the grouped parameters appear in the type catalog file is determined by Revit. For example, the Identity Data group may be shown last in the Revit user interface, but the parameters from that group may be listed somewhere in the middle.

If the option to sort the types alphabetically is selected, the types listed in the type catalog will be sorted alphabetically, but this is a TEXT sorting. So if, for example, you have types that start with numbers, they may not appear sorted in numerical order. For example, you might see something like this:

4

(Parameter sorting works the same way.)

If the option to sort the types alphabetically is NOT selected, the types will be listed in whatever order Revit provides.

The option to save the type catalog files to *.csv files (instead of the default *.txt files) may be useful if you want to edit the type catalog files manually in spreadsheet software before finally saving them to *.txt files for production use with Revit. For example, you may want to delete some parameters (columns) from the type catalog file before the final renaming to *.txt files, and the easiest way to do that is likely in spreadsheet software.

The option to exclude parameters by name using wildcards can remove parameters from the type catalog that are not desired.

For example, you may have a naming convention for parameters which are used to control how geometry flexes. Perhaps those parameters have names that start with CTRL. For example:

CTRL_AutoHeight CTRL_ArrayCount

You may also want to exclude formula-driven calculated parameters whose names have "calculated" in them.

To filter both of these sets of parameters out of the type catalog, you'd type:

CTRL* | * calculated*

Note that there should be no spaces around the pipe (|) separator character.

IMPORTANT: Parameter names are case-sensitive, and as such these searches are case-sensitive as well. So searching for parameters that start with

CTRL*

is different than searching for parameters that start with

Ctrl*

Once you click the "Begin Processing" button, the families will be opened and processed. A progress dialog that looks like this will be displayed:

Processing Progress
Adding family parameters to 'rac_advanced_sample_family.rfa'
Overall Progress: Processing family 1 of 4
Calife

If the "Cancel" button is clicked, you will be asked if you want to stop processing the families. If processing is stopped, any families processed up to this point WILL have been saved with the settings applied.

Last Log Tab

This tab is automatically displayed once processing has completed. It shows a log of all the actions that were attempted, and the success or failure of each action:

RP F	amily Proc	essor		— 1						
🕞 🕶 🕆 🖹 New Settings 🚔 Open Settings 🚽 Save Settings 🗄 Options 🔞 Help 💽 Videos 🕕 About										
Fami	y-Level Proc	essing Lookup Tables C	hange Materials Change Parameters Select Families & Begin Last Log							
😢 1 Error 🚯 15 Info 📀 10 Successful 📄 Copy to Clipboard 🔄 Save										
	Туре	Time	Message	Source	Details \land					
0	Info	2016-12-28 13.26.38.273	PROCESSING FAMILY FILE: C:\Program Files\Autodesk\Revit 2017\Samples\rac_advanced_sample_family.fa	ProcessFamilies						
0	Info	2016-12-28 13.26.38.740	Updating Family Settings:	Change Family Level Settings	rac_adv					
0	Success	2016-12-28 13.26.38.831	The family settings parameter 'Shared' was set to Checked	Set Family Setting	rac_adv					
\bigcirc	Success	2016-12-28 13.26.38.930	Family update complete.	ProcessFamilies						
0	Info	2016-12-28 13.26.39.158		ProcessFamilies						
0	Info	2016-12-28 13.26.39.718	PROCESSING FAMILY FILE: C:\Program Files\Autodesk\Revit 2017\Samples\rac_basic_sample_family.rfa	ProcessFamilies						
8	Error	2016-12-28 13.26.39.758	Unable to process family: 'rac_basic_sample_family.rfa' a family with this name is already open in this Revit session.	ProcessFamilies						
0	Info	2016-12-28 13.26.39.788	PROCESSING FAMILY FILE: C:\Program Files\Autodesk\Revit 2017\Samples\rme_advanced_sample_family.rfa	ProcessFamilies						
0	Info	2016-12-28 13.26.40.196	Updating Family Settings:	Change Family Level Settings	rme_adv					
0	Success	2016-12-28 13.26.40.284	The family settings parameter 'Shared' was set to Checked	Set Family Setting	me_adv					
0	Success	2016-12-28 13.26.40.374	Family update complete.	ProcessFamilies						
0	Info	2016-12-28 13.26.40.634	ProcessFamilies							
0	Info	2016-12-28 13.26.41.207	PROCESSING FAMILY FILE: C:\Program Files\Autodesk\Revit 2017\Samples\rme_basic_sample_family.fa	ProcessFamilies						
0	Info	2016-12-28 13.26.41.724	Updating Family Settings:	Change Family Level Settings	rme_bas					
0	Success	2016-12-28 13.26.41.813	The family settings parameter 'Shared' was set to Checked	Set Family Setting	me_bas					
<		1		1	>					

Buttons along the top allow you to turn on and off the different types of messages. For example, clicking the "Info" button will not show any Info rows in the log. Only Error, Warning and Successful messages would remain in the list.

NOTE: If the "Log only errors" option is checked then only errors (and a few info messages such as separators) will appear in the log.

The log can also be saved to one of several formats, including a spreadsheet format, comma-delimited text file, a tabdelimited text file and as an XML file.

Logs for each run can be automatically saved as comma-delimited text (CSV) files to a specified folder. This can be controlled by the Options settings.

Family Processor Best Practices

Because of the complexity of the settings that can be applied and because they can be applied to many families, it is recommended that you take great care when using Family Processor:

- **Carefully configure your settings.** By default Family Processor "remembers" your last settings between runs, so if starting a new set of operations, use the "New Settings" button first. The option to remember settings between runs can be turned off in the Options dialog.
- Test the settings by running the changes on the current family, or on multiple family files, *but in "Preview Only" mode*, then review the resulting log. Neither of these modes will save changes to any of the family files.
- Test on a *copy* of one family to process, then open the processed family in Revit and check it to ensure it was processed correctly.
- In order to keep the final family files as small as possible, Family Processor "rebuilds" the family files, which results in no automatic backup files being created. As such, if not saving the processed families with the "_(Edited)" suffix, and if not saving the processed families to an alternate parent folder, make sure you have other copies of the original family files before processing begins, in case the processing results in any undesirable changes and you need to go back to the original versions for reprocessing after changing the settings accordingly.
- The currently open family will be used as a source for default values, such as for material definitions, and existing parameters and the settings/values/formulas on them. So starting with a family open that already has the settings to be applied to other families can save time and improve consistency across your content.

Import & Link Manager

Overview

Import & Link Manager provides a more complete picture of the imports and links in a Revit model. Imported CAD objects are notoriously difficult to find and remove, and this tool makes working with imports and links much easier.

Starting Import & Link Manager

On the Revit ribbon, click on the "Import & Link Mgr" button.



Once the button is clicked, Import & Link Manager will open.

The Main Dialog

The main dialog lists all of the imported or linked CAD or Revit files in the active project. For each file, the following information is displayed (some columns have been turned off in Options):

IM Im	port and Link Ma	inager						-		×
ILM	🔣 🗸 🔍 Show Object 🛛 🚽 Save Report 🚔 Load/Unload Files 🗄 Options 🔞 Help 🔁 Videos 🕦 About									
All	All Links All Imp	orts Revit Links	CAD Links							
🗄 🍂 Pi	n 📌 Unpin 🚔	Change Workset	• © Reference Typ	e 👻 💈 Relo	ad 🗋 Swap/	Reload From File.	📄 Swa	p/Reload From Folder 🔎 Find/Replace 🗙 Re	emove	
	Name	Insertion Method	Workset	Referencing Sheet	Sheet Number	Туре	Pinned	Linked File Location	Status	^
۱.	Wall Base.dwg	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)		P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Structural Base	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Structural Base	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Building Sectio	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Exterior Elevati	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Section1.dwg	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Section2.dwg	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	
	Sections.dwg	Link	View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets	Loaded	~
										.:

Name – The value of the "Name" parameter under Identity Data for the import or link

Element ID – The Revit element ID of the import or link

Insertion Method – Displays Import or Link

Workset - Displays the import or link's assigned Workset

Host View – Displays either the view hosting the import/link or "(All Views)"

Referencing Sheet – For some link types, the name of the sheet where it is placed.

Sheet Number – Number of the referencing sheet.

Type - The file extension of the imported or linked file

Pinned – Displays the *Pinned* status, a checked box indicates the element is pinned

Linked File Location - For linked files only, this field displays the path to the linked file

Status – For linked files only, If the linked file can be found at the path a "Loaded" status will be displayed, if the file can't be found an "Invalid" status will be displayed.

The "Show Object" button can be used find a CAD object within the Revit model. To use this tool, first select the desired CAD object from the list and then click "Show Object"



If an opened view that shows the selected CAD object cannot be found, the following message will be displayed:



Once a view has been found for the selected CAD object, that view will be made the current view and the view will be zoomed in to the CAD object's extents.

The "Pin" and "Unpin" tools can be used to toggle the *Pinned* status of each imported or linked CAD object. To use this tool, first select the desired CAD object(s) from the list and then click either "Pin" or "Unpin."

	IM In	Import and Link Manager								
	ШM	🕶 🔍 Show Objec	t 🛃 Save Repo	ort 🖳 Load/Unio	ad Files	Options	🗿 Help 下 Video	s 🕦 Abo	out	
All All Links All Imports Point clinks CAD Links Reference Type - 2 Reload Swap/Reload From File Swap/							p/Relo;			
Name Insertion Method Workset Referencing Sheet Sheet Number Type Pinned Wall Base.dwg Link View "Drafting Vie <none> <none> CADLink (.DWG) ✓</none></none>								Pinned	Linker	
									P:\Ten	
Structural Base Link Vie				View "Drafting Vie	<none></none>	<none></none>	CADLink (.DWG)	\checkmark	P:\Ten	

The "Change Workset" button will only be available in a project that has Worksharing enabled. To assign an import or link to a Workset, first select it from the list, then click the "Change Workset" button and select the desired Workset from the dropdown list.

LM	Import and Link Manager									
🚺 🗸 🔍 Show Object 🛛 🐺 Save Report 🖾 Load/Unload Files 🗄 Option										
All All Links All Imports Revit Links CAD Links										
1 🍂 F	🕴 📌 Pin 📌 Unpir 🚘 Change Workset 🔹 📾 Reference Type 🕞 🛷 Reload 🗋 Swap/Reloa									
	Name	Workset1 Shared Leve Change Workset		Referencing Sheet	Sheet Number	Тур				
•	Wall Base.d <mark>i</mark> (Doors Walls Windows		<none></none>	<none></none>	CAE				
	Structural Bas		<none></none>	<none></none>	CAD					
	Structural Base	Building 2		<none></none>	<none></none>	CAD				
	Buildina Sectio	- · · · ·		<none></none>	<none></none>	CAD				

The "Reference Type" button allows the setting of .RVT links to either "Attachment" or "Overlay.

LM In	Import and Link Manager									
ILM	🛨 🔍 Show Objec	t 🛃 Save Repo	rt 🔄 Load/Unload Files.	🗄 Options 🔞 He						
All	All Links All Imp	orts Revit Links	CAD Links							
🗄 🍂 Pi	n 📌 Unpin 🚔	Change Workset	🕫 📾 Reference Type 👻 🤰	Reload 🗋 Swap/Relo						
	Name	Insertion Method	V Overlay Attachment	ncin <mark>g Sheet Typ</mark> Number Typ						
	Building Sectio	Link	/iew_pratting_vie <ivone></ivone>	None> CAE						
	Exterior Elevati	Link	View "Drafting Vie <none></none>							
	Section1.dwg	Link	View "Drafting Vie <none></none>	< <none></none>						
	Section2.dwg	Link	View "Drafting Vie <none></none>	<none> CAE</none>						
	Sections.dwg	Link	View "Drafting Vie <none></none>	< <none></none>						
F	2	Link (Overlay)	Workset1 <all th="" view<=""><th>ws> <all views=""> Rev</all></th></all>	ws> <all views=""> Rev</all>						
	3	Link (Overlay)	Workset1 <all th="" view<=""><th>ws> <all views=""> Rev</all></th></all>	ws> <all views=""> Rev</all>						

If a Revit link is selected, the room bounding option can be set or unset.

All	All Links	All Imports	Revit Links	CAD Links				
🕴 🍂 Pi	n 📌 Unp	in 🚔 Cha	nge Workset	👻 🖘 Refe	erence Type	- 🗌 -	Room Bound	ding 🗸
	Name		Flement Id	Ins	ertion Methor		Yes	
							No	ц
Þ	5		1710000	1.1				4
	Golden Nu	iaget BIM	2579226	Imp	ort			

The "Reload" and "Swap/Reload From..." buttons can be used to swap or reload an import or link with an updated or alternate file. To use this tool, first select the import or link from the list and then click "Swap/Reload From..."

IM In	Import and Link Manager – 🗆 🗙										
🔣 🗸 💭 🗸 💭 Show Object 🛛 🚽 Save Report 🖾 Load/Unload Files 🗄 Options 🔞 Help 🔁 Videos 🕦 About											
All	All Links All Imp	oorts Revit Links	CAD Links								
🗄 🍂 P	in 📌 Unpin 🚔	Change Workset	🔹 🕶 Reference Typ	e 🛛 🥏 Relo	ad 🗋 Swap/	/Reload From File.	📄 Swa	p/Reload From Folder 🔎 Find/Replace 🗙	Remove		
	Name Insertion Method Workset Referencing Sheet Sheet Number Type Pinned Linked File Location Status										
	Building Sectio Link View "Drafting Vie <none> <none> CADLink (.DWG) P:\Temp\App Testing\User Monitor\CAD\Sheet Sets Loaded</none></none>										

A dialog will open with the previous path to the file and options to handle the new import or link. Once the options are configured, click "OK" to apply the changes.

"Swap/Reload From Folder..." allows the selection of a source folder from which to load multiple files.

"Find/Replace..." can be used to modify portions of paths to quickly change multiple links at one time. See the topic "Find and Replace Paths" in this section.

When ILM is used to re-load a linked file, the existing link/import is removed and replaced with the updated file. Keep in mind that changes in geometry may cause the locations to shift when using center placement options. In most cases, placement according to origin (file origin - Revit origin) will produce the most consistent results.

Import/Link	CAD			Х
Select the impo	rt/link properties for replacment of t	he s	elected instances (Count: 1)	
Insertion Option	15			
Insertion:	Link	\sim	☑ Orient to view	
Placement:	Center to Center	\sim	Correct lines that are slightly off-axis	
Colors:	Preserved	\sim		
Layers:	All	\sim		
Import Units:	Auto-Detect	\sim	1	
Host View:	<do alter="" not=""></do>	\sim		
	<all views=""> <do alter="" not=""> Ceiling Plan: CEO 326 - Reflected Ceiling Plan: Level 1 Ceiling Plan: Level 2</do></all>	^	OK Cancel	

Choose "Do Not Alter" or a specific view in the list to limit the placement of the link. Choose "All Views" to make the link visible in all applicable views of the model.

The "Remove" button can be used to delete an import or link from the project. To use this tool, first select the import(s) or link(s) to remove and then click the "Remove" button.

Save Report

The "Save Report" tool is used to export the list of links as a spreadsheet. The report can be saved in either Microsoft Excel OpenXML or Microsoft Excel version 8 (xlsx or xls) types.



Load/Unload Files

The *"Load/Unload Files..."* tool can be used to load or unload links in a Revit project. This tool can only be used on documents that are not open in any Revit session.

IMPORTANT: Due to limitations when performing changes to Revit files without opening them, using this function on a workshare enabled central file is not supported. It will set the state of the project such that it will require recentralization.

Ensure the project to load or unload links from is closed, open a different project in Revit (or create a new project) and launch Import & Link Manager. Click the "Load/Unload Files..." button.



Browse to the Revit model file, select it in the browser window and choose "Open".

The list of Links contained in the selected project file will be displayed. The "Previous File Path" and "Previous State" columns indicate link locations and the status of each link as it was when the file was last saved.

IJ	IM Load/Unload Files - A18_RET Demo Building.rvt								
😭 Open Project 📔 Load 🏹 Unload 📔 Load From File 📔 Load From Folder 🔎 Find/Replace									
	File Path	Path Type	Status						
	RevitKeynotes_Imperial_2004.txt	Content	Loaded						
	UniformatClassifications.txt	Content	Loaded						
	P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2	Relative	Loaded						
	S17_RET Demo Building.rvt	Relative	Unloaded	1					
	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R	Relative	Loaded						
	P:\Temp\App_Testing\User_Monitor\CAD\Sheet_Sets\Architectural\R	Relative	Loaded						
		i	1	-					

The "Load", "Load From..." and "Unload" buttons can be used to modify the links. Changes made to the links will be displayed in the "Desired File Path" and "Desired Status" columns.

		_							
d From Folder 🔎 Find/Replace 🔯 Switch Absolute/Relative 🥪 Apply									
Status	Desired File Path	Desired Path Type	Desired Status						
Loaded	RevitKeynotes_Imperial_2004.txt	Content	Loaded						
Loaded	UniformatClassifications.txt	Content	Loaded						
Loaded	P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2	Relative	Loaded						
Unloaded	S17_RET Demo Building.rvt	Relative	Unloaded						
Loaded	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R	Relative	Loaded						
Loaded	P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R	Relative	Loaded						
	 P Find/Replace. Status Loaded Loaded Unloaded Loaded Loaded Loaded Loaded 	Prind/Replace Switch Absolute/Relative Apply Status Desired File Path Loaded RevitKeynotes_Imperial_2004.txt Loaded UniformatClassifications.txt Loaded P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2 Unloaded S17_RET Demo Building.rvt Loaded P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R Loaded P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R	P Find/Replace Image: Switch Absolute/Relative Image: Apply Status Desired File Path Desired Path Type Loaded RevitKeynotes_Imperial_2004.txt Content Loaded UniformatClassifications.txt Content Loaded UniformatClassifications.txt Content Loaded P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2 Relative Unloaded S17_RET Demo Building.rvt Relative Loaded P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R Relative Loaded P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R Relative						

Once all desired changes have been made, click the "Apply" button. Changes to the Revit project will be applied the next time the project is opened.

Find and Replace Paths

ILM can be used to correct portions of the paths to references on multiple links at one time. In the Load/Unload Files window, click on 'Find/Replace'.

	M Load/Unload Files - A18_RET Demo Building.rvt						×
1	彦 Open Project 🖻 Load 🏾 א Unload 📲 Load From File 📓	Load From Folder	🔎 Find/Replace	😰 Switch Absolute/Relative 🤡 Apply			
	File Path	Path Type	Status	Desired File Path	Desired Path Type	Desired Sta	atus
	RevitKeynotes_Imperial_2004.txt	Content	Loaded	RevitKeynotes_Imperial_2004.txt	Content	Loaded	
Γ	UniformatClassifications.txt	Content	Loaded	UniformatClassifications.txt	Content	Loaded	
	P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2	Relative	Loaded	P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2	Relative	Loaded	
	UniformatClassifications.txt P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2	Content Relative	Loaded Loaded	UniformatClassifications.txt P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2	Content Relative	Loaded Loaded	

In the "Find what:" text box, enter the part of the file path to search for.

M Find/Replace							
Find what:							
P:\Temp\App Testing\User Monitor\							
Replace with:							
P:\Temp\App Testing\Project Activity Logger\							
P:\Temp\App Testing\Project Ac	ctivity Logger\						
P:\Temp\App Testing\Project Ac	ctivity Logger∖						

📖 Load/Unload Files - A18_RET Demo Building.rvt 📁 Open Project... | 🙋 Load 🍺 Unload 📴 Load From File... 🔛 Load From Folder... 🔎 Find/Replace... | 🖻 Switch Absolute/Relative | 🥪 Apply File Path Path Type Status Desired File Path RevitKeynotes_Imperial_2004.txt Content Loaded P:\Temp\App Testing\User Monitor\2018-projects\RevitKeynotes_Imperial_2004.txt UniformatClassifications.txt Content Loaded С M Find/Replace Х R P:\Temp\App Testing\Project Activity Logger\Projects\20170919_R2. Loaded Relative S17_RET Demo Building.rvt Unloaded R Relative P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R... Loaded Find what: R Relative R P:\Temp\App Testing\User Monitor\ P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R.. Relative Loaded R P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R... Loaded Relative Replace with: R P:\Temp\App Testing\User Monitor\(CAD\Sheet Sets\Architectural\R... Relative Loaded P:\Temp\App Testing\Project Activity Logger R P:\Temp\App Testing\User Monitor\ P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R.. Loaded R Relative P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R.. R Relative Loaded Replace Selected Cancel Replace All R P:\Temp\App Testing\User Monitor\CAD\Sheet Sets\Architectural\R... Relative Loaded

Type the part of the new path to use in the "Replace with:" text box.

The File Paths will be updated and saved to the Revit model.

The next time the project is opened, Revit may present a message that the model has been "transmitted" (due to the externally modified paths).

Manage Revit Project Links

Introduction

Manage Revit Project Links is installed as a shortcut in the Windows Explorer context menu. It can be used to modify link paths within Revit files without first opening the files in Revit. It is a quick way to change references within .rvt files in cases where the paths no longer match the locations of the files they previously pointed to.

Starting Manage Revit Project Links

To run it, open Windows Explorer and browse to the folder containing the .rvt file(s) whose links need to be updated. Right click on the file (.rvt) to invoke the context menu.

<mark> </mark> 🛃 📙 🛨	D:\Demo Sets			- 0	\times
File Home	Share View				~ 🧃
$\leftarrow \rightarrow \cdot \uparrow$	→ This PC → Data (D:) → Demo Sets		Search D	emo Sets	Q
👌 N 🔿	Name	Date modified	Туре	Size	
F	🔜 2016 test gym.rvt	7/13/2016 7:47 AM	Revit Project	117,392 KB	
📑 V	🔜 2016-CTC Office Ste 200.rvt	9/21/2015 1:27 PM	Revit Project	15,636 KB	
- 4	🔜 2016-CTC-Demo-Titleblock.rfa	3/31/2016 9:03 AM	Revit Family	460 KB	- 1
<u>.</u>	🔜 2016-linked project memo.0001.rvt	7/29/2015 10:47 AM	Revit Project	3,220 KB	
	2016-linked pr		Revit Project	1,060 KB	
	2016-SingleLev Open	M	Revit Project	29,392 KB	
	Revit Project Manage Revit Project	t Links	Revit Project	29,412 KB	
_ h	2017 test gym Revit Properties	n	AVI File	3,743 KB	
	🔜 2017 test gym. 7-Zip	> /	Revit Project	133,876 KB	
	🔜 2017 test gym. CRC SHA	>	Revit Project	134,016 KB	
	🔜 2017 test gym. 🧉 Edit with Notepad++	м	Revit Project	126,776 KB	
— ~	🔜 2017 test gym. 🖻 Share	1	Revit Project	126,816 KB	
176 items 1 ite	em selected 1.03 N Open with	>			

Revit does not need to be open to use this tool.

The main interface will present a list of links found in the file.

IJ	4 Load/Unload Files - centralFile.rvt				_	□ ×				
1	📔 Load 🔰 Unload 📔 Load From File 🛃 Load From Folder 🔎 Find/Replace 🛛 🕄 Switch Absolute/Relative 🛛 🥪 Apply									
	File Path	Path Type	Status	Desired File Path	Desired Path Type	Desired Status				
	RevitKeynotes_Imperial_2004.txt	Content	Loaded	RevitKeynotes_Imperial_2004.txt	Content	Loaded				
	T:\2014-Projects\link01mech.rvt	Relative	Loaded	T:\2014-Projects\link01mech.rvt	Relative	Loaded				
	T:\2014-Projects\link02const.rvt	Relative	Unloaded	T:\2014-Projects\link02const.rvt	Relative	Unloaded				
	T:\2014-Projects\CAD\FloorPlan-Site.dwg	Relative	Loaded	T:\2014-Projects\CAD\FloorPlan-Site.dwg	Relative	Loaded				
	T:\2014-Projects\vvt link\link03-sublinked.rvt	Relative	Unloaded	T:\2014-Projects\rvt link\link03-sublinked.rvt	Relative	Unloaded				

Modifying Link Properties in Revit Files

Using this interface, link path types, load statuses and file paths can be changed by selecting a row or rows and clicking the desired action on the toolbar.

The result of the actions chosen are shown in the last three columns.

L	M Load/Unload Files - centralFile.rvt				_		\times	
81	😰 Load 🏂 Unload 📴 Load From File 📔 Load From Folder 🔎 Find/Replace 🛛 🗟 Switch Absolute/Relative 🛛 🎯 Apply							
	File Path	Path Type	Status	Desired File Path	Desired Path Type	Desired Status		
	RevitKeynotes_Imperial_2004.txt	Content	Loaded	RevitKeynotes_Imperial_2004.txt	Content	Loaded		
	T:\2014-Projects\link01mech.rvt	Relative	Loaded	rvt link\link01mech.rvt	Relative	Loaded		
	T:\2014-Projects\link02const.rvt	Relative	Unloaded	rvt link\link02const.rvt	Relative	Loaded		
	T:\2014-Projects\CAD\FloorPlan-Site.dwg	Relative	Loaded	rvt link\FloorPlan-Site.dwg	Relative	Loaded		
	T:\2014-Projects\rvt link\link03-sublinked.rvt	Relative	Unloaded	rvt link \link 03-sublinked.rvt	Relative	Loaded		

If the changes to be made appear as expected, click Apply to make them permanent. This will modify the file selected. Be sure that it is not being used by any other program.

For more detailed information about link management and to learn about the more robust <u>Import and Link Manager</u> tool, refer to that section in this guide.

Schedule Parameter Resolver

Introduction

Schedule Parameter Resolver aids in properly mapping shared parameters to schedule parameters. As can often happen while working on projects with other offices or disciplines or because of standards unconformity, parameters in a schedule don't properly display the expected data. Sometimes there's a conflict in name, data type or shared parameters. This tool makes it easy to sync schedule columns with the right parameter data.

Starting Schedule Parameter Resolver

On the Revit ribbon, click on the "SPR" button.



Choosing a Shared Parameter File

Begin by specifying the path to the shared parameter file which contains the parameters to map to the columns in the schedule(s). Simply click the Browse button to locate the desired .txt file (must be a Revit shared parameters file).

S-IR	- 🗆 🗙	
SIR - 😂 Open Setting	🚽 Save Settings 🗄 Options 🔞 Help 🕨 Videos 🕦 About	
Shared Parameters File:	D:\Demo Sets\RET Data Sets\Shared Parameters.bt	Browse

Resolving Schedule Parameters

Choose the schedules that need to have their parameters synchronized with the selected shared parameters. The parameters in the schedules will be listed in the 'Parameters' list in the 'Parameter Name' column. The action to perform and available parameters in the shared parameters file will be available in the drop downs in 'Replace with...' column.

Schedule Parameter Resolver				-		Х
STR 🕶 🞯 Open Settings 🛃 Save Settings	i≡ o	ptions 🔞 Help 下 Videos 👲 Support	(i) About			
Shared Parameters File: C:\temp\testing\revit\mo	dels\N	laster Shared Parameter.txt			Browse	e
Schedules	Para	meters				
Filter:	~	Project Parameters 🛛 🔽 Shared Paramete	rs Filter:			
Einbauteile - DüOG1		Parameter Name	Replace with			
EP - Raumliste TOP		Level	<do not="" replace=""></do>		~	711
Fläche nach Nutzungsart		Number	<do not="" replace=""></do>		~	111
Fläche nach Nutzungsart Kopie 1		Name	<do not="" replace=""></do>		~	111
Gelanderliste Balkonvariante 2 - Stahlgela	•	Тор	<do not="" replace=""></do>		Ý	
Geländerliste Balkonvariante 3 - Glasgelä		Area	Frame Width			111
Geschossdeckenliste		Mark	Frame Width Face			
LIFT Stahlstützen		Family	Frame Width Strike			
LIFT Träger / Streben		From Boom: Name	Glazing Height			
LPH 2-VK - BÜROEINHEIT		From Room: Flächenzuordnung	Glazing Material Glazing Thickness			
LPH 2-VK - Raumliste TYP 1A		AL Desite	Glazing Thickness Bead			
LPH 2-VK - Raumliste TYP 1B	-	AL DIELE	Glazing Thickness Panel Glazing Width			
LPH 2-VK - Raumliste TYP 2B	L	AL Hone	HARDWARE GROUP			
LPH 2-VK - Raumliste TYP 3A		Aw	IfcExportAs			
LPH 2-VK - Raumliste TYP 3B		fg= Aw*0.7	IfcExportType			

Use the filter text inputs to reduce the schedules or parameters in the list by name:



Assign all of the relevant mappings by selecting the appropriate shared parameter. Any parameters left unchanged (<Do Not Replace>) will remain unaltered.

Schedules	Parameters		
OOOR SCHEDULE	Parameter Name	Replace with	~
	Ceiling Height	<do not="" replace=""></do>	~
WALL FIRE RATING SCHEDULE	Comments	<do not="" replace=""></do>	~
	Door Fire Rating	<do not="" replace=""></do>	~
	Family and Type	<do not="" replace=""></do>	~
	Floor Finish	<do not="" replace=""></do>	~
	Frame Finish	Panel Finish	~
	Frame Material	<do not="" replace=""></do>	~
	Frame Type	<do not="" replace=""></do>	~
	Hardware Group	Hardware	~
	Height	<do not="" replace=""></do>	~
	Level	<do not="" replace=""></do>	~

When finished, click OK to apply the mapping or Close to exit without saving changes. Click the expand button to see the details of the operation.

Command was completed successful	ly.			
List of replaced schedule parameters:				
Hide details	Close			

Options

Shared Parameters

Add as instance: create as instance parameters if they don't exist

Add as type parameter: create as type parameters if they don't exist

Do not add to project: if the selected parameters don't exist, don't add them

Replaced Field Headers

Always use original field header: don't change the header ever

Always change the header ... : selecting this may cause unexpected changes in width if the names aren't similar

Change only if the header matches the parameter in the existing field: default

Header Groups

Only add new fields with standalone headers: no header group will be created with the new field

Extend existing groups to the replacement fields: default

Shared Parameter Manager

Introduction

Shared Parameter Manager expands upon the out of box shared parameter editing tools to more efficiently create and edit shared parameter files, merge multiple shared parameter files, and efficiently load shared parameters into projects.

Starting Shared Parameter Manager

On the Revit ribbon, click on the "Shared Param Mgr" button.



SM Shared Parameter Manager	— 🗆 X
SM - 🕒 Export Shared Parameters - 💥 Configure Default Parameter Groups 🛛 🗄	🗄 Options 🔞 Help 🔽 Videos 🚯 About
Manage Shared Parameter File Load Shared Parameters	
Parameter Name 🗸 Search	Clear Filter: None V Show Only
Master Shared Parameter File (Enabled)	Source Shared Parameter File (Read Only)
New Browse Save,	Browse
¶ ₁₂ ≒1	Group By: Group ∨ ♣ ≒
Parameters	
Add	
Modify	
Delete	
Move	
Duplicate	
Prefix/Suffix	
Find/Renlace	
- пылкерасе	
Groups	
Add	
Rename	
Delete	

Master Shared Parameter Files

Create a new master shared parameter file by clicking the "New" button.

SM Shared Parameter Manager	— 🗆 X
SM 🗸 📑 Export Shared Parameters 🔹 🔏 Configure Default Parameter Groups 🛛 🗄 Options 🔞 Help 📘 Videos 🕦 About	
Manage Shared Parameter File Load Shared Parameters	
Parameter Name V Search Citear Filter: None	Show Only
Master Shared Parameter File (Enabled)	
New Browse Save	Browse
੍ਰੀਮੂ ਸਿੰੂ Group By: Group	나 다.
Parameters	
Add	

Browse to the desired storage location and provide a name for the new shared parameter file

SM Save As			23
◯◯ ▽ 🌗 ➤ Computer ➤ Local Disk (C:) ➤ Tem	p 🗸 🗸 🗸 P		Q
Organize 🔻 New folder		•	0
☆ Favorites Name	Date modified Type Size		
☐ Libraries ☐ Documents ↓ Music	No items match your search.		
📄 Pictures 🛃 Videos			
Computer Local Disk (C:) Cocal Disk (D:)			
File name Master Shared Parameter File			•
Save as type: Shared Parameter File (*.txt)			•
) Hide Folders	Save	Can	cel

Select "Save" to generate the new shared parameter file and have it selected as the master shared parameter file.

Selecting Existing Shared Parameter Files

To select the Master Shared Parameter file click the "Browse..." button. Only the Master Shared Parameter File will be edited by this tool.

SM Shared Parameter Manager	_		×
SM 🗸 📄 Export Shared Parameters 👻 Configure Default Parameter Groups 🛛 🗄 Options 🔞 Help р Videos 🕦 About			
Manage Shared Parameter File Load Shared Parameters			
Parameter Name V Search Clear Filter: None	~	Show	Only
Master Shared Parameter File (Enabled)			
D:\Demo Sets\RET Data Sets\2016-Type Si New Browse Save 🖨		Brows	e
រិ្ដ្រាស់ Group By: Group	\sim	1 4	ર ્
Parameters Add			

Group Management

Adding Groups

To add a group, click the "Add..." button in the Groups box.

To add all default Revit groups quickly select the "Add Default Groups" Button. Any groups that already exist will be skipped when creating new groups.

SM Shared Parameter Manager			- 🗆 X
SM 🕶 📑 Export Shared Parameters 👻 Config	ure Default Parameter Groups 🛛 🗄 Options 🧃	🕽 Help 下 Videos 🕕 About	
Manage Shared Parameter File Load Shared Param	sters		
Remarker News		Clear Filter News	Shaw Oak
Master Shared Parameter File (Enabled)		Source Shared Parameter File (Read Only)	
D:\Demo Sets\RET Data Sets\Shared Paran Ne	w Browse Save		Browse
	¶Lậ↑	Group By: Group	 N n1
	SM Add Group(s)	×	+10 10
⊞ Analysis Results			
	Group Name(s):		
	Analysis Results		
Dimensions	Enter each new Analytical Alignment		
Electrical	separate line. Constraints		
Electrical - Lighting	Construction		
Electrical - Loads	Data		
Electrical Productivity Pack	Dimensions Division Geometry		
🐑 Energy Analysis	Electrical		
Exported Parameters	Electrical - Circuiting		
Fire Protection			
Graphics	Add Default Groups OK	Cancel	
Green Building Properties			
Identity Data	Groups		
Materials and Finishes	Add		
Mechanical			
Mechanical - Air Flow	Rename		
Hechanical - Loads	Delete		
⊕. Other	00000		
🕀 Other Group			
⊕. Phasing			
Photometrics	~		

To add custom groups, type the names of each group to be created. Type each group name separated by a return or pressing the enter key. When all names have been entered, click the "OK" button.

The groups will be added to the shared parameter file.

SM Shared Parameter Manager	— D X
SM 🔹 📑 Export Shared Parameters 👻 Configure Default Parameter Groups 🗄 Options 🤘	🛿 Help 下 Videos 🕕 About
Manage Shared Parameter File Load Shared Parameters	
Parameter Name V Search	Clear Filter: None V Show Only
Master Shared Parameter File (Enabled)	Source Shared Parameter File (Read Only)
D:\Demo Sets\RET Data Sets\2016-Type Si New Browse Save	Browse
्री _व श‡	Group By: Group ✓ 🖧 ≒t
COBie Parameters CTRL Parameters Add Modific	

Renaming Groups

To rename a group, select one or more from the list. Then click "Rename..." in the 'Groups' box.

SM Shared Parameter Manager SM	fault Parameter Groups 🗄 Options 🔞	Help Dideos () About	- □ ×
Master Shared Parameter File (Enabled)		Source Shared Parameter File (Read Only)	
D:\Demo Sets\RET Data Sets\2016-Type Si New	Browse Save		Browse
COBie Parameters CTRL Parameters	ename Group(s) Old Group Name New Group Name COBie Parameters COBie Data CTRL Parameters Driven Param [] OK Add Rename Delete	Cancel	

In the "Rename Group(s)" dialog, type the new name for each group and click the "OK" button.

Deleting Groups

To delete a group, select the parameter group. Then select the "Delete" button in the 'Groups' box.



A dialog will ask for confirmation of any group(s) selected for deletion

If the group selected has parameters in it at the time of deletion a dialog will prompt to either delete the group and parameters, or to move to a new group

SM Move Parameters			×
'CTRL Parameters' grou must first move them to	p is not empty another group	. Before deleting	the group, you
Move Parameters To:	Other		•
Delete Group and Pa	arameters	Move	Cancel

Managing Parameters

Adding Parameters

To add parameters, select a group to host the new parameters. Then click the "Add..." button in the 'Parameters' box.



In the "Create New Shared Parameters" dialog select the Parameter Group, Discipline, Parameter type and (if applicable) the Category. Type the names of each new parameter. All parameters created will use the settings selected. Once all new parameter names have been entered click the "Create" button.

SM Shared Parameter Manager											×
SM - 🕒 Export Shared Parameters -	🔀 Configure Default I	Paramete	r Groups	∃ Options (🕖 Help 📘	Videos 🕕	Abou	ut			
Manage Shared Parameter File Load Sh	ared Parameters										
Parameter Name \lor Search					Clear	Filter:	None	•	\sim	Shov	/ Only
Master Shared Parameter File (Enabled) D:\Demo Sets\RET Data Sets\2016-Type	Create New Sha	red Param	neters				×	e (Read Only)		Brows	e
	Parameter Group:	Driven Pa	aram				\sim		\sim	₽	ង
COBie Data	Discipline:	Common					\sim				
Unven Param	Parameter Type:	Length					\sim				
	Category:						\sim				
	Parameter Names:		Parameter Name	Tooltip	User Modifiable	Visible					
	parameter name	0	CTRL Height	drives the	\checkmark						
	on seperate line.	./ (CTRL Width	the geometry	\checkmark						
	Batch Add	*									
					Create	Cancel					
	L		Rename					1			

In "Create New Shared Parameters", click the checkbox next to a parameter to make it visible or not visible.

Visibility checkbox allows the parameter to be invisible in the project. The parameter will still be schedule, however in the properties dialog box; the parameter will not be visible. It is not recommended to load this parameter invisible as a project parameter, it is recommended to load a parameter as invisible in a family, and then load into a project. The

parameter will be visible in the family in which it was created; it will not be visible in the project, or when nested into another family.

SM Create New Shared Parameters					
Parameter Group:	CTRL F	Parameters	•		
Discipline:	Commo	n	•		
Parameter Type:	Length		-		
Category:			Ŧ		
Parameter Names:		Parameter Name	Visible		
Enter each new		CTRL Widget Offset Left			
on seperate line.	CTRL Widget Offset Right				
Ratch Add		CTRL Widget Offset Top			
Datch Add		CTRL Widget Offset Bottom			
	. CTRL Widget Offset Front				
		CTRL Widget Offset Back			
*					
Create					

If a list exists externally or to enter parameter names in a different manner, select the "Batch Add" button. A dialog similar to the Add Groups Dialog will appear and parameter names can be entered separated by an enter.

SM Create Batch Shan	ed Parameters	23
Parameter Name(s): Enter each new parameter name on seperate line.	CTRL Widget Offset Left CTRL Widget Offset Right CTRL Widget Offset Top CTRL Widget Offset Bottom CTRL Widget Offset Front CTRL Widget Offset Back	
	OK Can	el

When finished adding parameters, select the "Create" button. The entered parameters will be added to the Shared Parameter file.

Modifying Parameters

To modify a shared parameter select a single parameter from the list. Then click the "Modify..." button in the 'Parameters' box

🗸 🗕 Export Shared Parameters 👻 Configure Default	t Parameter Groups 🛛 🗄 Opti	ons 🕡	Help 🕕 Abo	out		
lanage Shared Parameter File Load Shared Parameters	1	1				
arameter Name 🔻 Search			Clear	Filter: None	•	Show Only
Master Shared Parameter File			Source Share	d Parameter File		
C:\Temp\Master Shared Parameters File.txt New	Browse Save	\$				Browse
‡la	₽(Group By:	àroup	~	î⊾ ≈‡
Analytical Model Analytical Model COBie2 Parameters Constraints Construction CTRL Vidget Angel CTRL Vidget Offset Bottom CTRL Vidget Offset Front CTRL Vidget Offset Right CTRL Vidget Offset Right CTRL Vidget Offset Right CTRL Vidget Offset Right CTRL Vidget Offset Top Data Dimensions Division Geometry Electrical Electrical - Lighting Electrical Engineering Electrical Engineering Energy Analysis Fire Protection	Add Modify Delete Move Groups Add Rename Delete					

In the "Modify 'parameter name' Parameter" dialog, the name, group, Discipline, Parameter type, Category and Visibility can be changed.

In this example the spelling error "Angel" has been corrected to "Angle." Click "OK" to accept the new settings.

SM Modify 'CTRL Widget Angel' Parameter						
Name:	CTRL Widget Angle					
Group:	CTRL Parameters					
Discipline:	Common 🔻					
Parameter Type:	Length					
Category:	· · · · · · · · · · · · · · · · · · ·					
	Visible					
	OK Cancel					

Any changes made to the Parameter name, Discipline, Parameter Type or Category will cause a new GUID to be generated for the shared parameter. The following dialog is a warning of the ramifications of changing a parameter GUID. Click "Yes" to continue or "No" to cancel.



Deleting Parameter(s)

To delete a shared parameter select a parameter(s) from the list. Then click the "Delete" button in the 'Parameters' box

SM Shared Parameter Manager					- • •
STM - 🕒 Export Shared Parameters - 🔀 Configure Default Paramet	ter Groups 🗄 Options 🕼) Help (1) A	bout		
Manage Shared Parameter File Load Shared Parameters					
Parameter Name		Clear	Filter: None	•	🗖 Show Only
Master Shared Parameter File		Source Sha	ared Parameter File		
C:\Temp\Master Shared Parameters File.txt New Browse.	Save 😝				Browse
Ĵta ¤t		Group By:	Group	-	îta ≈t‡
- Analysis Results	Parameters				
- Analytical Alignment	Add				
- Analytical Model					
Constrainte	Modify				
Construction	Delete				
CTRL Parameters					
CTRL Widget Angle	Move				
CTRL Widget Offset Bottom	Crewra				
CTRL Widget Offset Front					

Deleting parameters is permanent and cannot be undone. A dialog box will be displayed asking for confirmation before deleting parameters from the shared parameter file.



Hint: many of the actions that can be performed on groups and parameters are also available in the right-click context menu.

SM Shared Parameter Manager SM - Export Shared Parameters - X Configure Defa Manage Shared Parameter File Load Shared Parameters	ault Parameter Groups 🗄 Options 🕷	🛿 Help 下 Videos 🕦 About	– 🗆 X
Manage Shared Parameter File Load Shared Parameters Parameter Name Search Master Shared Parameter File (Enabled) D:\Demo Sets\RET Data Sets\2016-Type Si New COBie Data COBie Data New CTRL Add Parameters New Modify Parameters Delete Parameters Modify Parameters Duplicate Parameters Duplicate Parameters Add Prefix/Suffix Find/Replace Hard Groups Delete Groups Delete Groups	Browse Save Browse Save Parameters Add Modify Delete Move Duplicate Prefix/Suffix Find/Replace Groups Add Rename	Clear Filter: None Source Shared Parameter File (Read Only) Group By: Group	Show Only Browse ↓ the
	Delete		

Saving The Master Shared Parameter File

Changes are only made permanent once the master parameters file is saved. After saving, it is possible to roll back changes by using one of the backup files stored in the same directory as the master.

To save any changes to the master shared parameter file, select the "Save" button to the right of the master shared parameter file name

SM Shared Parameter Manager	
SM 🗸 📑 Export Shared Parameters 👻 Configure Default Parameter Gro	os ⋮Ξ Options 🔞 Help 🕦 About
Manage Shared Parameter File Load Shared Parameters	
Parameter Name	Clear Filter: None 🔻 🗖 Show Only
Master Shared Parameter File	Source Shared Parameter File
C:\Temp\Master Shared Parameters File.txt New Browse	Save Browse
jte ¤j	Group By: Group 🗸 🖞
- Analysis Results	ers
- Analytical Alignment	dd
COBie2 Parameters	dify
Constraints	

Click close, after the "Save is Successful" dialog will confirm the save.

Save Successful	X
The shared parameter file is successf	ully saved.
	Close

Once saved, a back-up of the original master shared parameter file will be saved in the original file path. In the file path, the back-up will appear with a .1.txt file name extension. (I.E. File name is Shared_Parameter1.txt, back-up will appear as Shared_Parameter1.1.txt). Number of back-ups saved is defaulted to 1. To change, go to options.

SM Select Source Shared Parar	neter File			22
◯◯ ▽ 🌗 ト Computer	r 🕨 Local Disk (C:) 🕨 Temp	√ 49	Search Temp	Q
Organize 🔻 New folde	r			- 1 0
Downloads	Name	Date modified	Туре	Size
Becent Discor	COBie.txt	2013-11-11 15:50	Text Document	137 KB
Recent Places	Master Shared Parameter File.3.txt	2013-11-21 11:43	Text Document	11 KB
E Libertin	Master Shared Parameter File.txt	2013-11-21 11:49	Text Document	23 KB
	Source Shared Parameters File.2.txt	2013-11-21 11:39	Text Document	8 KB
Music	Source Shared Parameters File.txt	2013-11-21 11:43	Text Document	136 KB
Pictures Videos				
🖳 Computer				
🚢 Local Disk (C:)				
Local Disk (D:)				
File na	me:	•	Shared Parameter	r File (*.txt) 🔹
			Open	Cancel

Source Shared Parameter Files

To open the source shared parameter file, click the "Browse..." button. The source shared parameter file will not be edited.

Help 🕦 About
Clear Filter: None
Source Shared Parameter File
Browse
Group By: Group 🗸 ମିଧ୍ୟ ମ୍
Copying Parameters or Groups from the Source to the Master

To copy shared parameters from the source to the master, select the desired parameter(s) and drag and drop them onto the desired group in the master shared parameter file.



The parameter(s) will be copied into the master shared parameter file, retaining all settings and GUIDs.

Parameters from multiple groups can be dragged simultaneously into a single group.

 Green Building Properties Green Building Properties Identity Data IFC Parameters Layers Materials and Finishes Mechanical Mechanical - Loads Model Properties Other Overall Legend Phasing Photometrics Plumbing Rebar Set 	Add Add Delete Groups Add Rename Delete Delete	Construction Construction Construction Curb Exists Electric Heat Electric Heat Electrical Electrical Electrical Electrical Electrical Electrical Electrical Electrical Coefficient of Performance Design Ambient Summer Dry Bulb Temperature	
Coefficient of Performance		Design Ambient Sammer Wet Dalb Temperature	
Design Ambient Summer Dry Bulb Temperature		Design Ambient Winter Dry Bulb Temperature	
Economizer		Energy Efficiency Bating	

Groups can be dragged and dropped as well. When dragging and dropping a group, all parameters contained in that group will be copied too.



Filters

Filters can be used to show conflicting, duplicate and unique parameters as well as identify naming issues in parameter names for both shared parameter files, click the "Filter" dropdown box.

SM Shared Parameter Manager					- 0	x
SM - E Options Help () About						
Manage Shared Parameter File Load Shared Parameters						
Parameter Name			Clear Filter None	•	Show	Only
Master Shared Parameter File			Source Shared Parane None			
C:\Temp\Master Shared Parameter File.txt New	Browse Save	4	C:\Temp\Source Share Unique		Brows	e
	Îa ¤1		Group By: Group Naming I	; ssues	Ĵ⊧	₽ ‡
Return Fan Full Load Current	 Parameters 		E COBie2			
Return Fan HP	Add		Constraints			

To show only parameters that match the filter criteria, click the "Show All" Checkbox.

SM Shared Parameter Manager	
도 🕅 👻 🕒 Export Shared Parameters 🗸 🔀 Configure Default Parameter Groups 🛛 🗄 Options) Help 👔 About
Manage Shared Parameter File Load Shared Parameters	
Parameter Name	Clear Filter: Duplicate 🗸 🗸 Show Only
Master Shared Parameter File	Source Shared Parameter File
C:\Temp\Master Shared Parameters File.bt New Browse Save	C:\COBie.txt Browse
Çis Si∳	Group By: Group 🔹 🦹
Graphics	

Search

To search for specific parameters, click in the search bar and type in parameter name or parameter Type. The search will break down as a new character is added.

SM Shared Parameter Manager			
SM - 🖹 Export Shared Parameters - 🗶 Cor	nfigure Default Parameter Groups 🗄 Options 🕼) Help (i) About	
Manage Shared Parameter File Load Shared Pa	arameters		
Parameter Name 🔹 appare		Clear Filter: None	👻 🔲 Show Only
Master Shared Parameter File		Source Shared Parameter File	
C:\Shared Parameters.txt	New Browse Save 😝	C:\COBie.txt	Browse
	Ĵu ¤l	Group By: Group	• 1: 1:
Analysis Results	Parameters	COBie2	~

Click "Clear" to remove the search criteria and show all parameters.

SM Shared Parameter Manager		
SM - Export Shared Paramet	ers 🗕 💥 Configure Default Parameter Groups 🛛 🗄 Options 🛛 🔞 🕨	Help 🕕 About
Manage Shared Parameter File	oad Shared Parameters	
Parameter Name		Clear Filter: None Source Shared Parameter File
C:\Shared Parameters.bd	New Browse Save	C:\COBie bd Browse
	਼ੈਰਿ ਸੈ	Group By: Group 🔻 🕄
 Analysis Results ⊕ Circuit 	Parameters	COBie2 COBieAccessibilityPerformance

Exporting Parameters

Shared Parameter Manager has the ability to export all shared parameters from a project and (optionally) any family content loaded into the project. To export parameters, click the "Export Shared Parameters" button and select either the "From project" or "From project and families" option.

SM Shared Parameter Manager	-				
SM Export Shared Parameters - 🔀 Co	onfigure Default Parameter Groups 🗦 Option	ıs 🔞 He	elp 🕕 About		
Manau From project	ra neters				
Parar even wante					
Master Shared Parameter File	the shared parameters that are added to the pr	sject.	ource Shared Parameter File		
C:\Shared Parameters.txt	New Browse Save	🥔 🕻	:\COBie.txt	Browse	
	‡la ≈l ‡	G	iroup By: Group	• 1: 1:	
🕀 Analysis Results	Parameters	6	COBie2	*	
Ercuit ⊕- Clearance	Add				

A dialog will prompt for the location to save the new Shared Parameter file. Select the location and file name and click the "Save" button.

SM Export Shared Parar	eters		23
🔾 - 🚰 🕨 Co	nputer 🕨 Local Disk (C:) 🕨 🔫 😽	Search Local Disk (C:)	Q
Organize 🔻 Ne	folder	:==	• 🕡
	Name	Date modified	Туре 🔺
 Libraries Documents Music Pictures Videos Computer Local Disk (C:) New Volume (Autodesk FromDesktop Intel MSOCache NVIDIA PerfLogs Program Files Program Files (x86) 	7/31/2013 3:30 PM 12/18/2013 8:26 AM 7/19/2013 9:46 AM 7/19/2013 9:40 AM 7/19/2013 4:56 AM 7/13/2009 10:20 PM 11/25/2013 11:17 1/2/2014 9:41 PM	File folde File folde File folde File folde File folde File folde File folde
			*
File name:			
Save as type:	hared Parameter File (*.txt)		•
Hide Folders		Save	ancel

A dialog will confirm that parameters have been exported successfully.



Selection Sets

The "Load Shared Parameters" tab is used to create selection sets. Selection sets are saved collections of Shared Parameters from one shared parameter file and all of the settings required to create project parameters from them.

Opening Shared Parameter File

To open a shared parameter file, click the "Browse..." button.

SM Shared Parameter Manager		
SM - 🕒 Export Shared Parameters - 💥 Configure	Default Parameter Groups 🗄 Options 🔞 Help 🕦 About	
Manage Shared Parameter File Load Shared Parameter	15	
Shared Parameter File:		Browse Open Master
Group By: Group	Selection Set	
	New Delete Discipli	ne:
	Rename Copy Type of Parameter	18:
	Group parameter und	ler:
	Group By: Group	🔵 Instance 🔵 Type
	Categories	
	Hide un-checke	d categories
	Ch	eck All Check None
	Instance	Both Load Parameters
		Luau Farameters
		.::

Alternatively, the "Open Master" button can be used to use the same master shared parameter file from the "Manage Shared Parameters File" tab. If no master shared parameter file is selected on the "Manage Shared Parameters File" this option will be disabled.

SM Shared Parameter Manager		
SM - 🖹 Export Shared Parameters -	X Configure Default Parameter Groups 🗄 Options	🕡 Help 🕕 About
Manage Shared Parameter File Load S	hared Parameters	
Shared Parameter File:		Browse Open Master
Group By: Group	Selection Set New Delete Rename Copy Group By: Group	Parameter Discipline: Type of Parameters: Group parameter under: Categories Hide un-checked categories
		Check All Check None Instance Type Both Load Parameters

Creating Selection Sets

To create a new selection set, click the "New..." button in the 'Selection Set' box.

Shared Parameter Manager	24					
📶 🗝 📑 Export Shared Param	neters 👻 🔀 Configur	e Default Parameter Groups	i = Options	🕜 Help	()) About	
fanage Shared Parameter File	Load Shared Paramete	ers				
Shared Parameter File: C:\Shar	ed Parameters.txt					Browse Open Maste
Group By: Group	•	Selection Set			Parameter	
🗐 Analysis Results	*	New	Delete		Discipline:	
i⊞∽ Circuit i≣∽ Clearance		Rename	Сору		Type of Parameters:	
 Constraints 		4D Parameters		•	Group parameter under:	
Construction						
CTRL Parameters	-	Group By: Group		•		🔘 Instance 🔘 Type
Unensions	=				Categories	
Electrical - Lighting					Hide un-checked ca	ategories
Electrical - Lighting						
Electrical Productivity Pack						
Energy Analysis						
Exported Parameters						
Fire Protection						
- Graphics	_					
Green Building Properties		>				
Identity Data						
IFC Parameters		<				
Materials and Finishes						
Mechanical						
Mechanical - Air Flow						
Mechanical - Loads						
⊡ Other						
Phasing					Check	All Check None
Photometrics					C	
≝n Plumbing ∓n BIS∆FileNames	-				Instance Type Bo	Load Parameters

Name the selection set and click the "Create" button.

SM Create Selection	Set	x
Selection Set Name	: COBie2 Parameters	
	Create	ancel

Note: Multiple selection sets can be created, using this same process.

To add groups or parameters from the shared parameter file to the selection set, select the group or parameters then click the add arrow.

SM Shared Parameter Manager			
SM - Export Shared Parameters - 💥 Configure De	efault Parameter Groups 🗄 Options 🔞 H	lelp 🕕 About	
Manage Shared Parameter File Load Shared Parameters			
Shared Parameter File: C:\Shared Parameters.txt			Browse Open Master
Group By: Group	Selection Set	Parameter	
🛨 Analysis Results	New Delete	Discipline:	
terrenter en	Rename Copy	Type of Parameters:	
DOBie2	4D Parameters 💌	Group parameter under:	-
COBieAerostituing environmente COBieAerostituing environmente COBieAerostituing COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieColor COBieConstituents COBieCreatedBy COBieCreatedBy COBieCreatedDon COBieDescription COBieDescription COBieDescription COBieEpectedLife COBieFeatures COBieFinish COBieGrade COBieGrade COBieGrade COBieModelReference	Group By: Group	Categories	egories
		Instance Type Bot	h Load Parameters
			.:

Note: Group name will copy over as well.

Modify Selection Sets

To rename a selection set, chose the selection set from the drop-down menu and click the "Rename" button.

anage Shared Parameter File Load Shared Pa	arameters			
ared Parameter File: C:\Shared Parameters.txt				Browse Open Master
oup By: Group	• _ ⁵	Selection Set	Parameter	
- Analysis Results	<u> </u>	New Delete	Discipline:	
l- Circuit (Bename Copy	Turne of Decementary	
- Clearance		nename Copy	Type or Parameters:	
COBie2	= 4	4D Parameters 🔹	Group parameter under:	
CUBieAccessibilityPerformance				Instance C Tupe
COBIEAssetTune	Gro	oup By: Group 👻	Calanzia	Instance O Type
COBieBarCode		COBie2	Categones	
COBieCategory			Hide un-checked cat	egories
		COBieAssetIdentifier		
COBieColor		- COBieAssetType		
COBieConstituents		COBieBarCode		
COBieCreatedBy		COBieCategory		
		COBieCodePerformance		
COBieDescription		COBieColor		
COBieDurationUnit		COBieConstituents		
COBieExpectedLife		COBieCreatedBy		
COBieFeatures		COBieCreatedOn		
COBieFinish		COBieDescription		
COBieGrade		COBieDurationUnit		
CUBieInstallationDate		COBieExpectedLife		
CUBieMaterial		COBieFeatures		
CUBieModelHeterence		COBieFinish	Charles (
CUBieNominalHeight		CUBieGrade	Lneck A	Check None
COBieNersie en GM		CUBielnstallationDate		
LUBIENOMINAIWIdth	-	CUBieMaterial	Instance Tune Bo	th Load Parameters

Type in new selection set name and click the "Create (OK)" button.



Deleting Selection Sets

To delete a selection set, click the "Delete..." button.

SM Shared Parameter Manager		
🖬 🕶 📑 Export Shared Parameters 👻 Config	ure Default Parameter Groups 🗄 Options 🔞 Help 🕦 About	
Manage Shared Parameter File Load Shared Param	eters	
Shared Parameter File: C:\Shared Parameters.bt		Browse Open Master
Group By: Group 🗸	- Selection Set	
- Analysis Results	New Delete Discipline:	
Circuit Clearance	Rename Copy Type of Parameters:	
COBie2	COBie2 Group parameter under:	~
	Group By: Group	🔵 Instance 🔵 Type
COBieBarCode COBieCategory	COBie2	ategories
COBieCodePerformance COBieColor	···COBieAssetIdentifier ···COBieAssetType ≡	
COBieConstituents	COBieBarCode	
COBieCreatedOn	COBieCodePerformance	
	COBieColor	
COBieExpectedLife		
COBieFinish	COBieCreatedOn	
COBieGrade	COBieDurationUnit	
	CUBieExpectedLife	
COBieModelReference	COBieFinish	
COBieNominalHeight	COBieGrade Lheck	All Lheck None
COBieNominalWidth	COBieMadelReference Type B	oth Load Parameters

Click "Yes" to delete or "No" to cancel.

Delete 'Door Parameters' Selection Set		23
Do you want to delete the 'Door P selection set?	arameters'	
Ye	es No	>

To copy a selection set, click the "Copy..." button.

SM Shared Parameter Manager		
- Export Shared Parameters - 💥 Confi	gure Default Parameter Groups 🗄 Options 🔞 Help	(1) About
Manage Chaund Baranata File Load Shared Parer	maters	•
Shared Parameter File: C:\Shared Parameters.bt	Selection Set	Browse Upen Master
Group Sy: Group	New Delete	Parameter
Anaysis Hesuits	Bename	Tupe of Parameters:
		Group parameter under
COBieAccessibilityPerformance	COBiez	
COBieAssetType	Group By: Group	Categories
	COBie2 COBieAccessibilityPerformance	Hide un-checked categories
COBieCodePerformance	COBieAssetIdentifier	
	COBieBarCode	
	···· COBieCategory	
	COBieColor	
	COBieCreatedBy	
COBieFeatures	COBieCreatedOn	
- COBieGrade	COBieDurationUnit	
	COBieFeatures	
COBieModelReference	COBieFinish	Check All Check None
COBieNominalLength	COBielnstallationDate	
COBieNominaWidth	COBieMaterial	Instance Type Both Load Parameters
Changed Descenders Manager		
SM Shared Parameter Manager		
SM Shared Parameter Manager	gure Default Parameter Groups 🛛 🗄 Options 🔞 Help	i About
SM Shared Parameter Manager SM - Export Shared Parameters - X Config Manage Shared Parameter File Load Shared Param	gure Default Parameter Groups 🛛 🗄 Options 🛛 🔞 Help meters	About
SM Shared Parameter Manager SM • Export Shared Parameters • Config Manage Shared Parameter File Load Shared Parameters Shared Parameter File: C:\Shared Parameters.bt	gure Default Parameter Groups 🛛 🗄 Options 🔞 Help meters	About Browse Open Master
SM Shared Parameter Manager SM - Export Shared Parameters - Config Manage Shared Parameter File Load Shared Parameters Shared Parameter File: C:\Shared Parameters.bt Group By: Group -	gure Default Parameter Groups 🗄 Options 🔞 Help meters Selection Set	About Browse Open Master Parameter
SM Shared Parameter Manager SM Export Shared Parameters Config Manage Shared Parameter File Load Shared Parameter File Shared Parameter File: C:\Shared Parameters.bt Group By: Group Analysis Results	gure Default Parameter Groups 📰 Options 🕢 Help meters Selection Set New Delete	About Browse Open Master Discipline:
SM Shared Parameter Manager SM	gure Default Parameter Groups 🗄 Options 🕡 Help meters Selection Set New Delete Rename Copy	About Browse Open Master Discipline: Type of Parameters:
SM Shared Parameter Manager SM Export Shared Parameters Config Manage Shared Parameter File Load Shared Parameter File Shared Parameter File: C:\Shared Parameters.bt Group By: Group Analysis Results Circuit	gure Default Parameter Groups 📰 Options 🔞 Help meters Selection Set New Delete Rename Copy	About Browse Open Master Discipline: Type of Parameters: Group parameter under:
Shared Parameter Manager SM - Export Shared Parameters - CoBieAccessibilityPerformance CoBieAccessibilityPerformance	gure Default Parameter Groups 🗄 Options 🔞 Help meters Selection Set New Delete Rename Copy COBie2	About Browse Open Master Discipline: Type of Parameters: Group parameter under: Instance Type
SM Shared Parameter Manager SM Export Shared Parameters Config Manage Shared Parameter File Load Shared Parameters bt Group By: Group Analysis Results Circuit COBieAccessibilityPerformance COBieAssetUdentifier COBieAssetType COBieAccel COBieAssetType COB	gure Default Parameter Groups 🗄 Options 🔞 Help meters Selection Set New Delete Rename Copy Group By: Group	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories
Shared Parameter Manager SM Shared Parameter Manager Manage Shared Parameter File Load Shared Parameter File Load Shared Parameter File Load Shared Parameters bt Group Group Group Course CobieAccessibilityPerformance COBieAccessibilityPerformance COBieAssetUge COBieBasCode COBieCategory	gure Default Parameter Groups := Options @ Help meters Selection Set New Delete Rename Copy COBie2	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories
Shared Parameter Manager SM - Export Shared Parameters - COBieCodeParameter File Load Shared Parameter File Load Shared Parameter File Load Shared Parameters.txt Group Group Group Group CobieCategory COBieCodeParameter CoBieCodParameter CoBieCodParameter CoBieC	gure Default Parameter Groups I ⊂ Options I Help meters Selection Set Rename Copy COBie2 Group By: Group COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie2 COBie3 COBie3 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4 COBie4	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories
Shared Parameter Manager SM + Export Shared Parameters - & Config Manage Shared Parameter File Load Shared Parameter File Load Shared Parameter File Load Shared Parameters but Group By: Group • Analysis Results CoBieAccessibilityPerformance COBieAccessibilityPerformance COBieAccessibilityPerformance COBieAccessibilityPerformance COBieAccessibilityPerformance COBieAccessibilityPerformance COBieAccessibilityPerformance COBieAccessibilityPerformance COBieCodePerformance COBieColor COBieColor COBieColor COBieCodePerformance COBieColor COBieCodePerformance COBieCodePerformance COBieColor COBieCodePerformance COBieColor COBieCodePerformance COBieColor COBieCodePerformance COBieColor COBieCodePerformance COBieCodePer	gure Default Parameter Groups I ⊂ Options	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories
SM Shared Parameter Manager SM ► Export Shared Parameters ▼	gure Default Parameter Groups 📰 Options <table-cell> Help meters Selection Set New Delete Rename Copy COBie2 COBie2 COBie2 COBieAccessibilityPerformance COBieAssetType COBieBarCode COBieBarCode COBieCategory COBieCodePerformance</table-cell>	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories
Shared Parameter Manager SM ► Export Shared Parameters ▼	gure Default Parameter Groups ⋮Ξ Options @ Help meters Selection Set New Delete Rename Copy COBie2 Group By: Group COBieAccessibilityPerformance COBieAssetIdentifier COBieAssetIdentifier COBieAssetIdentifier COBieCategory COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories
Shared Parameter Manager SM ► Export Shared Parameters ▼	gure Default Parameter Groups ⋮Ξ Options @ Help meters Selection Set New Delete Rename Copy COBie2 Group By: Group COBieAccessibilityPerformance COBieAssetIdentifier COBieAssetIdentifier COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories
SM Shared Parameter Manager SM ► Export Shared Parameters ▼	gure Default Parameter Groups ⋮Ξ Options @ Help meters Selection Set New Delete Rename Copy COBie2 Group By: Group COBie2 COBieAccessibilityPerformance COBieAssetUdentifier COBieAssetType COBieCategory COBieCategory COBieCode COBieConstituents COBieCreatedBy COBieCreatedBy COBieCreatedDn COBieCreatedDn COBieCreatedDn	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories
Shared Parameter Manager SM ► Export Shared Parameters - X Config Manage Shared Parameter File Load Shared Parameter File Shared Parameter File Load Shared Parameters but Group By: Group	gure Default Parameter Groups ⋮Ξ Options @ Help meters Selection Set New Delete Rename Copy COBie2 Group By: Group COBieAccessibilityPerformance COBieAssetIdentifier COBieCategory COBieCode Performance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPerformance COBieCodPe	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories
Shared Parameter Manager SM ► Export Shared Parameters - X Config Manage Shared Parameter File Load Shared Parameter File Shared Parameter File Load Shared Parameters but Group By: Group	gure Default Parameter Groups ⋮Ξ Options @ Help meters Selection Set New Delete Rename Copy Group By: Group Group By: Group COBie2 COBie2 COBieAccessibilityPerformance COBieAssetIdentifier COBieAssetIdentifier COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy COBieCreatedDy	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories
Shared Parameter Manager SM ► Export Shared Parameters - X Config Manage Shared Parameter File Load Shared Parameter Shared Parameter File Shared Parameter File Load Shared Parameters but Group By: Group	gure Default Parameter Groups ⋮Ξ Options Performance Selection Set New Delete Rename Copy COBie2 Group By: Group COBie2 COBieAccessibilityPerformance COBieAccessibilityPerformance COBieCodePerformance COBieCodePerforma	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories Check All Check None
Shared Parameter Manager SM ← Export Shared Parameters ~ X Config Manage Shared Parameter File Load Shared Parameter State Group By: Group ● ● Analysis Results ● ● Crouit ● ● Clearance ● ● COBieAccessibilityPerformance ● ○ CDBieAccessibilityPerformance ● ○ CDBieAccessibilityPerformance ● ○ CDBieAccessibilityPerformance ● ○ CDBieCodePerformance ●	gure Default Parameter Groups ⋮Ξ Options Performance Selection Set Rename Copy CoBie2 Group By: Group CoBieAccessibilityPerformance CoBieAssetIdentifier CoBieAssetIdentifier CoBieCategory CoBieCodePerformance CoBieCodePerformance CoBieCodePerformance CoBieCodePerformance CoBieCodePerformance CoBieCodePerformance CoBieConstituents CoBieCreatedDn CoBieCrea	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories Check All Check None Data
Shared Parameter Manager SM ► Export Shared Parameters - X Config Manage Shared Parameter File Load Shared Parameter State Group By: Group The Analysis Results • COBieAccessibilityPerformance COBieAccessibilityPerformance COBieAssetIdentifier COBieAccessibilityPerformance COBieAccessibilityPerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieCodePerformance COBieDecedeDy COBieDecedeDin COBieDecedeDy COBieDecedeDin COBieDecedeDin COBieDecedeDin COBieDecedeDy COBieDurationUnit COBieDecededDy COBieDurationUnit COBieBeatego COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieBrade COBieModelReference COBieModelReference COBieNominalHeight COBieNominalLength COBieNominalLength COBieBenacementCost T <td>gure Default Parameter Groups ⋮Ξ Options Performance COBie2 Group By: Group Group By: Group COBie2 COBieAccessibilityPerformance COBieAssetIdentifier COBieAssetIdentifier COBieColor COBieCodePerformance COBieColor COBieColor COBieColor COBieCreatedDy COBie</td> <td>About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories Check All Check None Instance Type Both Load Parameters</td>	gure Default Parameter Groups ⋮Ξ Options Performance COBie2 Group By: Group Group By: Group COBie2 COBieAccessibilityPerformance COBieAssetIdentifier COBieAssetIdentifier COBieColor COBieCodePerformance COBieColor COBieColor COBieColor COBieCreatedDy COBie	About Browse Open Master Parameter Discipline: Type of Parameters: Group parameter under: Instance Type Categories Hide un-checked categories Hide un-checked categories Check All Check None Instance Type Both Load Parameters

In the "Copy Selection Set" dialog, name the selection set and click the "Create" button.

SM Copy 'COBie2 Para	meters' Selection Set 💷 🛛 🛛
Selection Set Name:	COBie2 Parameters - Copy
	Copy Cancel

Sorting Shared Parameters File

The organization of the shared parameter file can be changed to make locating parameters easier. To organize the shared parameter file by shared parameter groups, click the "Group by..." drop down menu.

M Shared Parameter Manager		
SM - Export Shared Parameters - 💥 Configure	Default Parameter Groups 🗄 Options 🔞 Help 🕦 About	
Manage Shared Parameter File Load Shared Parameter	15	
Shared Parameter File: C:\Shared Parameters.txt		Browse Open Master
Group By: Group 👻	Selection Set	
🗄 Analysis Results	New Delete Discipline:	
Circuit Clearance	Rename Copy Type of Parameters:	
COBie2	COBie2 Group parameter under:	~
COBieAssetIdentifier COBieAssetType COBieBarCode COBieCategory COBieCadePerformance COBieCodePerformance COBieColor COBieContinuents	Group By: Group Group By: Group CoBie2 COBieAscetsibilityPerformance COBieAssetUgentifier COBieAssetUgen COBieAssetUge CoBieAssetUge	Instance Type
COBieCreatedBy COBieCreatedDn COBieDescription COBieDurationUnit COBieExpectedLife COBieFeatures	COBieCategory COBieCodePerformance COBieColor COBieConstituents COBieCreatedBy COBieCreatedDn COBieCreatedOn	
CUBieFinish COBieGrade COBieInstallationDate COBieModelReference COBieMominalHeight COBieNominalLength COBieNominalWidth COBieRonacementCost	CDBieDescription COBieExpectedLife CDBieFeatures CDBieFinish CDBieGrade CDBieInstallationDate CDBieMaterial CDBieMaterial CDBieMaterial	All Check None th Load Parameters
		.:

The shared parameter file can also be organized by parameter type. This will group, for example, all of the "Length" parameters together. To group by parameter type, select "Group" from the "Group By" dropdown menu.



Parameter Settings

The parameter settings are used when loading the selection set into a project as Revit project parameters. To configure parameters, select them from the list and define the discipline, type of Parameter, "group Parameter under", and whether the parameter is instance (green) or type (blue). Multiple parameters can be configured simultaneously.



Default parameter groups can be configured to help automate the process of configuring parameters. These settings will help automatically assign the "Group parameter under" value. To setup default parameter groups click the "Configure Default Parameter Groups" button.



The "Set Default Parameter Groups" dialog has all parameter types on the right, and grouping options for those parameters on the left. Simply drag and drop each parameter type into the desired default group. For example, "Length" and "Angle" type parameters are typically grouped under the "Dimensions" group.



With default parameter groups configured, as parameters are added to the selection set they will be assigned their parameter group automatically. These groups can always be changed after the fact.

Loading Parameters Into the Project

Once all parameters have been configured the "Load Parameters..." button can be used to load each parameter in the selection set into the project as a shared project parameter.

SM Shared Parameter Manager		
🖬 - Export Shared Parameters - 💥 Config	ure Default Parameter Groups 🗦 Options 🔞 Help	() About
Manage Shared Parameter File Load Shared Param	eters	
Shared Parameter File: C:\Shared Parameters.txt		Browse Open Master
Group By: Parameter Type 🔻	Selection Set	'COBie Material' Parameter
🐨 Air Flow	New Delete	Discipline: Common
⊞⊸ Angle ⊞⊸ Apparent Power	Rename Copy	Type of Parameters: Text
⊕ Area ≡	COBie2	Group parameter under: Other
E	Group By: Group Group By: Group COBie2 COBieAccessibilityPerformance COBieAssetIdentifier COBieBarCode COBieCodePerformance COBieColor COBieConstituents COBieCreatedBy COBieCreatedDu COBieCreatedUrie COBieFeatures COBi	Instance Type Categories Hide un-checked categories Air Terminals Analytical Beams Analytical Columns Analytical Columns Analytical Floors Analytical Nodes Analytical Walls Area Loads Check All
Control KVA Systems One and Four		Instance Type Both Load Parameters

Click "Yes" to load new selection set, click "No" to cancel.



Options

To access options, select the "Options" button at the top of the 'Shared Parameters Manager' dialog

SM Shared Parameter Manager		
SM - Export Shared Parameters	• 🔏 Configure Default Parameter Groups 📃 Options 🔞 Help 🔞 About	
Manage Shared Parameter File Load S	Shared Parameters	
Shared Parameter File: C:\Shared Para	meters.bd	Browse Open Master
Group By: Parameter Type	Selection Set COBieMate COBieMate	erial' Parameter

There are several options to control the default behavior of Shared Parameter Manager

SM Options		_ XX
Remember the size and position of the main	n window	ι.
Warn if category is not applicable to type pa	arameter	s.
Display the parameters not copied because	of duplie	cate name.
Backup master shared parameter file before	e overwri	itting.
Maximum backups: 1		
Ok	Ca	ancel

All options are user options, meaning they will be remembered per computer

Type Swapper

Type swapper provides the ability to change the type or style used for existing instances of text, dimensions and line elements in the active project. Duplicate family elements, usually the result of copying elements from one file to another, can also be swapped out for the original family and type.

Starting Type Swapper

On the Revit ribbon, click on the "Type Swapper" button.



The Type Swapper dialog will appear:

uplicate Fami	lies Dimension Styles Text Types Line S	tyles Line Patterns Fill Patterns	Materials MEP Syst	em Types
Approved	🗹 Pending 🔚 Save Selection 🕻 Load Sele	ection 😑 Clear Selection 👻 Dele	te Dimension Style:	<all></all>
pproved	Existing Dimension Types	Dimension Style 🛛 🛆	Count	Swap to
	Diameter - 3/32" Trebuchet MS	Diameter Dimension Style	1	<no change=""></no>
	Diameter Dimension Style	Diameter Dimension Style	0	<no change=""></no>
	Linear - 3/32" Trebuchet MS	Linear Dimension Style	247	<no change=""></no>
	Linear Dimension Style	Linear Dimension Style	0	<no change=""></no>
	Linear Dimension Style	Linear Dimension Style	0	<no change=""></no>
	Linear Dimension Style	Linear Dimension Style	0	<no change=""></no>
	Arc Length - 3/32" Trebuchet MS	Linear Dimension Style	0	<no change=""></no>
	Linear - 3/32" Trebuchet MS (Check)	Linear Dimension Style	442	<no change=""></no>
	Horizontal	Spot Coordinates	0	<no change=""></no>
	Horizontal (w-Elevations)	Spot Coordinates	0	<no change=""></no>
	Crosshair (Project)	Spot Elevations	0	<no change=""></no>
	Dot Leader (Project)	Spot Elevations	0	<no change=""></no>
	No Symbol (Project)	Spot Elevations	0	<no change=""></no>
	Target (Relative)	Spot Elevations	0	<no change=""></no>
	Target w Dot Leader (Project)	Spot Elevations	0	<no change=""></no>
	Target (Project)	Spot Elevations	0	<no change=""></no>
	Target Leader (Project)	Spot Elevations	0	<no change=""></no>
	Crosshair (Relative)	Spot Elevations	0	<no change=""></no>
	No Symbol (Relative)	Snot Elevations	0	<no change=""></no>

Duplicate Families

The "Duplicate Families" tab identifies families in the project that follow a naming convention of "<Family Name><number>" which is usually the result of Revit duplicating the family definition when elements are copied from project to project. For example "Baluster – Round4" at the top of the list:

TS Type Swapper		— D X			
TS → Ξ Options 🔞 Help 🔁 Videos 🙅 Support 🕦 About					
Duplicate Families Dimension Styles Text	Types Line Styles Line Patterns Fill Patterns	Materials MEP System Types			
🖥 Save Selection 🖸 Load Selection 🖃 Clear Selection 👻 Category:					
Family	Category	/ Swap With			
Baluster - Round4	Balusters	Baluster - Round			
Callout Head I Callout Heads		Callout Head			
Circular Handrail1	Profiles	Circular Handrail			
Section Head - no arrow1	Section Marks	Section Head - no arrow			
		Contine Tail Filled Hadenated			
Section Tail - Filled Horizontal1	Section Marks	Section Tall - Filled Horizontal			

Type Swapper will suggest the original family (typically <Family Name> without the number) from the project as the default "Swap With" option. In this example the "Baluster - Round" type has been selected by default.

Dupreate r annines Dimension Styles	Text Types Line Styles Fill Fatterns M	diendis	
🔚 Save Selection 🦸 Load Selection			~
Family	△ Category	Swap With	^
Bifold-4 Panel1	Doors	Bifold-4 Panel	
Bifold-4 Panel2	Doors	Bifold-4 Panel	
Break Line1	Detail Items	Break Line	
Break Line2	Detail Itomo	Break Line	
Break Line3	Detail Items	Break Line	
Rreak line4	Detail Items	Rreak Line	

The list of families shown can be filtered by category by using the "Category" dropdown. By selecting the "Doors" category only duplicate doors are shown in the dialog below.

Type Swapper TS → Ξ Options 🕡 He	lp 下 Video	s 🕦 About				×
Duplicate Families Dimensio	n Styles Te	xt Types Line Styles Fill Par Clear Selection 🗸 Category:	tterne Materiale Doors			~
Family	Ζ.	Category	Swap With			
Bifold-4 Panel1		Doors	Bifold-4 Panel			
Bifold-4 Panel2		Doors	Bifold-4 Panel			
Double-Flush1		Doors	Double-Flush	Double-Flush		
Single-Flush1		Doors	Single-Flush	Single-Flush		
Single-Flush2		Doors	Single-Flush			

If a promising candidate for swapping can be found, it is selected in the "Swap With" column automatically. In the example above, "Single-Flush" is a promising candidate for the "Single-Flush1" family that was found.

To prevent an unwanted swap, simply select the "<No Change>" option from the dropdown for each family.

Save Selection C Load Selection		~
Family	△ Category	Swap With
Bifold-4 Panel1	Doors	Bifold-4 Panel
Bifold-4 Panel2	Doors	Bifold-4 Panel
Double-Flush1 🥿	Doors	Double-Flush 🗸
Single-Flush1	Doors	<no change=""></no>
Single-Flush2	Doors	Double-Flush

Once all families have been configured with the desired "Swap With" options, click the "Swap" button at the bottom of the window to swap the types used on the instances of the families in the project. The "Delete duplicate families" option will remove the duplicate family once all instances have been swapped for the mapped type.

Family	Category	Swap With
Bifold-4 Panel1	Doors	Bifold-4 Panel
Bifold-4 Panel2	Doors	Bifold-4 Panel
Break Line1	Detail Items	Break Line
Break Line2	Detail Items	Break Line
Break Line3	Detail Items	Break Line
Break Line4	Detail Items	Break Line
Break Line5	Detail Items	Break Line
Brick Standard2	Detail Items	Brick Standard
		Delete duplicate families Swap

Swapping Elements

The "Text Types", "Dimension Styles", "Line Styles", "Line Patterns", "Fill Patterns", "Materials", "MEP System Types" and "Viewport Types" interfaces work in a similar way to the "Duplicate Families" tab, however no mappings will be suggested by default.

Type Swapper								_		×
TS - ☷ Option	s 🔞 Help 📘 Vi	ideos Qu	oport 🕕 Ab	out						
Duplicate Families	Dimension Styles	Text Types	Line Styles	Line Patterns	Fill Patterns	Materials	MEP System Types	Viewport Type	s	
Approved 🔽	Pending 📊 Save	Selection 🖒	Load Selecti	on 🖃 Clear S	election 👻 💢	Delete 🔻				
Approved	Existing Viewp	ort Types		Δ.	Count		Swap to			
	No Title				3		<no change=""></no>			
	Section 1				0		<no change=""></no>			
	Title w Line				0		<no change=""></no>			
	Viewport 1				41		<no change=""></no>			•
							Section 1 Title w Line			
									Sw	ар
adv										

To map a change, select an option from the "Swap to" dropdown menu for each text type. In this classic example *332 Arial* is being swapped for the *3/32" Arial* text style.

Approved	Pending 🔚 Save Selection 🖒 Load Selec	tion \equiv Clear Selection \rightarrow \approx Delete Dimension	sion Style: <all></all>		
Approved	Existing Dimension Types	Dimension Style /	Count	Swap to	
	Diameter	Diameter Dimension Style	0	<no change=""></no>	
_	Diameter Dimension Style	Diameter Dimension Style	0	<no change=""></no>	
	Linear - 3/32" Arial	Linear Dimension Style	17	<no change=""></no>	
	Linear Dimension Style	Linear Dimension Style	0	<no change=""></no>	
	Linear Dimension Style	Linear Dimension Style	0	<no change=""></no>	
	Linear Dimension Style	Linear Dimension Style	Linear Dimension Style 0		
	332 Arial	Linear Dimension Style	2	<no change=""></no>	
	Linear - 3/32" Arial Arrow	Linear Dimension Style	6	<no change=""></no>	
				Linear - 3/32 Antal Linear - 3/32 Antal Arrow Linear Dimension Style Linear Dimension Style Linear Dimension Style	

Approved Styles and Types

Administrators can specify by name which text types are approved for use by checking the "Approved" checkbox for each type or style. This provides clarification to ensure users are swapping unwanted types for the company standard types. Either check the boxes individually or use the right-click menu to check/uncheck several at a time.

Approved	🦉 Pending 🛛 🔚 Save S	Selection C Load Selection	n 😑 Clear Selection 🛛 💥 Delete 🛛 Dimer	sion Style: <all></all>	~
Approved	Existing Dimension	on Types	Dimension Style /	Count	Swap to
	Diameter		Diameter Dimension Style	0	<no change=""></no>
	DiDi		Diameter Dimension Style	0	<no change=""></no>
~ 1 5 /	Delete selected		Linear Dimension Style	17	<no change=""></no>
=	Clear selection	yle	Linear Dimension Style	0	<no change=""></no>
	Invert Selection	yle	Linear Dimension Style	0	<no change=""></no>
	Set approved	Check selected	Linear Dimension Style	0	<no change=""></no>
Ċ.	332 Arial	Uncheck selected	Linear Dimension Style	2	<no change=""></no>
0	Linear - 3/32" Arial Arrow		Mark the selected items as approved	6	<no change=""></no>
					Swap

Note: The list of approved types and styles can be both locked and deployed, preventing users from editing which items are approved or not. For more information about securing these settings, please consult the *CTC Suites Installation and Configuration* guide.

Saving and Loading Selections

Each of the tabs contain a 'Save Selection' button. This can be extremely useful to recall swap selections that are often needed on multiple projects. Each tab creates a file type corresponding to it's function. For example, saving a selection set from the Duplicate Families tab creates a .tsdf file. Other tabs save to extensions which follow a similar convention.

Approved	Pending 🕞 Save Selection	C Load Selection = C	lear Selection - 🔀 Delete Dimens	sion Style: <all></all>			
pproved	Existing Dimension Types		Dimension Style	Count	Swap to		
	Diameter		Diameter Dimension Style	0	<no change=""></no>		
<u>~</u>	Diameter Dimension Style		Diameter Dimension Style	0	<no change=""></no>		
	Linear - 3/32" Arial		Linear Dimension Style	17	<no change=""></no>		
\sim	Linear Dimension Style		Linear Dimension Shile	0	Ale Changes		
	Linear Dimension Style	Save Selection					
	Linear Dimension Style						
	332 Arial	$\leftrightarrow \rightarrow \checkmark \uparrow$	This PC > Temp Transfer (T:) > WC > TS				
	Linear - 3/32" Arial Arrow						
		Organize 🔻 New	folder				
		> 📻 Developmen	t (P:) Name	^	Date modified	Тур	
		> 💼 QB Database	s (Q:)		No items match you	ur search.	
		> 📻 Manufacture	r Content (R:				
		_	1				

To load a previously saved selection set, simply click 'Load Selection' and browse to the specific file. If a style or type from the saved selection does not exist in the current project, it will be ignored and omitted from the list.

Process Logs

After each swap operation, a log of the swapped elements and their status is displayed. This log can then be saved to a file which is readable by most common spreadsheet applications.

C	Events			Organ	nize 🔻 Ne	w fold	er	
Ē				۵.	Music	^	Name	Date modified
45	Copy to Cli	pboard 📄 Save			Pictures		\$RECYCLE.BIN	4/1/2016 3:58 PM
	Туре	Time	Message	-	Videos		2015revitdocs	11/25/2015 10:25
	Info	2016-07-15 16.36.12.019	Successful, swapped "Bifold-4 Panel1"		10 (C:)		2016-addin	1/22/2016 1:48 PM
	Info	2016-07-15 16.36.12.061	Successfully deleted "Bifold-4 Panel 1" fa		Data (Di)		app testing	7/15/2016 3:44 PM
	Info	2016-07-15 16.36.12.118	Successfully swapped "Birold-4 Panel2"			- v	<	.,,
	Info	2016-07-15 16.36.12.147	Successfully deleted "Bifold-4 Panel2" fa		81 (E-)			
6	Info	2016-07-15 16.36.12.200	Successfully swapped "Double-Flush 1" f		File name:	Туре	Swapper - Swap Duplicate Families Log.xlsx	
) Info	2016-07-15 16.36.12.227	Successfully deleted "Double-Flush1" far	-	Save as type:	Micro	soft Excel Workbook (*.xlsx)	
(Info	2016-07-15 16.36.13.533	Successfully swapped "Single-Flush1" fa					
(Info	2016-07-15 16.36.13.563	Successfully deleted "Single-Flush1" fam	∧ Hid	e Folders			Save
			1	1				

Appendix

Family Checker Rating Conventions

Properties

HIVE Rating - Average of all 'Global Review' scores
Organization Rating - Average of all 'Corporate Review' scores
FilePath - The path to the Revit family file
FileName - FamilyName.rfa from file being reviewed
FamilyType - "Model" or "Annotation"
Category - Family Category Value
ReviewDate - Date the Family Check was run in MM/DD/YYYY format
ReviewNumber - GUID generated at time of Run

Scoring

IdentityData

Score 5 if URL, Manufacturer and Model values are used

Score 1 if one of the parameters do not have a value

Null or no value if family is Annotation or Category is Detail Component, Mass or Profile

DetailLevel

Score of 0 until all check is completed

5 if each detail level has something different showing in plan view

3 if Coarse is different from Medium and Fine but Medium and Fine are the same

1 if no change is detected for any detail level

NULL (Empty in Excel) if Family type is Annotation or family category is a Mass or Profile

Detail_Level3D

Score 5 if Coarse, Medium, and Fine show different levels of detail in the family while in a 3D view

• Solids and model lines should not have the same settings to not show or show at varying levels of detail

- There should be at least one solid or model line that shows and doesn't show at each detail level
- Solid X doesn't show at medium and coarse
- Solid Y doesn't show at Coarse
- Model Line Z shows at all detail levels
- Model Line A doesn't show at medium and fine

Score 3 if Medium and Fine are the same but Coarse is different

Score 1 if all levels show no change in the family

NULL or no value if Annotation, Profile or Detail Component

VisibilityPlan

Score 0 until further evaluation

Score 5 if All Solid Geometry is off in RefLevel Floor Plan or RefLevel Ceiling Plan views and a detail Item, generic annotation, detail lines or filled region is visible in plan view (Ref Level)

Score 3 if any solid is visible in plan at any detail level, but 2D components also exist in plan... See Optimal rules to determine if 2D content exists in plan

Score 1 if only solid geometry is visible in plan view at any detail level

NULL or no score if Annotation, Detail Item, Mass or Profile

VisibilityGeneral

Score 5 if the family is visible in all views including sections

Score 1 if geometry is not showing in any of the views

NULL or no score if Annotation, Detail Item, or Profile

ImportedContent

Score 5 if no trace of imported content is left behind. (Materials, Sub-Object Styles, etc..)

Score 1 if: Traces of Imported geometry remains in the model

GeometryFlex

Score 5 if the geometry in family is constrained

- Solids must have sketch locked to reference planes and non-sketched faces locked to reference planes
- Detail/Model Lines must have ends soft constrained to other linework and position locked to a reference plane
- Detail Items must have sketch locked to reference planes

- Nested model families must follow same rules for internal geometry and have placed instances locked to a single reference plane in X, Y and Z directions
- Nested Detail/Annotation families must follow same rules for internal geometry and have placed instances locked to a single reference plane in X and Y directions
- Any arcs in families may be directly dimensioned
- No geometry should be locked to any geometry other than reference lines or reference planes

Score 4 if the family should be reviewed by a person

- If any of the 'Optimal' criteria is not able to be validated for a specific piece of geometry the related _Comments field should state "MANUAL REVIEW RECOMMENDED:" and list any element ID of the component that is being questioned.
- If the component is in a nested family, list the name of the nested family

Score 1 if the family has geometry that is not constrained per rules in Optimal settings

- If Action required is used the related _Comments field should state "MANUAL REVIEW REQUIRED:" and list any element ID of the component that is being questioned.
- o If the component is in a nested family, it will list the name of the nested family

NULL or no score if Family_Type is Annotation Symbol

TypeFlex

Score 5 if No error show when loading a family into a project and family is generating all available types without error

Score 1 if Errors appear when loading or if when the type is changed the model flexes with errors

HostFlex

Score 5 if family is able to be placed in host and host can flex 30% larger and smaller with no warnings

Score 1 if optimal rules are not met

Null or no score if Family is un-hosted or is line based, Annotation, Profile or Detail component

MEPConnectors

Score 5 if connections exist in the family

Score 1 if 'Category' is MEP related based on discipline association settings but no connectors exist in family

Null or no score if 'Category' is not MEP related based on discipline association settings and no connectors exist in family

MEPConnectorDescriptions

Score 5 if (a) Connector Description field is populated and linked to a parameter in the family

Score 4 if description is not populated

Score 3 if Description is populated but no parameter is linked

Score 1 if Description is not populated and no parameter is linked

Null or empty value if 'Category' is not MEP related based on discipline association settings

MEPConnectorMapping

Score 5 if all linkable Connector parameters are linked to parameters in the main family

Score 4 if:

- not all the important parameters are linked to parameters in the family
- Important connector parameters are parameters not in the 'Identity Data' group in the connector properties
- Currently Utility and Connector Description are the only parameters in the Identity Data group
- In related _Comments, "Action Recommended: " and List element ID values for each connector where action is recommended

Score 3 if Important parameters are linked to parameters in the family

- Important connector parameters are parameters not in the 'Identity Data' group in the connector properties
- Currently Utility and Connector Description are the only parameters in the Identity Data group

Score 1 if no connector parameters are linked to parameters in the family

Null or empty if 'Category' is not MEP related based on discipline association settings

MEPConnectorDirection

Null or empty if 'Category' is not MEP related based on discipline association settings and no connectors exist in the family

Also NULL if all connectors in the family are electrical connectors

Score 5 if Duct, Pipe, Conduit or Cable Tray connectors have the arrow (Connector Direction) pointing away from the solid on which they are hosted

Score 1 if Value 5 and NULL rules are not met

MEPConnectorLinking

Null or empty if 'Category' is not MEP related based on discipline association settings

Score 5 if the system type is set to "Global" or "Fitting" and there is more than one connector in the family of the matching system type, then there is a link between 2 connectors of the type fitting or of the type global

Score 3 if connectors are linked but are not of type fitting or global

Score 1 if more than one connector of type fitting or global exists but there is no link

MaterialApplication

Score 5 if all solid geometry has the 'Material' parameter linked to a material parameter in the family and material is not 'By Category'

Score 4 if all solid geometry has the 'Material' parameter linked to a material parameter in the family and any material is 'By Category'

Score 3 if any solid geometry has material assigned but not linked to a parameter

Score 1 if any geometry doesn't have a material assigned to it and is not linked to a parameter

Null or empty if FamilyType is Annotation, Profile or Detail Component

Score 1 If Structural Material value exists and is NOT filled with a non-'Default' Material

Null or empty If Structural Material Value does not exist or is not using Structural Categories

MaterialPhysicalProperties

For Categories Structural Columns, Structural Framing, Structural Foundations, Structural Connections,

Score 5 If all materials referenced by types in the family have physical properties

Score 3 If more than 50% of materials referenced by types in the family have physical properties

Score 1 If no materials referenced by types in the family do not have physical properties

Null or empty if family is not using Structural Categories

MaterialThermalProperties

For categories Doors, Windows, Curtain Wall components and Structural elements:

Score 5 If all materials referenced by types in the family have thermal properties

Score 3 If more than 50% of materials referenced by types in the family have thermal properties

Score 1 If no materials referenced by types in the family do not have thermal properties

TypeCatalogUsage

Null or empty if FamilyType is Annotation

Score 5 if a type catalog exists in the same directory as the family and the family has fewer than 2 types OR (no type catalog exists AND the number of types in the family is equal to or fewer than 5)

Score 4 if a type catalog exists, but the types in the family are the same name as the types in the type catalog

Score 3 if the number of family types in the family is equal to or fewer than 10 and no type catalog exists

Score 2 if the number of family types is equal to or fewer than 15 and no type catalog exists

Score 1 if the number of types is greater than 15 and no type catalog exists

OmniClassNumber

Null or empty if FamilyType is Annotation

If FamilyCategory is Detail Items or Mass:

Score 5 if NULL Rules do not apply and OmniClass Number has value

Score 1 if NULL Rules do not apply and OmniClass Number has no value

AssemblyCode

Null or empty if FamilyType is Annotation

If FamilyCategory is Profile, Detail Items or Mass:

Score 5 if NULL Rules do not apply and OmniClass Number has value

Score 1 if NULL Rules do not apply and OmniClass Number has no value

Warnings

Score 5 if no warnings are found in the family

Corporate Review Information

MasterSharedParamater

Score 0 at start until one of the following values update it

Score 5 if the Shared Parameter is found in the Master shared parameter files and

- Shared parameter name matches
- Shared parameter GUID matches
- Shared parameter data type matches

Score 3 if:

- the parameter is a family parameter (not a shared parameter) and
- the parameter name is not found in the Master shared parameter file

Score 1 if a parameter is a Shared Parameter and is NOT from the master list

Null or no value if Family type is Annotation or Family Category is Profile

CustomParameter

Score 5 if the parameter:

- Is a Family parameter
- Does not use any of the values found in the invalid name parts list on the Name Rules tab in Options
- Is grouped properly per the valid groups tab in Options
- Is prefixed with a valid name part
- Is group in the 'Other' parameter group

Score 4 if the parameter

- Is a family parameter
- Does not use values found on the Invalid Name Parts
- Is Grouped in 'Other' parameter group

Score 3 if the parameter:

- Is a Family parameter
- Does not contain any of the values found in the invalid name parts list on the Name Rules tab in Options

Or

• Is not grouped properly per the valid groups tab in Options and is not prefixed with a valid name part

• Is prefixed with a valid name part and is not Grouped in the 'Other' parameter group

Score 1 if Parameter

- Is a shared parameter but is not found in the Master shared parameter file
- Is a shared or family parameter and a similar parameter exists in the master list but one of the following conditions apply
- Same Name / different GUID
- Same GUID / Different name
- Same Name / Different Data Type
- Is a shared or family parameter and contains any of the values found in the invalid name parts list on the Name Rules tab in Options

Null or no value if Family type is Annotation or Family Category is Profile

ParameterGrouping

Score 5 if all parameters are grouped appropriately and appropriate groupings determined by the settings on the Valid Groups tab in options

Score 1 if parameters are not group appropriately per settings in Valid Groups tab in options

FileSize (KB)

Score 5 File Size less than or equal too setting by category

Score 1 file size is greater than setting

SubcategoryStandard

Score 5 If no sub-categories exist in families not available from the Sub-Categories Settings and no custom subcategories are empty/unused (Company Specific)

Score 3 if no sub-categories exist in families not available from the Sub-Categories Settings but at least one custom subcategories is empty/unused

Score 1 Sub-Category is custom (Not built in) and is not in the Sub-Categories Settings list

SubcategoryUnused

Score 5 if Each custom Sub-Category has geometry assigned

Score 3 if Sub-Category is listed in the Sub-Categories Settings list, but has no geometry assigned

Score 1 if Sub-Category is custom (Not built in), not listed in the Sub-Categories Settings list and has no geometry assigned

ApprovedParameter

Score 5 if more than 50% of custom parameters match shared parameters or if there are no custom parameters

Score 3 if more than 0, but less than or equal to 50% of custom parameters match shared parameters

Score 1 if custom parameters exist and no parameters match the shared parameter file

Null or no value if:

- Family_Type = Annotation
- Family Category = Profile

ParameterName

Score 5 if

- parameter name has no special characters: + / \ * () " ' <> | ^ \$ { } [],
- Has no other parts from the 'Invalid name parts' list

Score 1 if any of the above rules are broken

Preview

Score 5 if family preview settings match HIVE Preview Generator settings

Score 1 if any of the above rules are not met

Score NA if family is not sourced from HIVE

ReferencePlaneName

Score 5 if every reference plane has a value in the name parameter

Score 4 if less than 25% of the reference planes are not named

Element ID of unnamed reference planes recorded in related comments field

Score 3 if less than 50% of the reference planes are not named

Element ID of unnamed reference planes recorded in related comments field

Score 1 if greater than 25% of the reference planes are not named

Element ID of unnamed reference planes recorded in related comments field

Null or no value if FamilyType is Annotation